

# D2SA Series

Digital Amplifier Detachable Photoelectric Sensor

Laser Type Amplifier Unit

D2SA-M□ D2SA-S□ D2SA-M□-M8 D2SA-S□-M8

D2SA-M□3 D2SA-S□1 D2SA-M□-M8 D2SA-S□-M8

## Instruction Manual

● Thank you for purchasing DSA Series. We hope you are fully satisfied with this product and enjoy its performance.  
● Carefully read this instruction manual and keep it for future reference.

### Specification

Model	Advanced Model (2CH)		Standard Model (1CH)	
	Base unit	Handset	Base unit	Handset
Cable type	D2SA-M(N/P)	D2SA-S(N/P)	D2SA-M(N/P)3	D2SA-S(N/P)1
M8 connector type	-	-	D2SA-M(N/P)-M8	D2SA-S(N/P)-M8
Adaptable sensor head	DS Series			
Power source, voltage	12 - 24 V DC ± 10% including a ripple			
Consumption current	45 mA or less / 24 V			
Response time	60µs/500µs/2ms (Fast/Standard/Long)			
Control output	NPN / PNP Open collector			
Load current	100 mA or less Residual voltage: 1.8 V or less			
Indicator light	Laser emission indicator light: Green, Output Indicator light: Orange (1,2CH) Teaching indicator light: Red Channel indicator light: Green (1,2CH)			
Digital display	7 segment 8 digit display			
Timer function	OFF, On delay, Off delay, One-shot			
Timer time	1 ms - 9 s			
Mutual interference prevention function	Yes: Up to 4 machines			
Output method	Light on / Dark on Switching type in the function			
Analog output	Current output: 4 - 20 mA			
External input setting	External input setting (teaching, synchronizing input, floodlight off, counter reset)		External input setting (teaching, synchronizing input, floodlight off, counter reset)	
Setting input/output	Output setting (2CH output + Alarm output) * Settable only with D2SA-M□-M8			
Operating temperature/humidity	-25 to +55°C / 35 to 85% RH (No freezing)			
Shock resistance	10 to 55 Hz Double amplitude 1.5 mm 2 hours for each direction of X, Y, and Z			
Protective category	IP50			
Material	PC: Case and cover			
Weight (including the codes)	Cable type: 65 g M8 connector type: 30 g			

\*1 Operating temperature may differ according to the number of connection. See as follows:  
1 - 3 machines(s): -25 to +55°C  
4 - 8 machines: -25 to +50°C  
\* When not using analog output.

\* Base units and handsets of the advanced or standard models can be connected with any combination. However, some combination may be restricted. For details, contact our Customer Service.

### Each Part

No.	Name	Function
①	Laser emission indicator light	Turns on while the amplifier is powered.
②	1CH output indicator light	Turns on when the output of 1 CH is ON.
③	2CH output indicator light	Turns on when the output of 2 CH is ON.
④	Main monitor (Red)	Displays light intensity, function, and the number of counts.
⑤	Sub monitor (Green)	Displays the threshold, function selection, and the number of counts.
⑥	Teaching mode indicator light	Turns on in the Teaching mode.
⑦	Valid channel indicator light (1 CH)	Keeps turning ON when the monitor display value, adjustment, and the function setting are valid to 1 CH.
⑧	Valid channel indicator light (2 CH)	Keeps turning ON when the monitor display value, adjustment, and the function setting are valid to 2 CH.
⑨	UP button	RUN mode: Displays or changes the threshold. Function mode: Selects the function or changes the numerical values.
⑩	DOWN button	RUN mode: Switches the Function mode. (0.5 ± 0.2) Function mode: Fix the selection.
⑪	Mode button	RUN mode: Switches the channel. Function mode: Returns to RUN mode or performs scaling. Set mode: Run the teaching.
⑫	Teaching button	RUN mode: Switches the channel. Function mode: Returns to RUN mode or performs scaling. Set mode: Run the teaching.
⑬	SET/RUN selection switch	Switches between Teaching mode and RUN mode.

\* The button function varies in each mode: RUN mode, Function mode, and SET mode.  
\* As D2SA-M□3/D2SA-S□1/D2SA-M□-M8/D2SA-S□-M8 are 1 output (1CH) type, ④ and ⑤ do not turn on. The channel switching of ④ also becomes invalid.

### Adjustment

The available teaching depends on "5.3 Detection Mode setting." Refer to below:

Setting	Teaching
Standard detection	All teachings are valid.
Edge detection	No teaching is valid.
Differential detection	Only one point teaching is valid.

### Setting Maximum Sensitivity

Switch to SET.

Select the one-point teaching.

Press the teaching button.

Reflection type: Perform adjustment when there is no object.

Switch to RUN.

The threshold flashes and the display returns to normal.

Switch to SET.

Select the one point teaching.

Press the teaching button.

Reflection type: Perform adjustment with the background without object.

Switch to RUN.

The threshold flashes and the display returns to normal.

### One Point Teaching

Switch to SET.

Select the one point teaching.

Press the teaching button.

Reflection type: Perform adjustment with the background without object.

Switch to RUN.

The threshold flashes and the display returns to normal.

Switch to SET.

Select the zone teaching.

Press the teaching button.

Reflection type: Perform adjustment with the background without object, and when there is an object.

Switch to RUN.

The threshold flashes and the display returns to normal.

### Two Points Teaching

Switch to SET.

Select the two points teaching.

1st point: Press the teaching button.

2nd point: Press the teaching button.

Switch to RUN.

The threshold flashes and the display returns to normal.

### Auto Teaching

Switch to SET.

Select the auto teaching.

Start: Press the teaching button.

End: Press the teaching button.

Auto good

Switch to RUN.

The threshold flashes and the display returns to normal.

### Zone Teaching

Switch to SET.

Select the zone teaching.

Press the teaching button.

Switch to RUN.

The threshold flashes and the display returns to normal.

### Teaching Transparent Object

Switch to SET.

Press the teaching button.

Switch to RUN.

The threshold flashes and the display returns to normal.

### Teaching Length Measurement

Switch to SET.

SET: Press the teaching button.

IN: Press the teaching button.

Switch to RUN.

The upper limit flashes and the display returns to normal.

### Manual Adjustment

Pressing the UP/DOWN button in the RUN mode flashes the threshold. It indicates that adjustment is possible. Adjust to any value using the UP/DOWN button.

When using the zone teaching, the threshold of upper/lower limit can be set individually.

Automatically returns to the normal display 5 seconds after completion of the setting (no operation).

### Error Display in Teaching

An error message is displayed in the event of error during adjustment. Refer to the table below for readjustment.

Error Code	Description
Err 1	Indicates shortage of light intensity or no difference of light intensity.
Err 2	Indicates a sampling error in teaching of a moving object.
Err 3	Indicates a calculation error.
not cPlt	Indicates that the teaching is interrupted.

### Safety Precautions

Carefully read and understand the safety precautions before operation. The important information is provided to protect your health and property. Do not apply any other installing or operating procedure other than that described in this manual.

### Meaning of Safety Symbols

**WARNING** Indicates a possible hazard that may result in death, serious injury, or serious property damage if the product is used without observing the stated instructions.

**CAUTION** Indicates a possible hazard that may result in personal injury or property damage if the product is used without observing the stated instructions.

### Mandatory Requirements

**WARNING**

- This product is not an explosion-proof construction. Do not use the product under flammable, explosive gas or liquid environment.
- Do not use the product in water.
- Do not disassemble, repair, or convert the product. Failure to do this may cause failure, fire, or electric shock.
- Operate within the rated range.


This product cannot be used as a safety device to protect human body.

### Operational Precautions


**CAUTION**

- Use the specified sensor head to connect this product. Any use other than specified will cause accident or product damage.
- It is dangerous to wire or attach/remove the connector with the power on. Make sure to turn off the power before operation.
- Make sure to use the product with the protective cover attached and closed.
- Installing in the following places may result in malfunction:
  - A dusty or steamy place
  - A place generating corrosive gas
  - A place directly receiving scattering water or oil.
  - A place suffered from heavy vibration or impact.
- The product is not designed for outdoor use.
- Do not use the sensor in transient state after power on (approx. 100 ms).
- Do not wire with the high voltage cable or the power line. Failure to do this will cause malfunction by induction or damage.
- The sensor performance or digital display values may depend on the individual units or the condition of detected product.

### Input/Output Schematic



### Pin layout



### Function Setting

Press the mode button.

- Operation setting**: Select an operation mode (L on, L off, L on when light comes in, L on when light is blocked).
- Response speed setting**: Select a response speed (Long, Standard, Fast).
- Timer setting**: Select a timer and the time (Off, Off delay, On delay, One shot).
- Sensitivity correction setting**: Correct to the optimal value when sensitivity is not enough.
- Detailed setting (Expert mode)**: Moves to the Detailed setting menu.
- Initialization setting (Initial reset)**: Initialize all settings.
- End of setting**: Returns to the normal display.

- Zero-reset setting**: Set the displayed value on the main monitor to "0".
- Display setting**: Select a display method of normal main monitor (Numeric, Bar, Percent, Normal count, Total count).
- Detection mode setting**: Select a detection method from the list below (Normal, Rising edge, Trailing edge, Differential, Length measurement).
- Counter setting**: Select counter function ON/OFF and a count value.
- Output setting**: Select an output method of 1CH and 2CH.
- External input setting**: Select an assignment of external input (Teaching, Laser off, Synchro, Counter value, Hold reset).
- Analog function setting**: Select either read out or turn off the analog output.
- Span setting**: Set the slant of output.
- Output clamp hold setting**: Select a measurement value state when measurement is impossible.
- Average counter setting**: Select a number of times of sampling.
- Hold setting**: Select a hold state (Normal, Peak, Bottom, Peak to Peak).
- End of Analog function setting**: Returns to the TOP of Analog function setting.

- All zero-reset setting**: Select by using [AL] and fix by [0].
- All one point teaching setting**: Select by using [ALT] and fix by [0].
- Length measurement standard value setting**: Select a width of flood line of sensor head.
- End of Detail Setting (Expert mode)**: Returns to the TOP of Detail Setting (Expert mode).
- Analog output setting**: Select by using [A] and fix by [0].
- Span setting**: Select by using [SPAN] and fix by [4].
- Output clamp hold setting**: Select by using [CLP] and fix by [0].
- Average counter setting**: Select by using [Ave] and fix by [1].
- Hold setting**: Select by using [Hold] and fix by [0].
- End of Analog function setting**: Returns to the TOP of Analog function setting.

### Switching Channel

Pressing the [T] button during the RUN mode allows switching. At the same time the channel indicator light switches.

### Returning to Normal Display with One Button

Pressing the [T] button for 2 seconds or more in setting each function enables to return to the normal display (RUN mode) without using Exit (Exit).

### Key Lock


Cancel all the operations. Useful to prevent accidental operation. Hold down the [L] buttons for 2 seconds or more simultaneously in the RUN mode. Operate in the same way to cancel as well.

### Reset "Peak/Bottom hold"

Peak/Bottom hold can be reset by operating with amplifier itself at the time of analog output.


### Setting Amplifier Unit

#### Attaching and Removing to/from DIN rail




#### Expansion of Amplifier Unit

Slide and hook up each amplifier units to DIN rail. And fix it with End units from the both sides.



### Connecting Sensor Head


Open the protective cover and plug the connector into the amplifier unit with the lock lever facing up. Make sure that it clicks. When removing, hold down the lock lever and pull out the connector.



### CAUTION

Do not attach any sensor head other than the specified one (DS Series). When removing the connector, do not pull on the cable. Failure to do so will break the cable or damage the product.

### Dimensional drawing



### Options

End Unit
BEF-BE01-W190 (2 pcs)

● The product specification may change without notice for improvement.  
● For any inquiry, please contact the manufacturer/vendor below.

**OPTEX FA CO., LTD.**  
Head office: Mitsui Seimei Kyoto Yamashina BLDG 6F, 46-1  
Takehanadounmae-cho, Yamashina-ku, Kyoto  
607-8085 Japan  
TEL: +81-(0)75-594-8123  
FAX: +81-(0)75-594-8124





Digital Amplifier Detachable Photoelectric Sensor  
**D2SA Series**  
 Laser Type Amplifier Unit D2SA-M□S  
 D2SA-M□3S  
 D2SA-M□S-M8

**Instruction Manual**

- Thank you for purchasing DSA Series. We hope you are fully satisfied with this product and enjoy its performance.
- Carefully read this instruction manual and keep it for future reference.

**Specification**

Model	Advanced Model (2CH)	Standard Model (1CH)
Cable type	D2SA-M(N/P)S	D2SA-M(N/P)3S
M8 connector type	-	D2SA-M(N/P)S-M8
Adaptable sensor head	DS Series	
Power source, voltage	12 - 24 V DC ± 10% including a ripple	
Consumption current	45 mA or less / 24 V	
Response time	60µs/500µs/2ms (Fast/Standard/Long)	
Control output	NPN / PNP Open collector Load current: 100 mA or less Residual voltage: 1.8 V or less	
Indicator light	Laser emission indicator light: Green, Output Indicator light: Orange (1,2CH) Teaching indicator light: Red Channel indicator light: Green (1,2CH)	
Digital display	7 segment 8 digit display	
Timer function	OFF, On delay, Off delay, One-shot	
Timer time	1 ms - 9 s	
Output method	Light on / Dark on Switching type in the function	
Analog output	Current output 4 - 20 mA	
Setting input/output	External input setting (teaching, synchronizing input, floodlight off, counter reset) Output setting (2CH output + Alarm output) * Settable only with DSA-M□S-M8	External input setting (teaching, synchronizing input, floodlight off, counter reset)
Operating temperature/humidity	-25 to +55°C / 35 to 85% RH (No freezing)	
Store temperature/humidity	-40 to +70°C / 35 to 85% RH (No condensation)	
Shock resistance	10 to 55 Hz Double amplitude 1.5 mm 2 hours for each direction of X, Y, and Z	
Protective category	IP50	
Material	PC: Case and cover	
Weight (including the cables)	Cable type: 65 g M8 connector type: 30 g	



**Safety Precautions**

Carefully read and understand the safety precautions before operation. The important information is provided to protect your health and property. Do not apply any other installing or operating procedure other than that described in this manual.

**Meaning of Safety Symbols**

**WARNING** Indicates a possible hazard that may result in death, serious injury, or serious property damage if the product is used without observing the stated instructions.

**CAUTION** Indicates a possible hazard that may result in personal injury or property damage if the product is used without observing the stated instructions.

**Mandatory Requirements**

- This product is not an explosion-proof construction. Do not use the product under flammable, explosive gas or liquid environment.
- Do not use the product in water.
- Do not disassemble, repair, or convert the product. Failure to do this may cause failure, fire, or electric shock.
- Operate within the rated range.



This product cannot be used as a safety device to protect human body.

**Operational Precautions**

**CAUTION**

- Use the specified sensor head to connect this product. Any use other than specified will cause accident or product damage.
- It is dangerous to wire or attach/remove the connector with the power on. Make sure to turn off the power before operation.
- Make sure to use the product with the protective cover attached and closed.
- Installing in the following places may result in malfunction:
  - A dusty or steamy place
  - A place generating corrosive gas
  - A place directly receiving scattering water or oil.
  - A place suffered from heavy vibration or impact.
- The product is not designed for outdoor use.
- Do not use the sensor in transient state after power on (approx. 100 ms).
- Do not wire with the high voltage cable or the power line. Failure to do this will cause malfunction by induction or damage.
- The sensor performance or digital display values may depend on the individual units or the condition of detected product.

**Input/Output Schematic**



**Adjustment**

The available teaching depends on "5.3 Detection Mode setting." Refer to below:

Standard detection	All teachings are valid.
Edge detection	No teaching is valid.
Differential detection	Only one point teaching is valid.

**Setting Maximum Sensitivity**

Transmission type Regressive Reflection type: Perform adjustment when there is an object.


Reflection type: Perform adjustment when there is no object.

**One Point Teaching**


Reflection type: Perform adjustment with the background without object.

Threshold: FaS +15%, Sind +5%, Long +5%. Set the threshold to +□% against the amount of received light. (Depends on the response speed setting.)

**Auto Teaching**



**Zone Teaching**



**Manual Adjustment**



**Error Display in Teaching**

An error message is displayed in the event of error during adjustment. Refer to the table below for readjustment.

Error Code	Description
Err 1	Indicates shortage of light intensity or no difference of light intensity.
Err 2	Indicates a sampling error in teaching of a moving object.
Err 3	Indicates a calculation error.
not cPlt	Indicates that the teaching is interrupted.


**Function Setting**

1. Operation setting: Select an operation mode (L on, L off, d on, d off).
2. Response speed setting: Select a response speed (Long, Standard, Fast).
3. Timer setting: Select a timer and time (OFF, Off delay, On delay, One shot).
4. Sensitivity correction setting: Tune on/off for sensitivity correction.
5. Detailed setting (Expert mode): Access detailed settings.
6. Initialization setting (Initial reset): Initialize all settings.
7. End of setting: Return to normal display.

- 5.1 Zero-reset setting: Turn off/on zero reset.
- 5.2 Display setting: Select display method (numeric, bar, percent, total count).
- 5.3 Detection mode setting: Select detection method (Standard, Edge, Differential).
- 5.4 Counter setting: Select counter function and direction.
- 5.5 Output setting: Select output method (1CH, 2CH, Alarm).
- 5.6 External input setting: Select assignment of external input (teaching, laser, synchro, counter, hold).
- 5.7 Analog function setting: Select analog output setting.

- 5.8 Switching Channel: Switch between channels.
- 5.9 Returning to Normal Display with One Button: Cancel settings.
- 5.10 Key Lock: Lock/unlock the device.
- 5.11 Length measurement standard value setting: Set standard value.
- 5.12 End of Detail Setting (Expert mode): Return to normal display.
- 5.13 Analog output setting: Select read out or turn off.
- 5.14 Span setting: Set span for analog output.
- 5.15 Output clamp hold setting: Set output clamp hold.
- 5.16 Average counter setting: Set number of sampling.
- 5.17 Hold setting: Select hold state (Normal, Peak, Bottom, Peak to Peak).

**Switching Channel**



**Returning to Normal Display with One Button**

Pressing the [T] button for 2 seconds or more in setting each function enables to return to the normal display (RUN mode) without using [Exit].


**Key Lock**




**Reset "Peak/ Bottom hold"**

Peak/Bottom hold can be reset by operating with amplifier itself at the time of analog output.

**Setting Amplifier Unit**




**Connecting Sensor Head**



**CAUTION**

Do not attach any sensor head other than the specified one (DS Series). When removing the connector, do not pull on the cable. Failure to do so will break the cable or damage the product.

**Dimensional drawing**



**Options**



**Precautions for Function Setting**

- Some function settings automatically delete the invalid settings or settings, of which concomitant use is not allowed, from the displayed items. This does not indicate any failure.
- Some functions are not incorporated or not settable to D2SA-M□3S/D2SA-M□S-M8.
- Hold down the operation button for approx. 0.3 seconds if not especially specified.
- Analog output and Analog setting is available when response time setting is "Long" or "Standard".
- The sub monitor starts flashing when each setting selection becomes available.
- The monitor in use of the counter function displays "U" when the up-counter is selected, and displays "d" when the down-counter is selected.
- For functions other than Operation setting and Timer setting, both settings of 1 CH and 2 CH are changed when the setting of each function is modified.

The product specification may change without notice for improvement. For any inquiry, please contact the manufacture/vendor below.

**OPTEX FA CO., LTD.**  
 Head office: Mitsui Seimei Kyoto Yamashina BLDG 6F, 46-1  
 Takehanadounomae-cho, Yamashina-ku, Kyoto  
 607-8085 Japan  
 TEL: +81-(0)75-594-8123  
 FAX: +81-(0)75-594-8124  
 Website: http://www.optex-fa.com