Panasonic INSTRUCTION MANUAL

Photoelectric Sensor
Adjustable Range Reflective **EQ-500 Series**

MJE-EQ500 No.0040-93V

Thank you very much for purchasing Panasonic products. Read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference.



 Never use this product as a sensing device for personnel protection.

nis manual in a convenient place for quick reference.

device for personnel protection. In case of using sensing devices for personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.


1 SPECIFICATIONS

Email us at nsales@ramcoi.com

| | Туре | Multi-voltage | | DC-voltage | | |
|--|------------------------------------|--|---|--|-----------------------------------|--|
| | | | Short sensing range | | Short sensing range | |
| | Model No. | EQ-501 | EQ-502 | EQ-511 | EQ-512 | |
| Item ` | With timer | EQ-501T | EQ-502T | EQ-511T | EQ-512T | |
| Adjustable rai | nge (Note 1) (Note 2) | 0.2 to 2.5m | 0.2 to 1.0m | 0.2 to 2.5m | 0.2 to 1.0m | |
| | range (Setting aximum) (Note 2) | 0.1 to 2.5m | 0.1 to 1.0m | 0.1 to 2.5m | 0.1 to 1.0m | |
| Hysteresi | is (Note 2) | 10% or less of operation distance | | | | |
| Supply vo | oltage | 24 to 240V AC ± 10% or 12 to 240V DC ± 10% Ripple P-P 10% or less | | 12 to 24V DC±10% Ripple P-P 10% or less | | |
| Power / Current consumption | | AC: 4VA or less (With timer: 5VA or less) DC: 3W or less (With timer: 4W or less) | | 45mA or less | | |
| Output | | Relay contact 1a Switching capacity: 250V AC 3A (resistive load) 30V DC 3A (resistive load) Electrical life: 100,000 or more operations (switching frequency 1,200 times/hour) Mechanical life: 50,000,000 or more operations (switching frequency 18,000 times/hour) | | NPN open-collector transistor • Maximum sink current: 100mA • Applied voltage: 30V DC or less (between output and 0V) • Residual voltage: 1V or less (at 100mA sink current) • 0.4V or less (at 116mA sink current) PNP open-collector transistor • Maximum source current: 100mA • Applied voltage: 30V DC or less (between output and +V) • Residual voltage: 1V or less (at 100mA source current) • 0.4V or less (at 100mA source current) | | |
| Outp | ut operation | | Switchable either Detecti | on-ON or Detection-OFF | , | |
| Short-circuit protection | | — Incorporated | | | orated | |
| Response | e time | 20ms or less (Depends on the timer setting period for EQ-50□T) | | 2ms or less (Depends on the timer setting period for EQ-51 □T) | | |
| Sensing r | mode | _ s | | Switch either BG | Switch either BGS or FGS function | |
| Timer function | | EQ-5□T: Selectable from ON-delay and OFF-delay (0.1 to 5 sec. variable) | | | | |
| Automatic interference prevention function | | Incorporated (Note 3) | | | | |
| Protection | | IP67 (IEC) | | | | |
| Ambient temperature | | -25 to +55°C (No dew condensation or icing allowed), Storage: -30 to +70°C | | | | |
| Ambient humidity | | 35 to 85% RH, Storage: 35 to 85% RH | | | | |
| Emitting element | | Infrared LED (modulated) | | | | |
| Receiving element | | 2-segment photodiode | | | | |
| Material | | Enclosure: ABS, Front cover: Polycarbonate, Display cover: Polycarbonate | | | | |
| Connection method | | Screw-on terminal connection | | | | |
| Cable | | Suitable for round cable φ9 to φ11mm | | | | |
| Cable length | | Extension up to total 100m is possible with 0.3mm ² , or more, cabtyre cable | | | yre cable | |
| Weight | | 100g a | 100g approx. 85g approx. | | pprox. | |
| vveignt | | | * | 1 | ' ' | |

- Notes: 1) The adjustable range stands for the maximum sensing range which can be set with the adjuster.
 - 2) The adjustable range, the sensing range and the hysteresis are specified for white non-glossy paper (200 × 200mm) as the object.

 3) When the sensors are mounted closely, use them in the interference prevented area, as shown below.



Note that the detection may be unstable depending on the mounting conditions or the sensing object. In the state where this product is mounted, be sure to check the operation with the actual sensing object to be used.

INFORMATION RELATING TO LOW VOLTAGE DIRECTIVE (Multi-voltage type only)

| ` | <i>J</i> 1 |
|-------------------------------------|---------------------|
| Item | Description |
| Refering standard | IEC 60947-5-2: 1998 |
| Utilaization category | AC-12/DC-12 |
| Impulse withstanding voltage | 2.5kV |
| Pollution degree | 3 |
| Frequency of operation cycle | 25Hz |
| Turn off time | 20ms |
| Excess gain | 12% |
| Rated conditional protective device | 100A |
| Short-circuit protective device | FUSE 5A FAST BLOW |

Note: Each condition for use that the standards require is under less than 2,000m above sea level.

3 CAUTIONS

- This product has been developed / produced for industrial use only.
- Make sure that the power supply is off while wiring and adjusting.
- Take care that wrong wiring will damage the sensor.
 Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.


- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Take care that the sensor is not directly exposed to fluorescent light from a rapid-starter lamp, a high frequency lighting device
- or sunlight etc. as it may affect the sensing performance.

 If an external surge voltage exceeding 4kV (DC-voltage: 1kV) is impressed, the internal circuit will be damaged, and a surge suppressing element should be used.
- Do not use during the initial transient time (50ms) after the power supply is switched on.
- This sensor is suitable for indoor use only.
- A mechanical structure is employed for the distance adjuster of this product. Take care not to drop the product.
- adjuster of this product. Take care not to drop the product.


 Do not use this sensor in places having excessive
- vapor, dust, etc., or where it may come in direct contact with water, or corrosive gas.
 Take care that the sensor does not come in contact
- with water, oil, grease, organic solvents, such as, thinner, etc., strong acid or alkaline.
- This sensor cannot be used in an environment containing inflammable or explosive gases.
 Never disassemble or modify the sensor.
- Due to the configuration of the circuit, a slight noise may be generated in this product, however, this is not a problem.

4 MOUNTING


■ The tightening torque should be 0.8N·m or less.



 Care must be taken regarding the sensor mounting direction with respect to the object's direction of movement.



- When detecting a specular object (aluminum or copper foil, etc.) or an object having a glossy surface or coating, please take care that there are cases when the object may not be detected due to a small change in angle, wrinkles on the object surface, etc.
- When a specular body is present below the sensor, use the sensor by tiling it slightly upwards to avoid wrong operation.



- If a specular body is present in the background, wrong operation may be caused due to a small change in the angle of the background body. In that case, install the sensor at an inclination and confirm the operation with the actual sensing object.
- This product is not easily affected by the reflected light intensity since this sensor is the adjustable range reflective type. When the reflected light intensity is remarkably low, the sensing range may be affected. In that case, mount the sensor, while checking light-up of the stable indicator (green).
- sensor, while checking light-up of the stable indicator (green).

 Mounting screws of the terminal cover and display cover should certainly be tightened to maintain the water tight rating, however, the tightening torque of the screws should be of 0.3 to 0.5N m.

5 WIRING CONNECTIONS

 Check all wiring before applying power since incorrect wiring may damage the internal circuit.
 Also, carefully tighten the terminal screws so that the


Also, carefully tighten the terminal screws so that the wires of adjacent terminals do not touch.

The mounting hole for screw the terminal cover fixing inclines 70 degrees to the terminal cover, as shown in the figure below.

To avoid damaging this product or a screw, take care when tightening or loosening a screw.

To maintain a watertight performance, the cable should have an outer diameter between φ9 to φ11mm with a smooth covering material that allows the accessory conduit connector to be securely tightened, however, the tightening torque of the screw should be of 1.5 to 2.0N·m.

Composition of a conduit connector, and processing of a cable



Note: When assembling the conduit connector, take care of the direction of the gland packing.


Furthermore, in order to maintain a watertight performance, fit the gland packing such that the seating surface of the gland packing contacts the packing holder part of the terminal cover evenly.

- If pressure terminals are to be used, affix the connected pressure terminals to a terminal (M3.5 screw).
- Dimensions of the suitable crimp terminals


(Unit: mm) Round type Y-shaped type -22 or less -22 or less ϕ 3.6 or more ϕ 3.6 or less or less or less or less or less (After crimping) (After crimping)

The tightening torque of the terminal screws should be

6 I/O CIRCUIT DIAGRAMS



DC-voltage type




Symbols...D: Reverse supply polarity protection diode Z_{D1}, Z_{D2}: Surge absorption zener diode Tr1: NPN output transistor Tr2: PNP output transistor

Terminal position



7 PART DESCRIPTION



Notes: 1) The operation mode switch of the DC-voltage type is the DIP switch. Refer to 'B OPERATION MODE SWITCH' for

Incorporated on EQ-5□T only.


8 OPERATION MODE SWITCH

Multi-voltage type (L-ON / D-ON mode only)

| Operation mode switch | Description | | |
|-----------------------|--|--|--|
| | Detection-ON mode is obtained when the switch is turned fully clockwise. | | |
| | Detection-OFF mode is obtained when the switch is turned fully counterclockwise. | | |

Note: Turn the operation mode switch gradually and lightly with the attached screwdriver. If the distance adjuster is over turned or pressed heavily, it may be damaged.

DC-voltage type



9 BGS / FGS FUNCTION (DC-voltage type only)

- This sensor incorporates BGS / FGS function. Select either BGS or FGS function depending on the positions of the background and sensing object. BGS / FGS function is set with the operation mode switch.
- Depends on a selection of either BGS or FGS function, the output operation changes as follows.

| | | ← Sensing range → | |
|-------|-----------|-------------------|--|
| Non-d | etectable | Adjusted distance | |
| BGS | L-ON | ON OFF | |
| BG3 | D-ON | ON OFF | |
| FGS | L-ON | ON OFF | |
| FGS | D-ON | ON OFF | |

<BGS function>

 This function is used when the sensing object is apart from the background.



<FGS function>

This function is used when the sensing object contacts the background or the sensing object is glossy, etc.



10 DISTANCE ADJUSTMENT

For DC-voltage type, be sure to set the BGS / FGS function before distance adjustment. If the setting is done after the distance adjustment, the sensing area is changed.

- Turn the distance adjuster gradually and lightly with the attached screwdriver. If the distance adjuster is over turned or pressed heavily, it may be damaged.
- Multi-voltage type. DC-voltage type · BGS select

<When a sensing object moves horizontally to the sensor>

| Step | Description | Distance adjuster |
|------|---|----------------------|
| 1 | Turn the distance adjuster fully counterclockwise to the minimum sensing range position. (0.2m approx.) | Turn fully |
| 2 | Please an object at the required distance from the sensor, turn the distance adjuster gradually clockwise, and find out point (a) where the sensor changes to the light received condition. | |
| 3 | Remove the object, turn the distance adjuster further clockwise, and find out point @when the sensor changes to the light received condition again with only the background. When the sensor does not go to the light received condition even if the adjuster is fully turned clockwise, point @is this extreme point. | |
| 4 | The optimum position to stably detect objects is the center point between (a) and (a). | Optimum position |

When a sensing object is approaching / moving \ away from the sensor.

Follow only steps ① and ②. Since the sensing point
may change depending on the sensing object, be sure
to check the operation with the actual sensing object.


■ DC-voltage type · FGS select

| Step | Description | adjuster |
|------|---|----------------------|
| 1 | Turn the distance adjuster fully clockwise to the maximum sensing range position. (2.5m approx., 1.0m approx. for EQ-512□) | Turn fully |
| 2 | In the state where the sensor detects the background, turn the distance adjuster gradually counterclockwise, and find out point (a) where the sensor changes to the undetecting condition. | |
| 3 | Place an object at the required distance from the sensor, turn the adjuster counterclockwise further until the sensor goes into the undetecting condition again. Once it has entered, turn the adjuster backward a little until the sensor returns to the detecting condition. That position is designated as point (a). When the sensor does not go into the undetecting condition even if the adjuster is fully turned counterclockwise, the position where the adjuster was fully turned is regarded as the point (a). | |
| 4 | The optimum position to stably detect objects is the center point between (a) and (b). | Optimum position (B) |

11 STABILITY INDICATOR

Since the EQ-500 series use a 2-segment photodiode as its receiving element, and sensing is done based on the difference in the incident beam angle of the reflected beam from the sensing object, the output and the operation indicator (orange) operate according to the object distance.

Further, the stability indicator (green) shows the margin to the setting distance.



12 TIMER FUNCTION (EQ-5 □ T only)

- An OFF-delay timer, which is useful when the response of the connected device is slow, etc., an ON-delay timer, which is useful when the input specifications of the connected device require a
- signal of a fixed width, are possible with **EQ-5**□**T**.

 The OFF-delay timer and the ON-delay timer can be used at the same time.
- For DC-voltage type, set the DIP switch for the timer selecting to 'Timer ON' side.

| Sensing condition Operation | Beam-re ceived Beam-inter rupted |
|------------------------------------|----------------------------------|
| Light-received normal operation | OFF |
| Light-received ON-delay | OFF |
| Light-received OFF-delay | ON OFF |
| Light-received ON/OFF-delay | OFF |
| Light-interrupted normal operation | ON OFF |
| Light-interrupted ON-delay | OFF OFF |
| Light-interrupted OFF-delay | ON |
| Light-interrupted ON/OFF-delay | ON OFF |
| | |

Timer period: T = 0.1 to 5s (variable)

Note: Turn the timer switch gradually and lightly with the attached screwdriver. If the distance adjuster is over turned or pressed heavily, it may be damaged.

13 INTENDED PRODUCTS FOR **CE MARKING**

The models listed under "1 SPECI-FICATIONS" come with CE Marking. As for all other models, please contact our office

Contact for CE

Panasonic Marketing Europe GmbH Panasonic

Winsbergring 15, 22525 Hamburg, Germany

Panasonic Industrial Devices SUNX Co., Ltd.

http://panasonic.net/id/pidsx/global

Overseas Sales Division (Head Office) 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan Phone: +81-568-33-7861 FAX: +81-568-33-8591

About our sale network, please visit our website

© Panasonic Industrial Devices SUNX Co., Ltd. 2013 PRINTED IN JAPAN