

Thru-Beam Type Digital Displacement Sensor

**HG-T series**

# **User's Manual**

---

(MEMO)

## Introduction

Thank you for purchasing an **HG-T** series thru-beam digital displacement sensor.  
Before using this product, read and understand this User's Manual. Use the product correctly and in the optimum manner.  
Keep this manual in a safe location for reference whenever necessary.

## Types of Manuals

The following user's manuals are available for the **HG-T** series. Refer to the appropriate manual according to your need.

The user's manuals are also available for download from our website (<https://panasonic.net/id/pidsx/global>).

Unit name or purpose of use	Manual name	Manual Code
<b>HG-T</b> Control Unit	<b>HG-T</b> User's Manual	WUME-HGT
USB Communication Tool Software <b>HG-T Configuration Tool</b>	<b>HG-T Configuration Tool</b> User's Manual	WUME-HGTCT

### Please note

- 1) No part of this manual may be reproduced or reprinted in any form or by any means without prior written permission from Panasonic.
- 2) The contents of this manual are subject to change without notice for future improvement.
- 3) This manual has undergone strict quality control; but should you discover any dubious information, mistakes, misplaced pages, or missing pages, please contact your local dealer.

## Manual Configuration

<b>Chapter 1 Before Using This Product</b>	This chapter explains safety and handling precautions, laser safety standards, and other information that should be checked before using this product.
<b>Chapter 2 System Configuration</b>	This chapter explains the system configuration.
<b>Chapter 3 Overview of HG-T Series</b>	This chapter explains the principle of measurement and how to use this product when controllers are connected.
<b>Chapter 4 Installation and Connections</b>	This chapter explains installation, connections, wiring, and other work.
<b>Chapter 5 Basic Usage</b>	This chapter explains the flow of operations up to measurement startup, the base screen displayed when the power is turned ON, and basic operations.
<b>Chapter 6 Setting up General Functions</b>	This chapter explains details and settings for general functions.
<b>Chapter 7 Setting up Extended Functions</b>	This chapter explains details and settings for extended functions.
<b>Chapter 8 Specifications and Dimensions</b>	This chapter explains the specifications and dimensions.
<b>Chapter 9 Maintenance</b>	This chapter explains maintenance and inspection.
<b>Chapter 10 Troubleshooting</b>	This chapter explains troubleshooting and error codes.
<b>Chapter 11 Appendix</b>	This chapter provides menu structure.



# Contents

Introduction .....	3
Types of Manuals .....	3
Manual Configuration .....	4
 Chapter 1 Before Using This Product .....	1-1
1.1 Safety Precautions .....	1-2
1.2 Handling Precautions .....	1-3
1.3 Laser Safety Standards .....	1-5
1.3.1 IEC / JIS / GB .....	1-5
1.3.2 FDA .....	1-6
1.4 Terminology .....	1-8
1.5 Contents of Package .....	1-9
 Chapter 2 System Configuration .....	2-1
2.1 System Configuration .....	2-2
2.2. Description of Parts .....	2-3
2.2.1 Controller .....	2-3
2.2.2 Sensor Head .....	2-5
2.2.3 Sensor Head Connection Cable .....	2-6
2.2.4 Side View Attachment .....	2-6
 Chapter 3 Overview of <b>HG-T</b> Series .....	3-1
3.1 Principle of Measurement .....	3-2
3.2 Role of Controllers .....	3-3
3.3 Using Connected Controllers .....	3-4
 Chapter 4 Installation and Connections .....	4-1
4.1 Mounting the Controller .....	4-2
4.1.1 Mounting on a DIN Rail .....	4-2
4.1.2 Removing from a DIN Rail .....	4-2
4.1.3 Controller Wiring Connection Diagrams .....	4-3
4.2 Attaching the Sensor Head .....	4-4
4.3 Connecting the Sensor Head Connection Cable .....	4-5
4.3.1 Connecting to the Sensor Head .....	4-5
4.3.2 Disconnecting from the Sensor Head .....	4-6
4.3.3 Connecting to the Controller .....	4-7
4.3.4 Disconnecting from the Controller .....	4-7
4.3.5 Connecting and Disconnecting to / from Controller Connector .....	4-8
4.4 Connecting Controllers .....	4-11
4.4.1 How to connect .....	4-12
4.4.2 How to remove .....	4-14
4.5 Mounting the Side View Attachment .....	4-15

Chapter 5 Basic Usage .....	5-1
5.1 Using the Base Screen .....	5-2
5.1.1 Functions of Operation Keys and Display Unit .....	5-2
5.2 Flow of Operations up to Measurement Startup .....	5-5
5.3 Explanation of Basic Operation .....	5-7
5.3.1 Checking the Beam Axis .....	5-7
5.3.2 Adjusting the Beam Axis .....	5-9
5.3.3 Reference Waveform Registration .....	5-14
5.3.4 Teaching .....	5-15
5.4 Operation Mode .....	5-22
5.4.1 Auto Edge Detection Mode .....	5-22
5.4.2 Edge Detection Mode .....	5-24
5.4.3 External Form/Width Detection Mode .....	5-25
5.4.4 Inside Diameter/Gap Detection Mode .....	5-25
5.4.5 Central Position Detection Mode .....	5-26
5.5 Settings on the Base Screen (Using Shortcut Keys) .....	5-27
5.5.1 Display Switching Mode .....	5-27
5.5.2 Preset .....	5-32
5.5.3 Bank Mode .....	5-34
5.5.4 Key Lock .....	5-38
5.5.5 Sensitivity Settings .....	5-40
Chapter 6 Setting up General Functions .....	6-1
6.1 Flow of Measurement Data .....	6-2
6.2 Setting Operation List .....	6-3
6.3 Detection Settings ( <i>DETECT</i> ) .....	6-9
6.3.1 Operation Mode ( <i>OPMODE</i> ) .....	6-9
6.3.2 Measurement Direction ( <i>DIRECT</i> ) .....	6-10
6.3.3 Average Count (Response Time) ( <i>SPEED</i> ) .....	6-11
6.4 Basic Settings ( <i>BASIC</i> ) .....	6-14
6.4.1 HIGH Set Value ( <i>HISET</i> ) .....	6-14
6.4.2 LOW Set Value ( <i>LOSET</i> ) .....	6-16
6.4.3 Hysteresis ( <i>HYSTER</i> ) .....	6-18
6.4.4 Teaching Types ( <i>TEACH</i> ) .....	6-20
6.4.5 Tolerance $\leq \pm$ ( <i>TOL</i> ( $\pm$ ) ) .....	6-22
6.4.6 Preset Value ( <i>PRVAL</i> ) .....	6-23
6.4.7 Preset Data Selection ( <i>PROBJ</i> ) .....	6-24
6.4.8 Preset Save ( <i>PRSAVE</i> ) .....	6-25
6.4.9 Reference Waveform Save ( <i>RWSAVE</i> ) .....	6-26
6.4.10 Output Operation ( <i>OUTPUT</i> ) .....	6-27
6.4.11 Analog Output Selection ( <i>A/OSSEL</i> ) .....	6-28
6.4.12 Menu Display Settings ( <i>MENU</i> ) .....	6-29
6.5 Initialization ( <i>RESET</i> ) .....	6-30
6.6 Maintenance ( <i>MAINTN</i> ) .....	6-31

Chapter 7 Setting up Extended Functions .....	7-1
7.1 Setting Operation List .....	7-2
7.2 Advanced Settings ( <i>ADVANCE</i> ) .....	7-9
7.2.1 Hold Settings ( <i>HOLD</i> ) .....	7-9
7.2.2 Simultaneous Input ( <i>ALL IN</i> )(For Master Units Only) .....	7-17
7.2.3 External Inputs ( <i>EXTIN</i> ) .....	7-18
7.2.4 External Outputs ( <i>EXTOUT</i> ) .....	7-21
7.2.5 External Output Delay Timer Selection ( <i>OUT.DLY</i> ) .....	7-27
7.2.6 Number of Digits Displayed ( <i>DIGIT</i> ) .....	7-31
7.2.7 Analog Scaling ( <i>ANALOG</i> ) .....	7-32
7.2.8 Eco Mode ( <i>EEO</i> ) .....	7-37
7.2.9 Alarm Settings ( <i>ALARM</i> ) .....	7-38
7.2.10 Key Lock Function Selection ( <i>KEYLOCK</i> ) .....	7-44
7.2.11 Interference Prevention Function ( <i>INTFPR</i> )(For Master Units Only) ..	7-45
7.2.12 Sampling Cycle ( <i>SAMPLI</i> ) .....	7-47
7.3 Calculation Settings ( <i>CALL</i> )(For Master Units Only) .....	7-48
7.3.1 Calculation Mode ( <i>MODE</i> ) .....	7-48
7.3.2 Calculation Application Selection ( <i>APPLI</i> ) .....	7-49
7.4 Copy Settings ( <i>COPY</i> ) .....	7-53
7.4.1 Copy Individual Selection ( <i>COPYSEL</i> )(For Master Units Only) .....	7-54
7.4.2 Copy Batch Selection ( <i>CHKALL</i> )(For Master Units Only) .....	7-56
7.4.3 Copy Execution ( <i>COPYEXE</i> )(For Master Units Only) .....	7-57
7.4.4 Copy Lock ( <i>LOCK</i> )(For Slave Units Only) .....	7-58
7.5 Bank Settings ( <i>BANK</i> ) .....	7-59
7.5.1 Bank Save Selection( <i>BANKDAT</i> ) .....	7-59
7.6 Calibration Settings ( <i>CALIB</i> ) .....	7-61
7.6.1 Calibration Selection ( <i>CALSEL</i> ) .....	7-61
Chapter 8 Specifications and Dimensions .....	8-1
8.1. Specifications .....	8-2
8.1.1 Controller .....	8-2
8.1.2 Sensor Head .....	8-8
8.2. Dimension Drawings .....	8-9
8.2.1 Controller .....	8-9
8.2.2 Sensor Head .....	8-11
8.2.3 Side View Attachment .....	8-12
Chapter 9 Maintenance .....	9-1
9.1 Maintenance and Inspection .....	9-2
9.1.1 Maintenance Precautions .....	9-2
9.1.2 Main Inspection Items .....	9-2
Chapter 10 Troubleshooting .....	10-1
10.1 Troubleshooting .....	10-2
10.2 Error Messages .....	10-4
Chapter 11 Appendix .....	11-1
11.1 Menu Structure(General Function Display) .....	11-2
11.2 Menu Structure(Extended Function Display) .....	11-4

(MEMO)

# Chapter 1

## Before Using This Product

---



1.1 Safety Precautions .....	1-2
1.2 Handling Precautions .....	1-3
1.3 Laser Safety Standards .....	1-5
1.3.1 IEC / JIS / GB .....	1-5
1.3.2 FDA .....	1-6
1.4 Terminology .....	1-8
1.5 Contents of Package .....	1-9


# Before Using This Product

## 1.1 Safety Precautions Always observe


This section explains important rules that must be observed to prevent human injury and property damage.

- The hazards that may occur if the product is used incorrectly are described and classified by level of harm.

 <b>WARNING</b>	Risk of death or serious injury.
 <b>CAUTION</b>	Risk of minor injury or property damage.

 **WARNING**




- Never use this product as a sensing device for personnel protection.
- For sensing devices for personal protection, use products that conform to the laws and standards related to personal protection in each country, such as OSHA, ANSI, and IEC.
- This product is designed to inspect (judge or measure) objects and so must not be used to ensure safety, for example, to prevent accidents that affect human lives or property.
- Do not look at or touch direct laser beams or other reflections of light, as doing so is dangerous.

 **CAUTION**

- For the controller DC power supply, only use a power supply that is isolated by means of an isolation transformer or otherwise.
- There is a risk of short-circuiting and damage to the controller or power supply if a transformer such as an autotransformer is used. There is a risk of short-circuiting and damage to the controller or power supply if the controller is incorrectly mounted or connected.
- The **HG-TC** series controller is designed to be used with the **HG-T** series special-purpose sensor head to satisfy the specifications. If the controller is used with any sensor head other than the special-purpose sensor head, the specifications will not be satisfied and malfunctioning or another problem may occur.

### 1.2 Handling Precautions

- In this manual, the following symbols are used to indicate safety information that must be observed.

	Indicates an action that is prohibited.
	Indicates an action that must be taken.
	Indicates a matter that requires caution.
<Reference>	Indicates supplemental information.

#### ■ Handling precautions

##### Specifications

- This device has been developed / produced for industrial use only.
- This product (controller and sensor head receiver) uses an EEPROM. The EEPROM has a service life of one million setting operations.
- Do not use this product outside the range of the specifications. Risk of an accident and product damage.  
There is also a risk of a noticeable reduction of service life.

##### Power supply

- Verify that the supply voltage fluctuations are within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- Do not use during the initial transient time after the power supply is switched ON.
- To ensure performance, use the product at least 30 minutes (warm-up time) after the power is turned ON.

##### Wiring

- Make sure that the power is OFF before performing wiring or connection work for the controller.
- Note that there is a risk of damage or burning if the load is short-circuited or incorrectly wired.
- After you have completed wiring work, check the wiring carefully before switching on the power.
- Do not wire in parallel with a high-voltage line or power line, or run through the same conduit. Doing so may result in malfunctioning due to induction.
- Do not apply stress such as excessive bending or pulling to the extracted part of a cable,
- When connecting the sensor head connection cable to this product, do not apply force to the product.

## Before Using This Product

---

### Usage environment

- This product is suitable for indoor use only.
- The light emitting and receiving surfaces of the sensor head must be free of water, oil, fingerprints, and other substances that refract light as well as dust, grit, and other objects that intercept light.  
If stains or dirt become attached to the sensor head surfaces, wipe them with a lint-free soft cloth or lens cleaning paper. If the surfaces are very dirty, wipe off dirt using a cotton swab (or similar material) moistened with absolute alcohol.
- Do not allow ambient light such as sunlight to directly hit the light receiving section of the sensor head. In particular, if precision is required, use this product by mounting a douser (or similar material) on the sensor head.
- When a measured object with a strong specular reflection component (such as glass or specular reflector) is detected, it may not be detected correctly due to the influences of light reflected from the measured object. In such a case, install a pair of emitter and receiver at a certain angle so that reflected light does not hit the emitter or receiver. After adjusting the angle, always check the beam axis. After checking the beam axis, if the beam axis is aligned, register the reference waveform. If the beam axis is misaligned, readjust the beam axis, and register the reference waveform.
- Avoid using this product in environments where condensation occurs due to sudden temperature change.
- Avoid dust, dirt, and steam.
- Avoid using the product in atmospheres that contain corrosive or other harmful gases.
- Ensure that the product does not come into contact with organic solvents such as thinner.
- Ensure that the product does not come into contact with strong acid or alkaline.
- Ensure that the product does not come into contact with oil or grease.
- This product cannot be used in atmospheres that contain flammable or explosive gases.
- Performance may not be satisfactory in a strong electromagnetic field.
- Do not use this product in locations subject to severe vibration or shock.
- This product is a precision device. Do not drop or otherwise subject to shock. Risk of product damage.
- Take care not to touch any terminals in the connector or allow foreign objects to enter the connector.
- The sensor head is watertight, but the connector is not dustproof, waterproofing, or corrosion-resistant due to its structural reasons, so measurements cannot be taken under the water or in the rain. Pay attention to the environment where the product is used.

### Other matters

- Never attempt to disassemble, repair, or modify the product.
- When the product becomes unusable or unneeded, dispose of the product appropriately as industrial waste.



## 1.3 Laser Safety Standards

### 1.3.1 IEC / JIS / GB

To prevent laser products from affecting their users, IEC, JIS, and GB have the following respective standards:

IEC: IEC 60825-1-2014

JIS: JIS C 6802-2014

GB: GB 7247.1-2012

These standards classify laser products into classes according to the danger level of laser, and prescribe safety and preventive measures that should be implemented for each class.

This product belongs to “Class 1 laser product” according to JIS C 6802-2014 “Safety of Laser Products”.

- Explanation of danger level

Classification	Overview of danger evaluation
Class 1	This class of laser beams is safe when the operating state of the product is rightly predictable.
Class 1M	This class of laser beams is safe when the operating state of the product is rightly predictable, but direct intrabeam viewing by optical means can be dangerous.
Class 2	This class of laser beams is visible light and low output. Normally, eyes are protected by aversion reaction such as blinking.
Class 2M	This class of laser beams is visible light and low output. Normally, eyes are protected by aversion reaction such as blinking, but direct intrabeam viewing by optical means can be dangerous.
Class 3R	Direct intrabeam viewing is potentially dangerous, but the level of risk is lower than Class 3B laser.
Class 3B	Direct intrabeam viewing is always dangerous.
Class 4	This class of laser beams is high output. It has the ability to cause dangerous diffuse reflection. Such laser beams cause skin disorders and have the risk of fire occurrence.

- Warning label

On the emitter side

<Label position>

#### ◆ HG-T1010



#### ◆ HG-T1110



## Before Using This Product

### 1.3.2 FDA

- Exporting to the USA

If this product is incorporated into facilities or equipment to be exported to the USA, it is subject to the laser regulations of the U.S. Food and Drug Administration (FDA). To prevent laser products from affecting their users, PART1040 (Performance Standards for Light-Emitting Products) was established as one of the FDA regulations. These standards classify laser products into classes according to the danger level of laser and prescribe safety and preventive measures that should be implemented for each class.

This product complies with the FDA regulations (21 CFR 1040.10 and 1040.11) in accordance with FDA Laser Notice No. 50. (Class 1 laser product)

- FDA regulations

Requirements	Class (*1)					
	I	IIa	II	IIIa	IIIb	IV
<b>Performance (for all laser products)</b>						
Protective housings [1040.10(f)(1)]	R <sup>*2</sup>	R <sup>*2</sup>	R <sup>*2</sup>	R <sup>*2</sup>	R <sup>*2</sup>	R <sup>*2</sup>
Safety interlock [1040.10(f)(2)]	R <sup>*3, *4</sup>	R <sup>*3, *4</sup>	R <sup>*3, *4</sup>	R <sup>*3, *4</sup>	R <sup>*3, *4</sup>	R <sup>*3, *4</sup>
Location of controls [1040.10(f)(7)]	N/A	R	R	R	R	R
Viewing optics [1040.10(f)(8)]	R	R	R	R	R	R
Scanning safeguard [1040.10(f)(9)]	R	R	R	R	R	R
<b>Performance (for laser systems)</b>						
Remote interlock connector [1040.10(f)(3)]	N/A	N/A	N/A	N/A	R	R
Key control [1040.10(f)(4)]	N/A	N/A	N/A	N/A	R	R
Emission indicator [1040.10(f)(5)]	N/A	N/A	R	R	R <sup>*10</sup>	R <sup>*10</sup>
Beam attenuator [1040.10(f)(6)]	N/A	N/A	R	R	R	R
Manual reset [1040.10(f)(10)]	N/A	N/A	N/A	N/A	N/A	R <sup>*13</sup>
<b>Performance (for special-purpose products)</b>						
Medical use [1040.11(a)]	S	S	S	S <sup>*8</sup>	S <sup>*8</sup>	S <sup>*8</sup>
Surveying, leveling, and alignment [1040.11(b)]	S	S	S	S	NP	NP
Demonstration [1040.11(c)]	S	S	S	S	S <sup>*11</sup>	S <sup>*11</sup>
<b>Labeling (for all laser products)</b>						
Certification and identification [1010.2,3]	R	R	R	R	R	R
Protective housings [1040.10(g)(6), (7)]	D	R <sup>*5</sup>	R <sup>*5</sup>	R <sup>*5</sup>	R <sup>*5</sup>	R <sup>*5</sup>
Openings [1040.10(g)(4)]	N/A	N/A	N/A	N/A	N/A	N/A
Class warning [1040.10(g)(1), (2), (3)]	N/A	R <sup>*6</sup>	R <sup>*7</sup>	R <sup>*9</sup>	R <sup>*12</sup>	R <sup>*12</sup>
<b>Information (for all laser products)</b>						
User information [1040.10(h)(1)]	R	R	R	R	R	R
Product literature [1040.10(h)(2)(i)]	N/A	R	R	R	R	R
Service information [1040.10(h)(2)(ii)]	R	R	R	R	R	R

R: Required

N/A: Not applicable

S: Same requirements as for other products of the class

NP: Not permitted

D: Depends on the internal radiation level

## Before Using This Product

- \*1: Based on the maximum level of exposure to radiation during operation
- \*2: Required wherever and whenever if exposure to laser radiation exceeding the limit of Class 1 is not necessary to fulfill the functions of the product
- \*3: Required for protective housings that are opened during operation or maintenance if radiation exposure that occurs when the housing is opened is not always necessary
- \*4: Requirements for interlock differ according to the class of internal radiation.
- \*5: Wording differs according to the level and wavelength of laser radiation inside the protective housing.
- \*6: A label that indicates a warning statement
- \*7: CAUTION logo
- \*8: A means is required to measure the level of laser radiation for the purpose of human body irradiation.
- \*9: CAUTION is used when the radiation level is  $2.5 \text{ mWcm}^{-2}$  or lower, and DANGER is used when the radiation level is higher than  $2.5 \text{ mWcm}^{-2}$ .
- \*10: Time lag is required between reading and emission.
- \*11: Exception handling is required for laser products and light show for demonstration of Class IIIb or IV.
- \*12: DANGER logo
- \*13: Required since August 20, 1986


### ● Recognition / identification label

Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No50 on 6-24-07  
Panasonic Industrial Devices SUNX Co., Ltd.  
2431-1, Ushiyamacho, Kasugaishi, Aichiken 486-0901 Japan  
MANUFACTURED:

### <Label position>

#### Emitter

### ◆ Common to HG-T1010 and HG-T1110



## Before Using This Product

---







### 1.4 Terminology

Term	Description
Controller - Master unit	A controller that can be used on a standalone basis
Controller - Slave unit	A controller that is used by connecting to a master unit
Sensor head - Emitter	A sensor head emitter that is used by connecting to a controller
Sensor head - Receiver	A sensor head receiver that is used by connecting to a controller
Sensor head connection cable	A cable that is used to connect a sensor head and controller
Side view attachment	An attachment that is used to refract laser beams from the sensor head at 90 degrees
End plate	A plate that is used to secure both ends of controllers to prevent the connectors from coming off and causing a communication failure when controllers are connected
Communication unit	An interface unit that enables measurement data and other data of connected controllers to be monitored. (Note 1)

(Note 1): For details on communication units, refer to the user's manual for each communication unit.

## 1.5 Contents of Package

The following accessories are included in the product package. Before using the product, make sure that no items are missing.

Controller	Sensor head	
<p><b>HG-TC101</b> / Master unit of high-performance NPN output type  <b>HG-TC101-P</b> / Master unit of high-performance PNP output type</p> <ul style="list-style-type: none"> <li>Controller: 1 pc.</li> </ul>  <ul style="list-style-type: none"> <li>Instruction Manual (English / Japanese, Chinese / Korean): 1 PC each</li> <li>General Information for Safety, Compliance, and Instructions (23 languages): 1 PC</li> </ul>	<p><b>HG-T1010</b> / Measurement width 10 mm, standard type</p> <ul style="list-style-type: none"> <li>Sensor head (emitter and receiver): 1 set</li> </ul>  <ul style="list-style-type: none"> <li>Instruction Manual (English / Japanese, Chinese / Korean): 1 PC each</li> <li>General Information for Safety, Compliance, and Instructions (23 languages): 1 PC</li> </ul>	
<p><b>HG-TC111</b> / Slave unit of high-performance NPN output type  <b>HG-TC111-P</b> / Slave unit of high-performance PNP output type</p> <ul style="list-style-type: none"> <li>Controller: 1 pc.</li> </ul>  <ul style="list-style-type: none"> <li>Instruction Manual (English / Japanese, Chinese / Korean): 1 PC each</li> <li>General Information for Safety, Compliance, and Instructions (23 languages): 1 PC</li> </ul>	<p><b>HG-T1110</b> / Measurement width 10 mm, slim type</p> <ul style="list-style-type: none"> <li>Sensor head (emitter and receiver): 1 set</li> </ul>  <ul style="list-style-type: none"> <li>Instruction Manual (English / Japanese, Chinese / Korean): 1 PC each</li> <li>General Information for Safety, Compliance, and Instructions (23 languages): 1 PC</li> </ul>	
<p><b>HG-TC113</b> / Slave unit of wire-saving type</p> <ul style="list-style-type: none"> <li>Controller: 1 pc.</li> </ul>  <ul style="list-style-type: none"> <li>Instruction Manual (English / Japanese, Chinese / Korean): 1 PC each</li> <li>General Information for Safety, Compliance, and Instructions (23 languages): 1 PC</li> </ul>	<th>Side view attachment</th>	Side view attachment
	<p><b>HG-TSV10</b> / Side view attachment</p> <ul style="list-style-type: none"> <li>Attachment: 1 pc. (Note 1)</li> </ul>  <ul style="list-style-type: none"> <li>M2 screw with washer (length: 4mm): 2 pcs.</li> </ul> <p>(Note 1): <b>HG-TSV10</b> is sold by one unit. Two units are required for a pair of emitter and receiver.</p>	


## Before Using This Product

---

### Sensor head connection cable

**CN-HT-C2** / Cable length 2 m  
**CN-HT-C5** / Cable length 5m  
**CN-HT-C10** / Cable length 10m  
**CN-HT-C20** / Cable length 20m


- Connection cable: 1 pc.



### Communication unit

**SC-HG1-USB** / USB Communication Unit

- Communication unit: 1 pc.




- Instruction manual

### End plate

**MS-DIN-E** / End plate

- Plate: Set of 2 pcs.



- Instruction manual

# Chapter 2

## System Configuration

---

- 2.1 System Configuration.....2-2
- 2.2. Description of Parts .....2-3
  - 2.2.1 Controller..... 2-3
  - 2.2.2 Sensor Head ..... 2-5
  - 2.2.3 Sensor Head Connection Cable ..... 2-6
  - 2.2.4 Side View Attachment ..... 2-6

## System Configuration


### 2.1 System Configuration

The **HG-T** series consists of controllers, sensor head connection cables, and sensor heads. For the controllers, master units (two types) and slave units (three types) are available. Up to 15 slave units can be connected to one master unit. For the sensor heads, two types are available. For the sensor head connection cables, four types are available.

Connecting a communication unit to the end of the connection enables information to be checked from outside. (Note)



- Always shut OFF the power before connecting or disconnecting a slave unit or communication unit to / from the master unit. If you connect or disconnect a unit with the power ON, the controller may become damaged.
- Insert the male connector all the way into the female connector. If the connectors are not completely connected, the controller may become damaged.
- To connect units, always mount them on a DIN rail. To do so, mount end plates **MS-DIN-E** (optional) so as to enclose the connected units at both ends.
- When connecting slave units to the master unit, connect only NPN output type units or only PNP output type units. Dissimilar output types cannot be connected together.




(Note): When a communication unit is connected, up to 14 slave units can be connected.




## 2.2. Description of Parts

### 2.2.1 Controller


HG-TC101 / Master unit of high-performance NPN output type  
 HG-TC101-P / Master unit of high-performance PNP output type



HG-TC111 / Slave unit of high-performance NPN output type  
 HG-TC111-P / Slave unit of high-performance PNP output type




HG-TC113 / Slave unit of wire-saving type



	Name	Function
1	Female connector	For connection to a slave unit. Remove the connector cover before connecting to a slave unit.
2	Sensor head connection cable connector	Connects the sensor head connection cable.
3	Male connector (for slave unit only)	For connection to a master unit or slave unit.
4	Digital display unit / operation unit	For checking measured values and perform setting operation. For details, refer to the following page.
5	Digital display unit / operation unit cover	Protects the display unit and operation unit. Keep the cover closed when the display unit / operation unit is not used.

## System Configuration

- Display unit / operation unit




Name		Function	
1	Output 1 indicator (Orange)	Lights up when output 1 is ON.	
2	Output 2 indicator (Orange)	Lights up when output 2 is ON.	
3	Output 3 indicator (Orange)	Lights up when output 3 is ON.	
4	Circle meter (Orange, green)	• Shows increases or decreases of the judgment value by meter display. • Shows the level and item sequence of setting work by navigation display.	
5	Digital display section / SUB (Green)	Shows the setting item and the item set using display switching mode.	
6	Digital display section / MAIN (White)	Shows the measured value, judgment value, and setting.	
7	Guide mark / arrow keys (White)	Lights up when each key (LEFT / RIGHT / UP / DOWN) is enabled during each setting operation.	
8	Guide mark / Enter (White)	Lights up when the ENTER key is enabled during each setting operation.	
9	LEFT key	Used to change setting items and settings when configuring settings, and to move through set value digits.	
10	UP key		
11	RIGHT key		
12	DOWN key		
13	ENTER key	Used to select setting items and apply settings when configuring settings.	
14	EXIT key	Used to exit a setting item or cancel a setting when configuring settings.	
15	Status mark	TRIG (White)	Lights up while the trigger input (external input) is ON. Lights up during sampling when self-hold is set.
		HOLD (White)	Lights up while the judgment value is held.
		CALC (White)	Lights up when calculation mode is set with a slave unit connected.
16	Copy checkmark (Orange)	"COPY" lights up for a setting item that can be copied to a slave unit when a master unit is set up. In this case, if the setting item is selected as a copy target, the checkmark will light up and executing copy will perform copy processing.	
17	Input indicator (White)	Lights up when external input 1, 2, or 3 is ON.	
18	Preset indicator (Green)	Lights up when the preset function is used.	
19	Preset key	Used to set and cancel the preset function.	


## 2.2.2 Sensor Head

### • HG-T1010

<Emitter>




<Receiver>




### • HG-T1110

<Emitter>



<Receiver>




	Name	Function
1	Laser radiation indicator (Green)	Lights up when laser beams are emitted.
2	Light emitting surface	The surface that emits laser beams
3	Light receiving surface	The surface that receives laser beams
4	Beam axis adjustment indicator / TOP part (Orange / Green)(Note 1)	Indicates the beam axis adjustment state as light color (green or orange) and lighting state (lit, flashing, or unlit). (Only when the beam axis adjustment function is used)
5	Beam axis adjustment indicator / BOTTOM part (Orange / Green)(Note 1)	
6	Judgment output indicator (Orange / Green)	When controller judgment value is within the threshold range: Lights green When controller judgment value is outside the threshold range: Lights orange When the beam axis adjustment function is used: OFF
7	Sensor head connection cable connector	Connects the sensor head connection cable.
8	Female thread for mounting side view attachment	Connects the side view attachment and sensor head using an M2 screw with washer (length: 4mm).

(Note 1): The **HG-T1110** is not equipped with the beam axis adjustment indicators (TOP / BOTTOM part).

# System Configuration

## 2.2.3 Sensor Head Connection Cable


- CN-HT-C2 / Cable length 2m
- CN-HT-C5 / Cable length 5m
- CN-HT-C10 / Cable length 10m
- CN-HT-C20 / Cable length 20m



	Name	Function
1	Sensor head connector	Connects to the sensor head cable connector on the sensor head. There is no difference between the connectors on the emitter side and on the receiver side.
2	Controller connector	Connects to the sensor head cable connector on the controller.

## 2.2.4 Side View Attachment

HG-TSV10



	Name	Function
1	Sensor head mounting surface	Mounts the side view attachment on the light emitting and receiving surfaces of the sensor head.
2	Sensor head mounting hole	Connects the side view attachment and sensor head using an M2 screw with washer (length: 4mm).

# Chapter 3

## Overview of HG-T Series


---

- 3.1 Principle of Measurement .....3-2
- 3.2 Role of Controllers .....3-3
- 3.3 Using Connected Controllers .....3-4


## Overview of HG-T Series

### 3.1 Principle of Measurement

The sensor head emits belt-shaped laser beams from its emitter and receives them with the light receiving element (CMOS) of its receiver. If a measured object is inserted between the emitter and receiver of the sensor head, the bright section (light entry section) that receives laser beams and the dark section (light interception section) that is the shade of the measured object are projected on to the CMOS. The difference in the amount of received light between each pixel of the CMOS is used to detect position information about the border between the light entry section and the light interception section and measure the object.




- The edge position of the measured object can be measured.



## 3.2 Role of Controllers

Sensor head measured values are sent from the sensor head to the controller. Measured values can be held in the controller and calculations performed. Output judgment is based on judgment values. The controller is equipped with three outputs (OUT 1, OUT 2, and OUT 3) and with indicators that show the respective results of the three outputs.



## Overview of HG-T Series

### 3.3 Using Connected Controllers

The **HG-T** series enables measurement for various applications to be performed by connecting slave units to the master controller.


#### Calculation setting

This function can perform calculation processing based on the measured values of the connected controllers and output the calculation results from the master unit.

<example: thickness / width measurement>

The measured values that the master unit and the slave unit obtain for the measured object are added.

This enables the width of the measured object to be measured.



Other functions that are valid when controllers are connected include the interference prevention function and calculation output function.



# Chapter 4

## Installation and Connections

---

4.1 Mounting the Controller .....	4-2
4.1.1 Mounting on a DIN Rail .....	4-2
4.1.2 Removing from a DIN Rail .....	4-2
4.1.3 Controller Wiring Connection Diagrams .....	4-3
4.2 Attaching the Sensor Head .....	4-4
4.3 Connecting the Sensor Head Connection Cable .....	4-5
4.3.1 Connecting to the Sensor Head .....	4-5
4.3.2 Disconnecting from the Sensor Head .....	4-6
4.3.3 Connecting to the Controller .....	4-7
4.3.4 Disconnecting from the Controller .....	4-7
4.3.5 Connecting and Disconnecting to / from Controller Connector .....	4-8
4.4 Connecting Controllers .....	4-11
4.4.1 How to connect .....	4-12
4.4.2 How to remove .....	4-14
4.5 Mounting the Side View Attachment .....	4-15


## Installation and Connections

---

### 4.1 Mounting the Controller


#### 4.1.1 Mounting on a DIN Rail

1. Fit the rear part of the mounting section of the controller on a DIN rail.
2. While pushing the rear of the mounting part forward, insert the front of the mounting part into the DIN rail.




#### 4.1.2 Removing from a DIN Rail

1. Push the controller forward.
2. Lift up the front part of the controller to remove it.




### 4.1.3 Controller Wiring Connection Diagrams

#### • HG-TC101, HG-TC101-P / Master unit



(Note): Use a shielded cable to extend the analog output line.

#### • HG-TC111, HG-TC111-P / Slave unit



(Note): Use a shielded cable to extend the analog output line.

#### <Reference>


- The **HG-TC111** and **HG-TC111-P** cables do not have +V or 0V. Power is supplied from the connector of the master unit.
- The **HG-TC113** does not have +V, 0V, or each I/O. The connector on the slave unit is used to connect to the master unit.

## Installation and Connections

### 4.2 Attaching the Sensor Head


- The light emitting and receiving surfaces of the sensor head must be free of water, oil, fingerprints, and other substances that refract light as well as dust, grit, and other objects that intercept light.  
If stains or dirt become attached to the sensor head surfaces, wipe them with a lint-free soft cloth or lens cleaning paper. If the surfaces are very dirty, wipe off dirt using a cotton swab (or similar material) moistened with absolute alcohol.
- A serial number is marked on each opposite surface of the light emitting and receiving surfaces of the sensor head.  
Use a pair of emitter and receiver that have the same serial number.

Use M3 screws (to be prepared by the customer) to mount the sensor head.  
Tighten the screws to a torque of 0.5N·m.




#### Mounting hole dimensions

##### • HG-T1010



The mounting holes on the emitter and receiver are bilaterally symmetrical.

##### • HG-T1110



The mounting holes on the emitter and receiver are bilaterally asymmetrical.

### 4.3 Connecting the Sensor Head Connection Cable

Connect the controller and the sensor head using the **CN-HT-C** sensor head connection cable.

#### 4.3.1 Connecting to the Sensor Head




- If the sensor head connection cable is connected to the controller, always turn off the controller power before inserting or removing the connectors.
- Always grasp the connector body when connecting or disconnecting the connector. Wires may break if excessive stress is applied to the cable.
- After inserting the connectors, verify that both are attached firmly. If loose, a connector may fall out and cause an error.




- The sensor head connection cable branches into two cables. The cables are identical and can be connected to either the emitter or receiver.

1. Insert the sensor head connecting cable to the sensor head connection cable connector of the sensor head with the mark aligned.




2. Turn the fastening ring on the sensor head connector in the direction of the arrow to fasten the ring firmly.




## Installation and Connections

### 4.3.2 Disconnecting from the Sensor Head

1. Turn the fastening ring on each sensor head connection cable connector in the direction of the arrow to loosen.




2. Grasp each connector on the sensor head connection cable and pull out to remove.



When disconnecting, always make sure that the fastening ring has been completely loosened before pulling out the cable. Risk of damage if you pull the cable with excessive force (15N or more) with the fastening ring tightened.

### 4.3.3 Connecting to the Controller


Insert the controller connector on the sensor head connection cable into the connector for the sensor head connection cable on the controller.



Insert the connector firmly. Risk of sensor head or controller damage if not completely connected.

### 4.3.4 Disconnecting from the Controller

Grasp the controller, and while pressing on the release lever on the controller connector of the sensor head connection cable, pull the lever toward you to disconnect the cable.



Do not pull by holding the cable without pressing the release lever, as this can cause cable break or connector break.

## Installation and Connections


---

### 4.3.5 Connecting and Disconnecting to / from Controller Connector


The cable on the controller connector side can be shortened.  
Use the following procedures to disconnect and connect the cable from / to the controller connector.

- **Disconnection procedure**

1. Slide the protective cover in the direction of the arrow.




2. Press down on the wire insertion hole lever (white) with a flathead screwdriver (tip width 2mm or less), and disconnect each wire.






## • Connection procedure


1. Align the tip of the wire with the “STRIP GAUGE” mark on the side of the connector, strip the cable so that the core wire length is 7 to 8mm, and twist the core wires several times.



2. Using a flathead screwdriver with a tip width of 2mm or less, press down the lever (white) on the operation unit until the lever locks.




3. Insert the wire all the way into the wire insertion hole. Make sure that the jacketed part of the wire has entered the wire insertion hole and the tips of the core wires have passed through the connection part as shown below.




## Installation and Connections

---


- 4.** Insert the tip of the flathead screwdriver into the release hole so that it contacts the bottom of the lever (white), and move the tip of the flathead screwdriver up. The lever (white) will make a “click” sound when it returns to its original position, and the wire will be locked.



- 5.** Pull on the wire gently to ensure that it does not come out.



- 6.** Slide the protective cover in the direction of the arrow to return the cover to its original position.




## 4.4 Connecting Controllers

- Always shut off the power before connecting a slave unit to or disconnecting a slave unit from the master unit.  
There is a risk of controller damage if you attempt connection or removal with the power ON.
- ❌ ● Insert the male connector firmly into the female connector. Risk of controller damage if not completely connected.
- When connecting slave units to a master unit, connect only NPN output types, or only PNP output types. Dissimilar output types cannot be connected together.
- ❗ ● To connect units, the units must be mounted on a DIN rail. Attach end plates **MS-DIN-E** (optional) so as to enclose the connected units at the ends.

### <Reference>

- Up to 15 slave units can be connected to a master unit. (Up to 14 slave units can be connected if a communication unit is connected.)
- If **HG-TC** series and **HG-SC** series controllers are used in combination, connect a slave unit of the same series (as the master unit) on the near side of the master unit and a slave unit of a different series (from the master unit) on the far side of the master unit.

Example: When **HG-TC**□ is master unit



- If **HG-TC** series and **HG-SC** series controllers are used in combination, some functions such as the calculation function and copy function will be restricted. For details on the restricted functions, consult your Panasonic representative.


## Installation and Connections

---


### 4.4.1 How to connect

For details on how to mount a controller, refer to “4.1 Mounting the Controller”.


1. Mount a master unit on a DIN rail.




2. Remove the connector cover.




3. Mount each slave unit one at a time on the DIN rail. Remove all connector covers except for the cover on the end slave unit.



4. Slide each slave unit and connect the female and male connectors.



- 5.** Attach end plates **MS-DIN-E** (optional) with the flat side facing in so as to enclose the connected units at the ends.



- 6.** Tighten the screws to fasten the end plates.  
Tighten the screws to a torque of  $0.3\text{N}\cdot\text{m}$  or less.




Take care that this product might become damaged if the screws are tightened to a torque exceeding  $0.3\text{N}\cdot\text{m}$ .

## Installation and Connections

---

### 4.4.2 How to remove

- 1.** Loosen the screws on the end plates.
- 2.** Remove the end plate.
- 3.** Slide and remove the controllers, one at a time.



### 4.5 Mounting the Side View Attachment




- Take care that the beam axis can be adjusted after a side view attachment is mounted on the emitter.
- After mounting a side view attachment on the sensor head, check whether the beam axis is aligned. After checking the beam axis, always register the reference waveform and check operations.


Mounting side view attachment **HG-TSV10** on sensor head **HG-T1010** makes various installations possible. (Note 1)

When mounting a side view attachment on the sensor head, use the M2 screws with a washer (length: 4mm) provided.

Tighten the screws to a torque of 0.088 N-m or less.



<Example of **HG-TSV10** mounted on both sides> (Note 2)



Notes: 1) Side view attachments cannot be mounted on sensor head **HG-T1110** (measurement width 10 mm, slim type).

2) **HG-TSV10** is sold by one unit. Two pieces of attachment are required when using the attachment on both emitter and receiver.

(MEMO)



# Chapter 5

## Basic Usage

---

5.1 Using the Base Screen	5-2
5.1.1 Functions of Operation Keys and Display Unit	5-2
5.2 Flow of Operations up to Measurement Startup	5-5
5.3 Explanation of Basic Operation	5-7
5.3.1 Checking the Beam Axis	5-7
5.3.2 Adjusting the Beam Axis	5-9
5.3.3 Reference Waveform Registration	5-14
5.3.4 Teaching	5-15
5.4 Operation Mode	5-22
5.4.1 Auto Edge Detection Mode	5-22
5.4.2 Edge Detection Mode	5-24
5.4.3 External Form/Width Detection Mode	5-25
5.4.4 Inside Diameter/Gap Detection Mode	5-25
5.4.5 Central Position Detection Mode	5-26
5.5 Settings on the Base Screen (Using Shortcut Keys)	5-27
5.5.1 Display Switching Mode	5-27
5.5.2 Preset	5-32
5.5.3 Bank Mode	5-34
5.5.4 Key Lock	5-38
5.5.5 Sensitivity Settings	5-40


## 5.1 Using the Base Screen

### 5.1.1 Functions of Operation Keys and Display Unit


#### ■ Functions of operation keys





<Controller>







## ■ Functions of display unit




 (White)
<b>Guide mark / arrow keys</b>
<b>During measurement</b>
Unlit as the keys are disabled.
<b>During setting</b>
Only enabled arrow keys are lit.

 (White)
<b>Guide mark / Enter</b>
<b>During measurement</b>
Unlit as the key is disabled.
<b>During setting</b>
Lit when the Enter key must be pressed.

3.000 (Green)
<b>Digital display section / SUB</b>
<b>During measurement</b>
Shows the measured value.
<Example: Base screen>

<b>During setting</b>
Shows the selected setting item.
<Example: Screen when HIGH set value is set>


3.000 (White)
<b>Digital display section / MAIN</b>
<b>During measurement</b>
Shows the judgment value that was used for judgment.
<Example: Base screen>

<b>During setting</b>
Shows the set value of the selected setting item.
<Example: Screen when HIGH set value is set>





 (Green / Orange)

### Circle meter


**During measurement**

Shows position information about the measured object by incrementing or decrementing the meter count.


<Example: When the measured value is below LOW set value> (Orange)



<Example: When the measured value is GO> (Green)



<Example: When the measured value is above HIGH set value> (Orange)




"GO" is a value within the judgment range set with the HIGH set value and LOW set value.

**During setting**


- Shows setting item positioner navigation (blinking).

<Example: Setup menu screen>



- Shows the count when an operation key is held down.


<Example: Display switching mode screen>




#### <Reference>

When there is no measured object between the emitter and receiver during measurement mode, the display of the controller display unit is as shown below.

#### <State of sensor head>




#### <State of controller display unit>



The state in which this screen is displayed is called "indeterminate state".

## 5.2 Flow of Operations up to Measurement Startup

This section explains the flow of operations up to measurement startup by using auto edge detection mode as an example.



### Setting up the functions

Perform operation mode settings, teaching settings, output settings, and output operation settings in this order to complete basic operation settings.

1. Select and set operation mode "Auto edge detection mode". (Default) >>"6.3.1 Operation Mode"
2. Perform teaching "1-point teaching" (default) to set the GO range. >>"5.3.4 Teaching"
3. Select and set output setting "3-value output". (Default) >>"7.2.4 External Outputs"
4. Select and set output operation "N.O. (Normally Open)". (Default) >>"6.4.10 Output Operation"

### Start measurement

#### Fine adjustment

To change the GO range, change the HIGH set value and LOW set value to any desired values.

>>"6.4.1 HIGH Set Value"  
"6.4.2 LOW Set Value"



## 5.3 Explanation of Basic Operation

### 5.3.1 Checking the Beam Axis


Check the beam axis to see if the emitter and receiver of the sensor head are installed correctly. For the controller, you can check the beam axis using the digital display section / MAIN (white), digital display section / SUB (green), and circle meter (orange or green).

For the sensor head, you can check the beam axis using the beam axis adjustment indicator / TOP part and beam axis adjustment indicator / BOTTOM part for the receiver. (Except for **HG-T1110**)

**How to display the screen for checking the beam axis** (Beam axis adjustment mode)

Hold down the  key and  key simultaneously on the operation unit of the controller for two seconds.

**To check the beam axis using the controller**




If the beam axis is aligned, all LED segments of the circle meter on the left side of the display unit lights up in green.

At the same time, the bar mark in the middle of the display section / MAIN lights up in white.

The guide mark / Enter on the right side of the display section also lights up in white.

### To check the beam axis using the sensor head (Except for **HG-T1110**)



If the beam axis is aligned, both the beam axis adjustment indicator / TOP and beam axis adjustment indicator / BOTTOM on the sensor head receiver will light up in green.

- Notes: 1) The beam axis adjustment indicator on the sensor head receiver does not light up during measurement mode.  
 2) The **HG-T1110** is not equipped with beam axis adjustment indicators. Therefore, when the **HG-T1110** is used, the beam axis cannot be checked using the sensor head.

#### <Reference>

If the beam axis of the sensor head is misaligned, refer to “5.3.2 Adjusting the Beam Axis” and adjust the beam axis.

If you confirm that the beam axis has been aligned, proceed to 5.3.3 “Registering the Reference Waveform”.

### How to return to measurement mode

You can return to measurement mode by pressing the ☐ key on the operation unit of the controller.




## 5.3.2 Adjusting the Beam Axis

Invoke beam axis adjustment mode and check the state of the beam axis by using the display unit of the controller or the beam axis adjustment indicators on the sensor head receiver (except for **HG-T1110**).


### Checking the beam axis using the display unit of the controller

First, when adjusting the beam axis, select whether adjustment will be performed by moving the emitter or the receiver with the ◀/▶ key of the controller.

<Example: The emitter is too low with respect to the receiver.>




- When "HEAD-E" (emitter base) is selected



















An arrow is displayed from "B" to "T". Move the Emitter to the TOP side and adjust it.

- When "HEAD-D" (receiver base) is selected



An arrow is displayed from "T" to "B". Move the receiver to the BOTTOM side and adjust it.

Depending on the state of the beam axis, the display unit of the controller changes the displays as shown below. Check the circle meter and bar mark.

Display unit of controller (when receiver base is set)			State of beam axis	
State of circle meter (Orange)	State of bar mark (White)	State of guide mark / Enter (White)		
	 (Note)	Unlit		<ul style="list-style-type: none"> <li>The light-receiving side has shifted toward the TOP side (the light-emitting side has shifted toward the BOTTOM side).</li> </ul>
	 (Note)	Unlit		<ul style="list-style-type: none"> <li>The light-receiving side has shifted toward the BOTTOM side (the light-emitting side has shifted toward the TOP side).</li> </ul>
All segments unlit		Unlit		<ul style="list-style-type: none"> <li>The beam axis is completely out of alignment.</li> <li>Laser emission stop input turns ON during beam axis adjustment.</li> <li>The measured object intercepts the entire beam axis.</li> </ul>
		Unlit		<ul style="list-style-type: none"> <li>The beam axis is aligned, but the amount of entering light is too much due to the influences of ambient light, etc.</li> </ul>
		Unlit		<ul style="list-style-type: none"> <li>Light enters, but the beam axis is inclined.</li> </ul>
				<ul style="list-style-type: none"> <li>The beam axis is aligned, but the amount of entering light is too little. (The entire beam axis is covered with a transparent body.)</li> </ul>
		Unlit		<ul style="list-style-type: none"> <li>Objects intercepting light or stains (adhering substances) exist inside the measurement area.</li> </ul>

(Note): If the base used for verifying beam axis adjustment is set to "HEAD-E" (emitter base), the display of the arrows will be reversed. Pay attention to this change.



## Checking the beam axis using the beam axis adjustment indicators on the sensor head receiver


(\* Except for **HG-T1110**)



Depending on the state of the beam axis of the sensor head, the displays of the beam axis adjustment indicators (TOP and BOTTOM parts) on the sensor head receiver change as shown below.

State of beam axis adjustment indicator (TOP / BOTTOM part)	State of beam axis
<p>Unlit(TOP side)</p> <p>Lit [Green(BOTTOM side)]</p>	<ul style="list-style-type: none"> <li>The light-receiving side has shifted toward the TOP side (the light-emitting side has shifted toward the BOTTOM side).</li> </ul>
<p>Lit (Green)</p> <p>Unlit</p>	<ul style="list-style-type: none"> <li>The light-receiving side has shifted toward the BOTTOM side (the light-emitting side has shifted toward the TOP side).</li> </ul>
<p>Unlit</p> <p>Unlit</p>	<ul style="list-style-type: none"> <li>The beam axis is completely out of alignment.</li> <li>Laser emission stop input turns ON during beam axis adjustment.</li> <li>The measured object intercepts the entire beam axis.</li> </ul>
<p>Lit (Orange)</p> <p>Lit (Orange)</p>	<ul style="list-style-type: none"> <li>The beam axis is aligned, but the amount of entering light is too much due to the influences of ambient light, etc.</li> </ul>
	<ul style="list-style-type: none"> <li>Light enters, but the beam axis is inclined.</li> </ul>
	<ul style="list-style-type: none"> <li>The beam axis is aligned, but the amount of entering light is too little. (The entire beam axis is covered with a transparent body.)</li> </ul>
<p>Blinking (Orange)</p> <p>Blinking (Orange)</p>	<ul style="list-style-type: none"> <li>Objects intercepting light or stains (adhering substances) exist inside the measurement area.</li> </ul>

## ■ Adjusting the beam axis


1. Holding down the  key and  key for two seconds invokes beam axis adjustment mode. (The number of lit increments in the circle meter increases while the keys are held down.)



2. Press the  or  key to select either receiver base or emitter base for beam axis adjustment. The sensor head that you move during beam axis adjustment should be selected as the base.

The following figure shows the situation where receiver base is selected


- "HEAD-D": Receiver base (Default)
- "HEAD-E": Emitter base




The beam axis adjustment method is explained below, using an example where the base of beam axis adjustment is set to "HEAD-D" (receiver base).

3. Check whether the beam axis of the sensor head is aligned, using the display unit of the controller or the beam axis adjustment indicators (TOP and BOTTOM parts) on the sensor head receiver.

- Controller display unit



- Sensor head




### <Reference>


For the display of the display unit of the controller, refer to "Checking the beam axis using the display unit of the controller".

For the display of the beam axis adjustment indicators on the sensor head receiver, refer to "Checking the beam axis using the beam axis adjustment indicators on the sensor head receiver".


4. Move the receiver of the sensor head vertically and laterally while checking the display unit of the controller. For the **HG-T1010**, you can check the beam axis using the beam axis adjustment indicators on the sensor head receiver.




- When the controller display unit displays the message shown in the following figure, move the receiver downward (toward BOTTOM).



5. If the beam axis of the sensor head is aligned, all LED segments of the circle meter on the display unit of the controller will light up in green and the guide mark / Enter will light up in white.



- Sensor head



6. If you confirm that the beam axis has been aligned, proceed to “5.3.3 Reference Waveform Registration”. To return to measurement mode, press the key.

### 5.3.3 Reference Waveform Registration

By registering the reference waveform, you can register waveforms in a normal state. Registering normal waveforms helps to improve measurement accuracy and discover any abnormal changes that occur during operation.




- After installing this product, always register the reference waveform. Unless the reference waveform is registered, correct measurements cannot be made.
- Register the reference waveform when there is no measured object.
- When a measured object with a strong specular reflection component (such as glass or specular reflector) is detected, it may not be detected correctly due to the influences of light reflected from the measured object. In such a case, install a pair of emitter and receiver at a certain angle to the measured object so that reflected light does not hit the emitter or receiver. After adjusting the angle, always adjust the beam axis.


#### ■ Registering the reference waveform

1. Invoke beam axis adjustment mode and check that the beam axis is aligned, using the circle meter and guide mark / Enter on the display unit of the controller or the beam axis adjustment indicators (at TOP and BOTTOM parts) on the sensor head receiver.


- Controller display unit



- Sensor head




(Note): The **HG-T1110** is not equipped with beam axis adjustment indicators.

2. When the beam axis is aligned, pressing the  key registers the current waveform as the reference waveform. The registered reference waveform will be stored in the EEPROM of the sensor head receiver.



<Image of registered reference waveform>



(Note): You can use the "**HG-T Configuration Tool**" software view an image of the registered reference waveform.


## 5.3.4 Teaching

### <Overview>

Set the HIGH set value and LOW set value. The range between the LOW set value and the HIGH set value is set as GO range. Values within GO range are judged to be "GO", and values outside GO range are judged to be out-of-range (on LOW or HIGH side).

Term	Description
GO	Refers to the judgment range between the HIGH set value and LOW set value.

### <Settings>



Teaching type	Setting method
1-point teaching (Default)	<p>You can use a master workpiece to set upper and lower limit values. Use this method when you want to set judgment values for the workpiece as <math>\pm</math> tolerance.</p> <p>Upper limit value Tolerance Judgment value Tolerance Lower limit value</p>
2-point teaching	<p>You can use two workpieces to set upper and lower limit values. Use this method when you want to judge workpieces within an upper limit and lower limit range.</p> <p>Upper limit value Lower limit value</p>
3-point teaching	<p>You can use a good workpiece, a HIGH-side defective workpiece, and a LOW-side defective workpiece to set upper and lower limit values. Use this method when you want to judge workpieces within a range that takes the intermediate values between good and HIGH-side or LOW-side defective workpieces as upper and lower limits.</p> <p>Maximum value Upper limit value Median value Lower limit value Minimum value</p>

(Note): Upper and lower limit values are regarded as HIGH and LOW set values, respectively.

### <Reference>

The default setting for the tolerance is "0.100" ( $\pm 0.100$ ).

<When 1-point teaching is selected>


1. Hold down the ◀ key for 2 seconds. (The number of lit increments in the circle meter increases.)



2. "SET1" appears in the digital display section / SUB (green), and the digital display section / MAIN (white) blinks.



3. Press the ◀ key. The position of the master workpiece will be acquired as a judgment value.



4. When teaching is completed, "GOOD" appears in the digital display section / MAIN (white), and the HIGH set value and LOW set value are applied. Then, the display will automatically return to the base screen.



(Note): When tolerance is set to 0.100

(Note): When tolerance is set to 0.100



## <Reference>

- Judgment results that appear in the display are described in the table below.

Digital display section / MAIN (White)	Description
GOOD	Stable measurement can be performed
HARD	Stable measurement cannot be performed (Note)
ERROR	Teaching did not take place correctly (Note)

(Note): If "HARD" or "ERROR" appears in the digital display section / MAIN, restore the controller to its normal state and then execute teaching again.

- If teaching is performed when one of the messages in the table below appears in the digital display section during measurement, teaching will not take place correctly and an error will be displayed. In this case, restore the controller to its normal state and then execute teaching.

Digital display section		Description
MAIN (White) / SUB (Green)	Display	
MAIN (White)	-----	Immediately after the power is turned ON or a reset is input
MAIN (White)	OVER	When the upper or lower display limit is exceeded
MAIN (White)	ALARM	When an alarm is output
SUB (Green)	HWERR	When an error is output

<When 2-point teaching is selected>


1. Hold down the ◀ key for 2 seconds. (The number of lit increments in the circle meter increases.)




2. "SET.1" appears in the digital display section / SUB (green), and the digital display section / MAIN (white) blinks.




3. Measure the first workpiece and then press ◀ key.



4. "SET.2" appears in the digital display section / SUB (green). Measure the second workpiece and then press ◀ key.



5. When teaching is completed, “GOOD” appears in the digital display section / MAIN (white), and the HIGH set value and LOW set value are applied. Then, the display will automatically return to the base screen.



## <Reference>

The higher judgment value is set as the HIGH set value and the lower judgment value is set as the LOW set value, regardless of the order of steps 3 and 4.

<When 3-point teaching is selected>


1. Hold down the ◀ key for 2 seconds. (The number of lit increments in the circle meter increases.)




2. "SET.1" appears in the digital display section / SUB (green), and the digital display section / MAIN (white) blinks.




3. Measure the HIGH-side defective workpiece and press the ◀ key.




4. "SET.2" appears in the digital display section / SUB (green). Measure the good workpiece and press the ◀ key.



5. "SET.3" appears in the digital display section / SUB (green). Measure the LOW-side defective workpiece and press the ◀ key.



6. When teaching is completed, "GOOD" appears in the digital display section / MAIN (white), and the HIGH set value and LOW set value are applied. Then, the display will automatically return to the base screen.



## <Reference>

Regardless of the order of steps 3, 4 and 5, the workpiece judgment values are sorted in order from the highest to the lowest value. The intermediate value between the maximum value and the median value is set as the HIGH set value, and the intermediate value between the minimum value and the median value is set as the LOW set value.

## 5.4 Operation Mode

### <Overview>

You can set an operation mode according to the measurement method for the object to be measured.


- Auto edge detection mode ( *ATEGE* )
- Edge detection mode ( *EDGE* )
- External form/width detection mode ( *OUTWD* )
- Inside diameter/gap detection mode ( *INGAP* )
- Central position detection mode ( *CENPOS* )

For the setting procedure for each operation mode, refer to “6.3.1 Operation Mode”.

### 5.4.1 Auto Edge Detection Mode


This mode automatically recognizes the direction in which the measured object enters the measurement area of the sensor head (TOP or BOTTOM side). The distance from the edge of the side where the measured object enters the measurement area to the edge of the measured object is measured.

#### <When the measured object enters the measurement area from the TOP side>



On the basis of the TOP side, the distance from the TOP side edge to the edge of the measured object is detected as the measured value.

#### <When the measured object enters the measurement area from the BOTTOM side>



On the basis of the BOTTOM side, the distance from the BOTTOM side edge to the edge of the measured object is detected as the measured value.


### <Reference>

- The following states are judged to be indeterminate states and displayed as “.....”.
  - Full light interception state
  - State in which more than one edge is detected


If auto edge detection mode is set, the base position will be switched according to the direction (TOP or BOTTOM side) in which the measured object enters the measurement area of the sensor head, causing the HIGH and LOW set values to be switched.

- Example of switching between HIGH and LOW set values

<When the measured object enters the measurement area from the TOP side>



<When the measured object enters the measurement area from the BOTTOM side>



- When the measured object enters the measurement area from the TOP side, LOW set value 2.0mm is used. When the measured object enters the measurement area from the BOTTOM side, LOW set value 2.0mm is switched to HIGH set value 8.5mm.
- When the measured object enters the measurement area from the BOTTOM side, HIGH set value 7.0mm is used. When the measured object enters the measurement area from the TOP side, HIGH set value 7.0mm is switched to LOW set value 3.5mm.


<Reference>

- If auto edge detection mode is set, the upper limit for measured values is 10.5 mm.


### 5.4.2 Edge Detection Mode

When the direction in which the measured object enters the measurement area of the sensor head is specified as the TOP or BOTTOM side, this mode measures the distance from the TOP or BOTTOM side of the measurement area to the edge of the measured object.

<When the direction in which the measured object enters the measurement area is specified as the TOP side>



On the basis of the TOP side, the distance from the TOP side edge to the edge of the measured object that is the nearest to the BOTTOM side among the sections switching from light interception to light entry is detected as the measured value.



If the measured object enters the measurement area from the BOTTOM side, no measured value is detected. The measured value remains displayed as "-----".

<When the direction in which the measured object enters the measurement area is specified as the BOTTOM side>

The measured object moves in the direction opposite to the one when the direction in which the measured object enters the measurement area is specified as the TOP side.


#### <Reference>

- Full light entry state is displayed as "-----".
- For details on how to set the measurement direction, refer to "6.3.2 Measurement Direction".



## 5.4.3 External Form/Width Detection Mode

This mode measures the external form or width of the measured object.



On the basis of the TOP side, the distance from the edge switching from light entry to light interception that is nearer to the TOP side to the edge switching from light interception to light entry that is nearer to the BOTTOM side is detected as the measured value.


There is no need to set the measurement direction.

### <Reference>

- The following states are judged to be indeterminate states and displayed as "-----".
  - Full light interception state
  - Full light entry state
  - Light interception state on either or both of the TOP and BOTTOM side edges

## 5.4.4 Inside Diameter/Gap Detection Mode

This mode measures the inside diameter or gap of the measured object.



On the basis of the TOP side, the distance from the edge switching from light interception to light entry that is nearer to the TOP side to the next edge switching from light entry to light interception is detected as the measured value.

There is no need to set the measurement direction.


### <Reference>

- The following states are judged to be indeterminate states and displayed as "-----".
  - Full light interception state
  - Full light entry state
  - Light entry state on only either the TOP or BOTTOM side edge

### 5.4.5 Central Position Detection Mode

When an object such as a pin is measured, this mode measures the distance from either the TOP or BOTTOM side edge to the center of the measured object.

<When the measurement direction is specified as the TOP side>



On the basis of the TOP side, the central value (A) between the first edge (B) switching from light entry to light interception and the last edge (C) switching from light interception to light entry is calculated.

The distance from the TOP side edge to the central value (A) is detected as the measured value.


$$A = (B - C)/2$$

B: The first edge that switches from light entry to light interception on the basis of the TOP side

C: The last edge that switches from light interception to light entry

Measured value = A - TOP side edge

<When the measurement direction is specified as the BOTTOM side>



On the basis of the BOTTOM side, the central value (A) between the first edge (B) switching from light entry to light interception and the last edge (C) switching from light interception to light entry is calculated. The distance from the BOTTOM side edge to the central value (A) is detected as the measured value.

$$A = (B - C)/2$$

B: The first edge that switches from light entry to light interception on the basis of the BOTTOM side

C: The last edge that switches from light interception to light entry

Measured value = BOTTOM side edge - A

#### <Reference>

- The following states are judged to be indeterminate states and displayed as ".....".
  - Full light interception state
  - Full light entry state
  - Light interception state on either or both of the TOP and BOTTOM side edges
- For details on how to set the measurement direction, refer to "6.3.2 Measurement Direction".

## 5.5 Settings on the Base Screen (Using Shortcut Keys)

This section explains other functions that can be used from the base screen.


### 5.5.1 Display Switching Mode

#### <Overview>

You can change the display of the digital display / SUB (green) as needed for the task.

For example, if you select "Sensor head measured value", the actually measured value and judgment value can be simultaneously compared and displayed, making it easy to check the state of sensor head measurement.

#### <Settings>



	Name	Digital display SUB (green)	Description	Factory default state
1	Normal measured value	NORMV	Shows the normal measured value. • When using the hold function, you can check internal measured values that are not held.	Default state
2	Calculated value (Note)	CALC	Shows the calculated value. • When using the calculation function and hold function, you can check calculation results that are not held.	—
3	Label	LABEL	You can view and set any values or characters. • This saves you the trouble of attaching sensor number and other labels on the controller.	—
4	LOW set value	LOSET	Shows the LOW set value. • You can check the judgment value and lower limit value at the same time.	—
5	HIGH set value	HISET	Shows the HIGH set value. • You can check the judgment value and upper limit value at the same time.	—
6	Sensor head measured value	HEADV	Shows the measured value from the sensor head. • When using the preset or calibration function, you can check the actual pre-correction measured value.	—
7	Measurement direction	DIRECT	Shows the direction in which the measured object is inserted. You can check that the direction is the TOP or BOTTOM side.	—

Note: Calculation function settings are configured on the master unit. When a setting other than "STAND" (standard difference) is selected for the calculation function, "CALC" appears only on the master unit. When the "STAND" (standard difference) setting is selected for the calculation function, "CALC" appears on the slave units but not on the master unit. When the calculation function is not used, this does not appear on either the master unit or the slave units.


"CALC" does not appear on a master unit that is not connected to slave units.

<Reference>


- "NORM" (Normal Value) is the normal measured value to which the preset, measurement direction, and calibration function are reflected.
- "HEAD" (Head Value) is the measured value from the sensor head.
- The digital display section / MAIN (white) displays the judgment value that triggers judgment output ON / OFF based on the LOW set value and the HIGH set value. Analog output is also output based on the judgment value.

## <Setting method>


1. Hold down the  $\triangle$  key for 2 seconds. (The number of lit increments in the circle meter increases.)





2. "NORM.V" (normal measured value) appears in the digital display section / SUB (green).




3. Press the  $\triangle / \nabla$  key to switch to the item you want to display.




4. Press the  key to apply the setting and return to the base screen.








However, if you press the  key with "LABEL" selected, you will move to the label setting screen.





## <Label settings>


1. If you press the  key with "LABEL" selected in display switching mode, you will move to the label setting screen.



2. Press the  /  key to change the alphanumeric character. Press the  /  key to change the digit position.



3. Press the  key to apply the setting and return to the base screen.



## 5.5.2 Preset


### <Overview>


You can perform zero-point adjustment and shift to any preset value.

You can perform reference zero-point adjustment when the sensor head has been replaced or when the workpiece has been changed, and set the dimensions of the master workpiece (or the like) as preset values for use as master values (reference values).

### <Presets>

1. Perform master workpiece measurement.



2. Press the  key with the master workpiece measured.  
When the preset function turns ON, the preset indicator (green) lights up.  
If the preset value is set to "0.000" (default setting), you can perform zero-point adjustment.



Preset key



Preset indicator (Green)





## <Reference>

- If you change the preset value with the preset function turned OFF, the normal measured value will be shifted according to the preset value.
- To set preset values by external input, set external input to preset input.
- If you set preset values by key operation, the preset values are saved in internal memory and retained even after the power is turned OFF.
- The internal memory can be used approximately one million times.
- If one of the messages in the table below appears in the digital display section, the preset function has not been executed correctly and an error has occurred. In this case, restore the controller to its normal state and then execute the preset function.

Digital display section		Description
MAIN (White) / SUB (Green)	Display	
MAIN (White)	-----	Immediately after the power is turned ON or a reset is input or when a measured object has not entered the measurement area
MAIN (White)	OVER	When the upper or lower display limit is exceeded
MAIN (White)	ALARM	When an alarm is output
SUB (Green)	HWERR	When an error is output

## <Canceling a preset>

1. To cancel the preset function, hold down the  key for 2 seconds.




### 5.5.3 Bank Mode

#### <Overview>

You can save or load the HIGH set value, LOW set value, or other settings to / from a specified bank (1 to 3).

You can use the bank function to save settings for an object to be measured in a bank beforehand and easily load the settings when needed.



#### • Types of setting items saved to and loaded from banks


Setting item	Factory default state
All setting items	—
HIGH set value, LOW set value	Default state
HIGH set value, LOW set value, preset value sensitivity adjustment, judgment level, and judgment filter	—


#### <Reference>

- For details on how to change the setting items saved to and loaded from banks, refer to “7.5 Bank Settings”.
- Set values saved to and loaded from banks are saved in internal memory and retained even after the power is turned OFF.
- The internal memory can be used approximately one million times.


## ■ Saving and loading to / from banks by key operation

<Setting method>


1. Hold down the  key for 2 seconds. (The number of lit increments in the circle meter increases.)





2. "SAVE" appears in the digital display section / SUB (green).




3. Press the  /  key to switch between "SAVE" and "LOAD".




4. Press the  key. "BANK1" appears in the digital display section / SUB (green), and "YES" appears in the digital display section / MAIN (white).





5. Press the  /  key to change banks.





6. Press the  key to set the bank. “YES” blinks in the digital display section / MAIN (white).





7. Press the  /  key to switch between “YES” and “NO”.



8. Press the  key.  
If you selected “SAVE” in step 3, the current settings are saved to the bank.  
If you selected “LOAD” in step 3, the settings saved in the bank are loaded.



9. Press the  key twice to return to the base screen.



### ■ Loading by external input

By using bank A input and bank B input that are external inputs, the settings stored in each bank can be loaded by the external inputs.

Using combinations of bank A input and bank B input ON and OFF, you can load settings from each bank.

- Input external input signals for at least 20ms.
- Bank A input and bank B input combinations are shown below.

Bank No. to load from	Bank A input	Bank B input
Bank 1	ON	OFF
Bank 2	OFF	ON
Bank 3	ON	ON

#### <Reference>



Settings cannot be saved to banks by external input.


## 5.5.4 Key Lock

### <Overview>

You can lock the operation keys to prevent accidental key operation during measurement. While key lock is activated, all key operations other than key lock release cannot be performed.

### <Key lock setting>

1. Hold down the  key and  key simultaneously for 2 seconds. (The number of lit increments in the circle meter increases.)



Hold down simultaneously for 2 seconds

2. "LOCK" appears in the digital display section / SUB (green), and "ON" appears in the digital display section / MAIN (white). Then, the display will automatically return to the base screen.



### <Reference>


- When any key is pressed, "LOCK" appears in the digital display section / SUB (green), and "ACT" appears in the digital display section / MAIN (white).



- Functions that use external input are enabled.
- You can configure settings to activate key lock automatically when key operation is not performed for 5 minutes or more.

### <Key lock release>

1. While key lock is enabled, hold down the  key and  key simultaneously for 2 seconds. "OFF" appears in the digital display section / MAIN (white) and lock is released.



(Note): Even when auto key lock is enabled, you can use the above operation to release the lock.

### 5.5.5 Sensitivity Settings

#### <Overview>

You can adjust measurement sensitivity according to the light transmittance and measurement state of the measured object.

For sensitivity settings, you can set a judgment level and judgment filter. You can cope with various applications by combining judgment level and judgment filter settings.


#### ■ Judgment level

Adjusting the judgment level enables objects with high transmittance to be measured stably.


The judgment level is a set value that is used to judge whether the sensor head receiver is in a light entry state or light interception state according to the intensity of light received by the receiver.

If the intensity of received light that is registered as the reference waveform is regarded as 100% and the intensity of received light falls below a judgment level of 25% (default value), the receiver will be judged to be in a light interception state and the edge position will be calculated. For measured objects with high transmittance, you must increase the judgment level because light is received even in sections where light is intercepted.

#### <When the measured object is opaque>




#### <When the measured object is translucent>






## <Judgment level settings>


1. Hold down the ◀ key and ▶ key simultaneously for 2 seconds. (The number of lit increments in the circle meter increases.)



2. "SEN.ADJ" (sensitivity settings) appears in the digital display section / SUB (green), and "DEFAULT" appears in the digital display section / MAIN (white).




3. Press the ◀ key to set the default. "DEFAULT" blinks in the digital display section / MAIN (white).








4. Press the ◀ / ▶ key to switch between "DEFAULT" (default) and "USER" (user settings).





Sensitivity setting	Function
Default (DEFAULT)	Sets to the default state
User settings (USER)	Allows you to specify any desired judgment level value and judgment filter value


5. Select **"USER"** (user settings) and press the  key twice. **"JDG.LVL"** (judgment level) appears in the digital display section / SUB (green), and **"25"** (default) appears in the digital display section / MAIN (white).




6. Set a judgment level. Press the  /  key to change the numeric character. Press the  /  key to change the digit position.



7. After setting the judgment level, press the  key. **"JDG.FIL"** (judgment filter) appears in the digital display section / SUB (green), and **"9"** (default) appears in the digital display section / MAIN (white).



To return to the base screen halfway during setting, hold down the  key for 2 seconds.





## ■ Judgment filter

Judgment filters can make measurement less affected by dirt and other foreign objects adhering to the glass cover of the sensor head emitter or receiver.

For judgment filter "3", only when at least three consecutive pixels appear as the light interception part of the sensor head receiver, the receiver is judged to be in a light interception state and the edge position (measured value) is calculated. When dirt adheres to the emitter or receiver, measurement can be continued unless at least three consecutive pixels appear as the light interception part.


If the filter value is too large, small objects cannot be measured.

<For judgment filter "3">




## <Judgment filter settings>


1. Hold down the ◀ key and ▶ key simultaneously for 2 seconds. (The number of lit increments in the circle meter increases.)



2. "SEN.ADJ" (sensitivity settings) appears in the digital display section / SUB (green), and "DEFAULT" appears in the digital display section / MAIN (white).




3. Press the ◀ key to set the default. "DEFAULT" blinks in the digital display section / MAIN (white).








4. Press the ◀ / ▶ key to switch between "DEFAULT" (default) and "USER" (user settings).





Sensitivity setting	Function
Default (DEFAULT)	Sets to the default state
User settings (USER)	Allows you to specify any desired judgment level value and judgment filter value


5. Select **"USER"** (user settings) and press the  key twice. **"JDG.FIL"** (judgment filter) appears in the digital display section / SUB (green), and **"9"** (default) appears in the digital display section / MAIN (white).





6. Set a judgment filter. Press the  /  key to change the numeric character. Press the  /  key to change the digit position.



7. After setting a judgment filter, press the  key. **"FINISH"** blinks in the digital display section / MAIN (white) and then the display returns to the base screen.



To return to the base screen halfway during setting, hold down the  key for 2 seconds.



Setting item	Setting range	Default value
judgment filter (JDG.FIL)	3 to 50	9

(MEMO)



# Chapter 6

## Setting up General Functions

---


6.1 Flow of Measurement Data .....	6-2
6.2 Setting Operation List .....	6-3
6.3 Detection Settings ( <i>DETECT</i> ) .....	6-9
6.3.1 Operation Mode ( <i>OPMODE</i> ) .....	6-9
6.3.2 Measurement Direction ( <i>DIRECT</i> ) .....	6-10
6.3.3 Average Count (Response Time) ( <i>SPEED</i> ) .....	6-11
6.4 Basic Settings ( <i>BASIC</i> ) .....	6-14
6.4.1 HIGH Set Value ( <i>HISET</i> ) .....	6-14
6.4.2 LOW Set Value ( <i>LOSET</i> ) .....	6-16
6.4.3 Hysteresis ( <i>HYSTER</i> ) .....	6-18
6.4.4 Teaching Types ( <i>TEACH</i> ) .....	6-20
6.4.5 Tolerance $\langle \pm \rangle$ ( <i>TOL</i> $\langle \pm \rangle$ ) .....	6-22
6.4.6 Preset Value ( <i>PRVAL</i> ) .....	6-23
6.4.7 Preset Data Selection ( <i>PROBJ</i> ) .....	6-24
6.4.8 Preset Save ( <i>PRSAVE</i> ) .....	6-25
6.4.9 Reference Waveform Save ( <i>RWSAVE</i> ) .....	6-26
6.4.10 Output Operation ( <i>OUTPUT</i> ) .....	6-27
6.4.11 Analog Output Selection ( <i>A/OSSEL</i> ) .....	6-28
6.4.12 Menu Display Settings ( <i>MENU</i> ) .....	6-29
6.5 Initialization ( <i>RESET</i> ) .....	6-30
6.6 Maintenance ( <i>MAINTN</i> ) .....	6-31

## Setting up General Functions

### 6.1 Flow of Measurement Data

For controllers, up to 15 slave units can be connected to a master unit. (Up to 14 slave units can be connected if a communication unit is connected.) Each controller can perform measurements independently and measured values can be calculated between controllers. Each function is executed as shown in the following flowchart.

Example: When one master unit and two slave units are connected and calculation application selection "THICK" (thickness/width measurement) and independent measurement are used at the same time <When the master unit and slave unit 1 perform calculations and slave unit 2 performs independent measurement>




Notes: 1) When calculation mode is selected, the number of slave units performing calculations varies according to the calculation application selection settings.

2) Displayed only during calculation

## 6.2 Setting Operation List

### ■ Setting mode selection (General functions)




No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
1	Detection settings (DETECT)		This function allows you to set an operation mode, the direction of insertion, and average count according to the shape or application of the measured object.	6-9
2	Basic settings (BASIC)		This function allows you to specify basic settings such as threshold values and output operation. Functions can also be extended with menu display settings.	6-14
3	Initialization (RESET)		This function allows you to return all controller settings (other than calibration settings) to the factory default settings.	6-30
4	Maintenance (MAINT)		This function displays the cumulative operating periods for the controller and sensor head.	6-31

#### <Reference>

- Pressing the ▽ key in each setting mode allows you to enter a function selection item.
- You can extend function selection items from menu display settings in basic settings mode. For details on menu display settings, refer to “6.4.12 Menu Display Settings”.

## Setting up General Functions

### ■ Function selection [Detection settings]




No.	Item	Display screen	Function	Reference page
—	Initial screen		—	—
1	Detection settings		—	—
1-a	Operation mode (OP.MODE)		This function allows you to set an operation mode according to the use of the measurement method for the object to be measured. <Default: AT.EDGE>	6-9
1-b	Measurement direction (DIRECT)		This function allows you to set the insertion direction of the measured object to the TOP or BOT-TOM side. <Default: TOP>	6-10
1-c	Average count (response time) (SPEED)		This function allows you to set the time period (response time) from when the sensor head starts measurement until a judgment value (JUDGE.V) is finalized and a judgment is output. The response time differs depending on whether the sampling cycle is high-speed sampling or standard sampling. <Default: 32>	6-11

#### <Reference>





- The key operation (for the ) for returning to the setting mode selection screen also applies to the ☐ key.

## ■ Function selection [Basic settings]



No.	Item	Display screen	Function	Reference page
–	Initial screen		–	–
2	Basic settings		–	–
2-a	HIGH set value (HI.SET)		This function allows you to manually set the HIGH set value (upper limit value) to any desired value. <Default: 5.000>	6-14
2-b	LOW set value (LO.SET)		This function allows you to manually set the LOW set value (lower limit value) to any desired value. <Default: 1.000>	6-16
2-c	Hysteresis (HYSTER)		If the judgment value (JUDGE.V) fluctuates in the vicinity of the HIGH/LOW set value, judgment output may turn ON and OFF repeatedly, resulting in unstable operations. Increasing the value of hysteresis makes operations stable. <Default: 0.003>	6-18
2-d	Teaching type (TEACH)		This function allows you to set HIGH and LOW set values automatically. <Default: TCH.1>	6-20
2-e	Tolerance <±> (TOL <±>)		When 1-point teaching is performed, the judgment value (JUDGE.V) of the master workpiece plus the tolerance is set as the HIGH set value and the judgment value of the master workpiece minus the tolerance is set as the LOW set value. <Default: 0.100>	6-22
2-f	Preset value (PR.VAL)		When the preset function is set to ON, this function allows you to shift to any preset value (by addition/subtraction). When the preset function is set to OFF, this function shifts the normal measured value according to the preset value. <Default: 0.000>	6-23
2-g	Preset data selection (PR.OBJ)		This function allows you to select target data (NORM.V or JUDGE.V) to be preset. <Default: NORM.V>	6-24
2-h	Preset save (PR.SAVE)		Setting preset save to ON allows you to write information preset with external input to the EEPROM of the controller. Even if the power is turned OFF, the preset ON/OFF state and offset value remain stored. <Default: OFF>	6-25


## Setting up General Functions

No.	Item	Display screen	Function	Reference page
2-i	Reference waveform save (BW.SAVE)		This function is only valid for communication commands from the host device. Setting reference waveform save to ON allows you to write the reference waveform to the EEPROM of the sensor head receiver when reference waveform registration is executed with a communication command from the host device. <Default: OFF>	6-26
2-j	Output operation (OUTPUT)		This function allows you to select an operation for judgment output. <Default: N.O.>	6-27
2-k	Analog output selection (A/O.SEL)		This function allows you to select analog voltage output or analog current output. <Default: 1-5 V>	6-28
2-l	Menu display setting (MENU)		This function allows you to select general function display or extended function display. <Default: NORMAL>	6-29

### <Reference>

- The key operation (for the  $\Delta$  key) for returning to the setting mode selection screen also applies to the  $\square$  key.

■ Initialization settings




No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
3	Initialization		-	6-30
3-a	Initialization (RESET)		This function allows you to return all controller settings (other than calibration settings) to the factory default settings.	

<Reference>  
The key operation (for the key) for returning to the setting mode selection screen also applies to the ☐ key.

# Setting up General Functions

## ■ Maintenance



No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
4	Maintenance		-	-
4-a	Cumulative operating period (RUN.TIM)		This function displays the cumulative operating period for the controller.	6-31
4-b	Cumulative head operating period (HD.TIME)		This function displays the cumulative operating period for the sensor head.	

<Reference>

The key operation (for the key) for returning to the setting mode selection screen also applies to the ☐ key.






## Setting up General Functions

### 6.3.2 Measurement Direction ( DIRECT )

This function sets the insertion direction of the measured object to the TOP or BOTTOM side.


Measurement direction	Function
TOP(TOP)	When the measured object is inserted from the TOP side
BOTTOM(BOTTOM)	When the measured object is inserted from the BOTTOM side



<Reference>

When the operation mode (OP.MODE) is set to auto edge detection mode (AT.EDGE), external form/width detection mode (OUT.WD), or inside diameter/gap detection mode (IN.GAP), the measurement direction is displayed as "X X X X X".

## Setting method



Setting item	Setting range	Default value
Measurement direction (DIRECT)	TOP(TOP) BOTTOM(BOTTOM)	TOP

### 6.3.3 Average Count (Response Time) ( *SPEED* )

This function allows you to set the time period (response time) from when the sensor head starts measurement until a judgment value (JUDGE.V) is finalized and a judgment is output. The response time differs depending on whether the sampling cycle is high-speed sampling or standard sampling.

- Sampling cycle: Standard sampling "NORMAL"


Average count (number of times)	Sampling cycle (ms)	Response time (ms)	Update cycle (ms)
1	1	2	1
2	1	3	1
4	1	5	1
8	1	9	1
16	1	17	1
32	1	33	1
64	1	65	1
128	1	129	2
256	1	257	4
512	1	513	8
1,024	1	1,025	16

- Sampling cycle: High-speed sampling "HI-SPD"


Average count (number of times)	Sampling cycle (ms)	Response time (ms)	Update cycle (ms)
1	0.5	1.5	0.5
2	0.5	2	0.5
4	0.5	3	0.5
8	0.5	5	0.5
16	0.5	9	0.5
32	0.5	17	0.5
64	0.5	33	0.5
128	0.5	65	1
256	0.5	129	2
512	0.5	257	4
1,024	0.5	513	8

## Setting up General Functions

- When the average count is set to 8  
(Sampling cycle: Standard sampling "NORMAL")




- Update cycle



### <Reference>

- Setting the average count to a small value enables the sensor head to respond to momentary changes. Setting the average count to a large value enables the sensor head to be less influenced by sudden changes or similar events.
- Indeterminate value display "-----" appears until the average count is reached after reset input turns ON.
- For details on sampling cycles, refer to "7.2.12 Sampling Cycle".
- If "MODE" (calculation mode) is set to "CALC" (calculate), approximately 3 ms will be added to the response time for judgment output. For details on calculation mode, refer to "7.3.1 Calculation Mode".

Setting method



Setting item	Set value	Default value
Average count (response time) (SPEED)	1	32
	2	
	4	
	8	
	16	
	32	
	64	
	128	
	256	
	512	
	1024	


# Setting up General Functions

## 6.4 Basic Settings ( BASIC )

This function allows you to specify basic settings such as threshold values and output operation. Functions can also be extended with menu display settings.


### 6.4.1 HIGH Set Value ( HISET )

This function allows you to set the HIGH set value (upper limit value) to any desired value. If the judgment value (JUDGE.V) exceeds the HIGH set value, the judgment is output as HIGH.



- <Reference>
- Be sure to set a HIGH set value that is greater than the LOW set value.
  - The HIGH set value can be always displayed in the digital display section / SUB (green). For details, refer to “5.5.1 Display Switching Mode”.
  - By teaching, you can set HIGH and LOW set values. For details, refer to “5.3.4 Teaching”.

### Setting method




Setting item	Setting range	Default value
HIGH set value (HI.SET)	-199.999 to 199.999 (mm)	5.000


- <Reference>
- In addition to this method, you can also set a HIGH set value directly from the base screen during measurement.

<Setting a HIGH set value directly during measurement>

1. Press the  $\Delta$  key in the base screen. "HI.SET" appears in the digital display / SUB (green), and the HIGH set value appears in the digital display / MAIN (white).



2. Press the  $\triangleleft$  /  $\triangleright$  key to change the digit position. Press the  $\Delta$  /  $\nabla$  key to increase or decrease the numerical value.



3. Press the  $\hookrightarrow$  key to finalize the setting.


### <Reference>

If you take no action for 5 seconds, the screen will automatically return to the base screen and the setting will be finalized.

## Setting up General Functions

### 6.4.2 LOW Set Value (LOSET)


This function allows you to set the LOW set value (lower limit value) to any desired value. If the judgment value (JUDGE.V) falls below the LOW set value, the judgment is output as LOW.



<Reference>

- Be sure to set a LOW set value that is smaller than the HIGH set value.
- The LOW set value can be always displayed in the digital display section / SUB (green). For details, refer to “5.5.1 Display Switching Mode”.
- By teaching, you can set HIGH and LOW set values. For details, refer to “5.3.4 Teaching”.

## Setting method



Setting item	Setting range	Default value
LOW set value (LO.SET)	-199.999 to 199.999 (mm)	1.000


<Reference>

In addition to this method, you can also set a LOW set value directly from the base screen during measurement.




<Setting a LOW set value directly during measurement>

1. Press the  $\nabla$  key in the base screen. "LO.SET" appears in the digital display / SUB (green), and the LOW set value appears in the digital display / MAIN (white).



2. Press the  $\triangle / \nabla$  key to change the digit position. Press the  $\triangle / \nabla$  key to increase or decrease the numerical value.



3. Press the  $\hookleftarrow$  key to finalize the setting.

<Reference>

If you take no action for 5 seconds, the screen will automatically return to the base screen and the setting will be finalized.

## Setting up General Functions


### 6.4.3 Hysteresis (HYSTER)

If the measured object vibrates in the vicinity of the HIGH/LOW set value, the judgment value may fluctuate, resulting in unstable operations. Increasing the value of hysteresis makes operations stable.

- If hysteresis is "0"

The judgment value (JUDGE.V) fluctuates in the vicinity of the HIGH set value (or LOW set value), making judgment output unstable.


(In the following timing chart, external output is set to "3VAL" and output operation is set to "N.O.".)



- If hysteresis is set

Even if the judgment value (JUDGE.V) fluctuates in the vicinity of the HIGH set value (or LOW set value), judgment output will be stable.

(In the following timing chart, external output is set to "3VAL" and output operation is set to "N.O.".)




<Reference>


- For details on external output, refer to "7.2.4 External Outputs".
- For details on output operation, refer to "6.4.10 Output Operation".

## Setting up General Functions


- Set hysteresis to a value that is smaller than the difference between the HIGH set value and LOW set value. If hysteresis is set to a value that is equal to or greater than the difference between the HIGH set value and LOW set value, the judgment is not output as "GO".



- Even if hysteresis is set, be sure to set a HIGH set value that is greater than the LOW set value. If the LOW set value is set to a value that is equal to or greater than the HIGH set value, the judgment is not output as "GO".



## Setting method




Setting item	Setting range	Default value
Hysteresis (HYSTER)	0 to 199.999 (mm)	0.003

# Setting up General Functions

## 6.4.4 Teaching Types (TEACH)

By teaching, you can automatically set HIGH and LOW set values.  
 For the teaching method, you can select 1-point teaching, 2-point teaching, or 3-point teaching.

<Settings>




Teaching type	Setting method
1-point teaching (Default)	<p>You can use a master workpiece to automatically set upper and lower limit values. Use this method when you want to judge workpieces by a <math>\pm</math> tolerance.</p> <p>Upper limit value Tolerance Judgment value Tolerance Lower limit value</p>
2-point teaching	<p>You can use two workpieces to automatically set upper and lower limit values. Use this method when you want to judge workpieces within an upper limit and lower limit range.</p> <p>Upper limit value Lower limit value</p>
3-point teaching	<p>You can use a good workpiece, a HIGH-side defective workpiece, and a LOW-side defective workpiece to automatically set upper and lower limit values. Use this method when you want to judge workpieces within a range that takes the intermediate values between good and defective workpieces as upper and lower limits.</p> <p>Maximum value Upper limit value Median value Lower limit value Minimum value</p> <p>HIGH defective workpiece      Good workpiece      LOW defective workpiece</p>

(Note): Upper and lower limit values are regarded as HIGH and LOW set values, respectively.

<Reference>  
 For details on how to perform teaching, refer to “5.3.4 Teaching”.

## Setting method




Setting item	Set value	Default value
Teaching type (TEACH)	1-point teaching (TCH.1) 2-point teaching (TCH.2) 3-point teaching (TCH.3)	TCH.1

## Setting up General Functions

#### 6.4.5 Tolerance <±>(TOL (<±>))

When 1-point teaching is performed, the judgment value (JUDGE.V) of the master workpiece plus the tolerance can be set as the HIGH set value and the judgment value of the master workpiece minus the tolerance can be set as the LOW set value.




(Note 1): When the tolerance ( $\pm$ ) is set to 1.000

<Reference>

- Settings of tolerance  $\langle \pm \rangle$  are valid only when 1-point teaching is set.
- For details on how to perform 1-point teaching, refer to “5.3.4 Teaching”.

## Setting method




Setting item	Setting range	Default value
Tolerance ( $\pm$ )(TOL< $\pm$ >)	0 to 199.999	0.100

## 6.4.6 Preset Value (PRVAL)

When preset is performed, this function allows you to shift to any preset value (by addition/subtraction).

You can set the dimensions of the master workpiece (or the like) as preset values for use as master values (reference values).


Setting preset to OFF shifts the measured value.



### <Reference>

- Setting preset to ON with the preset value set to 0 (default value) performs zero-point adjustment.
- If you change the preset value with preset set to OFF, the measured value will be shifted according to the preset value.
- Even if preset is being executed, any changes to preset value settings will be reflected.
- For details on the preset function, refer to “5.5.2 Preset”.

### Setting method



Setting item	Setting range	Default value
Preset value (PR.VAL)	-199.999 to 199.999 (mm)	0.000

# Setting up General Functions


## 6.4.7 Preset Data Selection ( PROJ )

This function allows you to select target data (NORM.V or JUDGE.V) to be preset.  
Selecting "Judgment value (JUDGE.V)" allows you to preset any value that you hold.

Preset data selection	Function
Normal measured value (NORM.V)	Normal measured values (NORM.V) are targeted for presetting.
Judgment value (JUDGE.V)	Judgment values (JUDGE.V) are targeted for presetting.

<Reference>  
If you set preset data selection to "Judgment value (JUDGE.V)" and then set the calculation function to any application other than "standard difference" mode, normal measured values (NORM.V) will be targeted.

### Setting method



Setting item	Set value	Default value
Preset data selection (PR.OBJ)	Normal measured value (NORM.V) Judgment value (JUDGE.V)	NORM.V



### 6.4.8 Preset Save ( *PR.SAVE* )

Setting PR.SAVE (preset save) to ON allows you to write information preset with external input to the EEPROM of the controller.


Even if the power is turned OFF, the preset value will remain stored.

When the power is turned ON, the controller reads the preset ON/OFF state and offset value that were written to the EEPROM last time.

#### <Reference>

- The EEPROM of the controller can be rewritten approximately one million times. If there is no need to save preset values, set PR.SAVE (preset save) to OFF.
- If you set preset values by key operation, the preset values are saved in internal memory and retained even after the power is turned OFF.
- If preset input has been set for external input, preset can be performed by external input.
- For preset input by external input, refer to “7.2.3 External Inputs”.

#### Setting method



Setting item	Set value	Default value
Preset save (PR.SAVE)	Preset save OFF (OFF) Preset save ON (ON)	OFF

# Setting up General Functions

## 6.4.9 Reference Waveform Save ( BW.SAVE )

This function is only valid for communication commands from the host device.  
 Setting "BW.SAVE" (reference waveform save) to ON writes the reference waveform to the EEPROM of the sensor head receiver when reference waveform registration is executed with a communication command from the host device. Setting "BW.SAVE" (reference waveform save) to OFF prevents the reference waveform from being written to the EEPROM.




If you turn OFF the power with "BW.SAVE" (reference waveform save) set to OFF, waveform data that is registered when reference waveform registration is executed with a communication command from the host device will not be saved into the EEPROM of the sensor head receiver. If you need to save the waveform data, be sure to set "BW.SAVE" (reference waveform save) to ON.

### <Reference>

- The EEPROM of the sensor head receiver can be rewritten approximately one million times. Pay attention to the upper limit to the number of save operations. If there is no need to save reference waveforms, set "BW.SAVE" (reference waveform save) to OFF.
- Reference waveforms that are registered through key operations or PC tools will be saved into the EEPROM regardless of the set value.

### Setting method




Setting item	Set value	Default value
Reference waveform save (BW.SAVE)	Reference waveform save OFF (OFF)	OFF
	Reference waveform save ON (ON)	

## 6.4.10 Output Operation ( OUTPUT )


This function allows you to select an operation for judgment output.

Output operation	Function
Normally open (N.O.)	ON is output at the time of judgment output.
Normally closed (N.C.)	OFF is output at the time of judgment output.

- Example of output operation settings (for GO output)



### Setting method



Setting item	Set value	Default value
Output operation (N.O./N.C.)	Normally open (N.O.) Normally closed (N.C.)	N.O.

### <Reference>

- For alarm output when external output is "2VAL", "LOGIC", or "LOGIC2", output operation is "Normally Closed" (N.C.) regardless of the settings.
- For details on external output, refer to "7.2.4 External Outputs".


# Setting up General Functions

## 6.4.11 Analog Output Selection ( A/OSEL )

This function allows you to select analog output as either analog voltage output or analog current output.

Output operation	Function
Analog voltage output (1-5V)	Analog output is selected as analog voltage output.
Analog current output (4-20mA)	Analog output is selected as analog current output.

### Setting method



Setting item	Set value	Default value
Analog output selection (A/O.SEL)	Analog voltage output (1-5V) Analog current output (4-20mA)	1-5V

<Reference>

If output operation is an indeterminate state "-----", analog output is "1 V" when analog voltage output is set or "0 mA" when analog current output is set.


If output operation is an alarm, analog output is "5.2 V" when analog voltage output is set or "0 mA" when analog current output is set.

## 6.4.12 Menu Display Settings (MENU)

Functions can be extended by changing the menu display settings.  
Changing the menu display for extended settings display enables you to change the settings of the following functions.

Setting mode	Setting item
Advanced settings (ADVANC)	Hold settings (HOLD) Simultaneous input (ALL IN)(for master units only) External input (EXT.IN) External output (EXT.OUT) External output delay timer selection (OUT.DLY) Number of digits displayed (DIGIT) Analog scaling (ANALOG) Eco mode (ECO) Alarm settings (ALARM) Key lock function selection (KEYLOC) Interference prevention function (INTF.PR)(for master units only) Sampling cycle (SAMPLI)
Calculation settings (CALC)(for master units only)	Calculation mode (MODE) Calculation application selection (APPLI)
Copy settings (COPY)	Copy individual selection (CPY.SEL)(for master units only) Copy batch selection (CHK.ALL)(for master units only) Copy execution (CPY.EXE)(for master units only) Copy lock (LOCK)(for slave units only)
Bank settings (BANK)	Bank save selection (BNK.DAT)
Calibration settings (CALIB)	Calibration selection (CAL.SEL)

### Setting method



Setting item	Set value	Default value
Menu display settings (MENU)	General function display (NORMAL) Extended function display (ADV.)	NORMAL

#### <Reference>

Turning OFF the power returns "MENU" (menu display settings) to "NORMAL" (general function display).


## 6.5 Initialization ( RESET )

This function allows you to reset all the controller settings to the factory default settings. For each default value of general functions, refer to “6.2 Setting Operation List”. For each default value of extended functions, refer to “7.1 Setting Operation List”.

### <Reference>

- The key operation (for the  $\triangle$  key) for returning to the setting mode selection screen also applies to the  $\square$  key.
- Reference waveform registration and calibration settings, key lock function settings, and settings stored in banks are not initialized.


### Setting method



## 6.6 Maintenance ( MAINT )

This function displays the cumulative operating periods for the controller and sensor head.

### Setting method



Item	Function
Cumulative operating period (RUN. TIM)	This function displays the cumulative operating period for the controller. (Units: h)
Cumulative head operating period (HD. TIME)	This function displays the cumulative operating period for the sensor head. (Units: h)

#### <Reference>

The key operation (for the  $\triangle$  key) for returning to the setting mode selection screen also applies to the  $\square$  key.

(MEMO)



# Chapter 7

## Setting up Extended Functions

---


7.1 Setting Operation List .....	7-2
7.2 Advanced Settings ( <i>ADVANCE</i> ) .....	7-9
7.2.1 Hold Settings ( <i>HOLD</i> ) .....	7-9
7.2.2 Simultaneous Input ( <i>ALL IN</i> )(For Master Units Only) .....	7-17
7.2.3 External Inputs ( <i>EXTIN</i> ) .....	7-18
7.2.4 External Outputs ( <i>EXTOUT</i> ) .....	7-21
7.2.5 External Output Delay Timer Selection ( <i>OUTDELAY</i> ) .....	7-27
7.2.6 Number of Digits Displayed ( <i>DIGIT</i> ) .....	7-31
7.2.7 Analog Scaling ( <i>ANALOG</i> ) .....	7-32
7.2.8 Eco Mode ( <i>ECO</i> ) .....	7-37
7.2.9 Alarm Settings ( <i>ALARM</i> ) .....	7-38
7.2.10 Key Lock Function Selection ( <i>KEYLOCK</i> ) .....	7-44
7.2.11 Interference Prevention Function ( <i>INTFPR</i> )(For Master Units Only) ..	7-45
7.2.12 Sampling Cycle ( <i>SAMPLI</i> ) .....	7-47
7.3 Calculation Settings ( <i>CALC</i> )(For Master Units Only) .....	7-48
7.3.1 Calculation Mode ( <i>MODE</i> ) .....	7-48
7.3.2 Calculation Application Selection ( <i>APPLI</i> ) .....	7-49
7.4 Copy Settings ( <i>COPY</i> ) .....	7-53
7.4.1 Copy Individual Selection ( <i>COPYSEL</i> )(For Master Units Only) .....	7-54
7.4.2 Copy Batch Selection ( <i>CHKALL</i> )(For Master Units Only) .....	7-56
7.4.3 Copy Execution ( <i>COPYEXE</i> )(For Master Units Only) .....	7-57
7.4.4 Copy Lock ( <i>LOCK</i> )(For Slave Units Only) .....	7-58
7.5 Bank Settings ( <i>BANK</i> ) .....	7-59
7.5.1 Bank Save Selection ( <i>BANKSAT</i> ) .....	7-59
7.6 Calibration Settings ( <i>CALIB</i> ) .....	7-61
7.6.1 Calibration Selection ( <i>CALSEL</i> ) .....	7-61

# Setting up Extended Functions

This chapter explains the functions that can be newly set up when the display menu is changed from general functions to extended functions.

## 7.1 Setting Operation List


■ Setting mode selection



No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
1	Detection settings		-	-
2	Basic settings		-	-
3	Advanced settings (ADVANC)		This function allows you to specify more detailed settings such as hold settings and alarm settings.	7-9
4	Calculation settings (for master units only) (CALC)		This function can perform calculation processing based on the measured values of the connected controllers and display the judgment results in the display section of the master unit or output them from the master unit.	7-48
5	Copy settings (COPY)		This function can perform calculation processing based on the measured values of the connected controllers and display the judgment results in the display section of the master unit or output them from the master unit.	7-53
6	Bank settings (BANK)		This function allows you to save or load the HIGH set value, LOW set value, or other settings to/ from a specified bank (1 to 3).	7-59
7	Calibration settings (CALIB)		This function allows you to reduce installation errors when replacing the sensor head, for example.	7-61
8	Initialization (RESET)		-	-
9	Maintenance (MAINT)		-	-

<p>&lt;Reference&gt;</p> <ul style="list-style-type: none"> <li>● Pressing the ▢ key in each setting mode allows you to enter a function selection item.</li> <li>● For details on detection settings mode or basic settings mode, refer to “Chapter 6 Setting up General Functions”.</li> </ul>				
--	--	--	--	--

## ■ Function selection [Advanced settings]



No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
3	Advanced settings		-	-
3-a	Measurement mode (MEAS)		This function allows you to select a hold mode. <Default: S-H>	7-9
	Trigger mode (TRG)		This function allows you to select an action for external trigger input. HOLD/1SHOT <Default: HOLD>	7-9
3-b	Simultaneous input (for master units only) (ALL IN)		Setting simultaneous input in a master unit causes all the slave units connected to the master unit to enter the same input signal state as the master unit. <Default: ONE>	7-17
3-c	External input (EXT.IN)		This function allows you to select a combination of signals to be input to external input 1, input 2, and input 3 from five types. <Default: P/R/T>	7-18
3-d	External output (EXT.OUT)		This function allows you to select a combination of signals to be output from external output 1, output 2, and output 3 from four types. <Default: 3 VAL>	7-21
3-e	External output delay timer selection (OUT.DLY)		This function allows you to set an external output timer and external output delay timer. <Default: OFF>	7-27
	External output delay timer setting (OD.TIME)		This function allows you to set an external output delay timer when ON.DLY (ON delay), OFF.DLY (OFF delay), or SS.DTY (single shot delay) is selected. <Default: 100>	
3-f	Number of digits displayed (DIGIT)		This function allows you to switch the number of digits after the decimal point in the digital display section. <Default: 0.001>	7-31

## Setting up Extended Functions


No.	Item	Display screen	Function	Reference page
3-g	Analog scaling (ANALOG)		This function allows you to set scaling for analog output. <Default: DEFAULT>	7-32
	Upper limit value of scaling (ANA.HI)		This function allows you to set the upper limit value for scaling when analog scaling is set to "FREE". <Default: 10.000>	7-34
	Lower limit value of scaling (ANA.LO)		This function allows you to set the lower limit value for scaling when analog scaling is set to "FREE". <Default: 0.000>	
3-h	Eco mode (ECO)		This function allows you to turn OFF the backlight on the display unit of the controller to save electricity when the display unit is not used. <Default: OFF>	7-37
3-i	Alarm settings (ALARM)		This function allows you to set the number of delays that triggers alarm output. <Default: 1000>	7-39
			This function allows you to select either the held condition of the last measured value or alarm condition for the judgment output and measured value at the time of measurement alarm 1 occurrence. <Default: HOLD>	7-40
			This function judges the influence of stain on the detection surface according to the intensity of received light and outputs measurement alarm 2. <Default: LOW>	7-41
			This function allows you to set a stain threshold value when stain check is set to USER. <Default: 55>	
			This function checks the number of connected controllers and outputs an alarm when the number of connected controllers changes. <Default: OFF>	7-42
			This function outputs a measurement alarm when edge detection mode detects that the specified measurement direction differs from the insertion direction of the detected object. <Default: ON>	7-43
3-j	Key lock function selection (KEYLOC)		This function allows you to configure settings to activate key lock automatically. <Default: MANUAL>	7-44
3-k	Interference prevention function (for master units only) (INTF.PR)		This function allows you to install each sensor head close to each other. <Default: ON>	7-45
3-l	Sampling cycle (SAMPLI)		This function allows you to set the sampling cycle to standard sampling or high-speed sampling. <Default: HI-SPD>	7-47

### <Reference>

- The key operation (for the key) for returning to the setting mode selection screen also applies to the key.

# Setting up Extended Functions

■ Function selection [Calculation settings (for master units only)]




No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
4	Calculation settings (for master units only)		-	-
4-a	Calculation mode (MODE)		This function allows you to specify whether to perform calculations.  <Default: NO.CALC>	7-48
4-b	Calculation application selection (APPLI)		This function allows you to set calculation application selection when calculation mode is set to "CALC". You can select an application to be used for calculation.  <Default: MAX>	7-49

<Reference>  
The key operation (for the key) for returning to the setting mode selection screen also applies to the ☐ key.


---







- Function selection [Copy settings]

- Master unit



- Slave unit




No.	Item	Display screen	Function	Reference page
—	Initial screen		—	—
5	Copy setting		—	—
5-a	Copy individual selection (for master units only) (CPY.SEL)		This function allows you to select copy target items individually and copy them from the master unit to a slave unit.  <Default: NO.CALC>	7-54
5-b	Copy batch selection (for master units only) (CHK.ALL)		This function allows you to set calculation application selection when calculation mode is set to "CALC". You can select an application to be used for calculation.  <Default: MAX>	7-56
5-c	Copy execution (for master units only) (CPY.EXE)		This function allows you to copy the settings of copy individual selection or select all for copy from the master unit to a slave unit.  <Default: YES>	7-57
5-d	Copy lock (for slave units only) (LOCK)		This function allows you to prohibit copying from the master unit.  <Default: OFF>	7-58

<Reference>

The key operation (for the  $\triangle$  key) for returning to the setting mode selection screen also applies to the  $\square$  key.

## ■ Function selection [Bank settings]




No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
6	Bank settings		-	-
6-a	Bank save selection (BNK.DAT)		This function allows you to select the settings stored in the bank when loading them. <Default: THRS>	7-59




### <Reference>


The key operation (for the key) for returning to the setting mode selection screen also applies to the ☐ key.

# Setting up Extended Functions

## ■ Function selection [Calibration settings]



No.	Item	Display screen	Function	Reference page
-	Initial screen		-	-
7	Calibration settings		-	-
7-a	Calibration selection (CAL.SEL)		This function allows you to select a setting method for calibration.  <Default: DEFAULT>	7-61

<Reference>  
The key operation (for the  key) for returning to the setting mode selection screen also applies to the ☐ key.



## 7.2 Advanced Settings ( ADVANCE )

### 7.2.1 Hold Settings ( HOLD )

This function sets the method for holding a judgment value (JUDGE.V).  
To output normal measured values in real time, set the measurement mode to sample hold "S-H" and leave external inputs turned OFF.

#### ■ Measurement mode function ( MEAS )


This function allows you to select a hold mode from the following five types.

Measurement mode (MEAS)	Function	Reference page
Sample hold (S-H)	This function holds and outputs the judgment value (JUDGE.V) only when external input is ON. When external input is OFF, the judgment value (JUDGE.V) is updated as necessary before being output. (Real-time output)	7-11
Peak hold (P-H)	When external input is turned ON, the maximum value during the sampling period is held and output as the judgment value (JUDGE.V). When external input is turned OFF, the maximum value during the sampling period is continuously updated.	7-12
Bottom hold (B-H)	When external input is turned ON, the minimum value during the sampling period is held and output as the judgment value (JUDGE.V). When external input is turned OFF, the minimum value during the sampling period is continuously updated.	7-13
Peak-to-peak hold (P-P)	The difference between the maximum value and minimum value is held and output as the judgment value (JUDGE.V).	7-14
NG hold (NG-H)	This function holds LOW judgment and HIGH judgment output.	7-15

#### ■ External trigger input function

##### • Hold


If external trigger input turns ON, this function holds the judgment value (JUDGE.V) while the input is ON.



## Setting up Extended Functions

- One-shot

Each time external trigger input turns ON (a rising edge is reached), this function updates and holds the judgment value (JUDGE.V).



- Reset input function

When a reset signal is input, this function resets the measured values, judgment values, and other values that have been stored.


<Reference>

- If the calculation application selection function is set to "STAND" (standard difference), the hold settings of the master unit will be cleared.
- Depending on the settings of the calculation application selection function, the hold settings of the slave unit that are used for calculation will be cleared.

Sample hold

When external trigger input turns ON, the judgment value (JUDGE.V) is held. When external trigger input turns OFF, the hold state is released and returned to the state in which the judgment value is updated as necessary.

(Example of implementation)



Note: The above figure is an example of output when external output is set to 3-value "3VAL". In external output, judgment results are output according to the output settings.


# Setting up Extended Functions

## Peak hold

When external trigger input turns ON, the peak value during any sampling period is held as the judgment value (JUDGE.V). During the sampling period, the peak value is updated as necessary and used as the judgment value.

(Example of implementation)

Measurement mode	Trigger input mode
Peak hold	Hold input




Note: The above figure is an example of output when external output is set to 3-value "3VAL". In external output, judgment results are output according to the output settings.

## Bottom hold

When external trigger turns ON, the bottom value during any sampling period is held as the judgment value (JUDGE.V).

(Example of implementation)

Measurement mode	Trigger input mode
Bottom hold	Hold input




Note: The above figure is an example of output when external output is set to 3-value "3VAL". In external output, judgment results are output according to the output settings.

# Setting up Extended Functions

## Peak-to-peak hold

When external trigger input turns ON, the normal measured value (NORM.V) during any sampling period minus the value obtained by subtracting the bottom value from the peak value is held as the judgment value (JUDGE.V). During the sampling period, the value obtained by subtracting the bottom value from the peak value is updated as necessary.

(Example of implementation)




Note: The above figure is an example of output when external output is set to 3-value "3VAL". In external output, judgment results are output according to the output settings.

NG hold

This function holds judgment output when output is judged to be HIGH or LOW during the period specified by external trigger input (or the period during which TRIG input is OFF). [The judgment value waveform of NG hold has the same behavior as that of sample hold.] Reset input releases the hold state of the HIGH judgment value or LOW judgment value that is held. While TRIG input is ON, the judgment value (JUDGE.V) and judgment value are held. If HIGH is output once during a single output judgment period, LOW will not be output. Similarly, if LOW is output once during a single output judgment period, HIGH will not be output.

(Example of implementation)



Note: The above figure is an example of output when external output is set to 3-value "3VAL". In external output, judgment results are output according to the output settings.


## Setting up Extended Functions

### <Reference>

If the reset input function is used, the following respective behaviors occur when the external trigger input function is not used, when hold is selected for the external trigger input function, and one-shot is selected for the external trigger input function.


- When the external trigger input function is not used

When a reset signal is input, an indeterminate state occurs for the length of time equivalent to the average count (response time).




- When the external trigger input function is set to hold

If a reset signal is input when trigger input is ON, an indeterminate state occurs and judgment output is held. The indeterminate state is retained until trigger input turns OFF.



- When the external trigger input function is set to one-shot

If a reset signal is input with the judgment output held, an indeterminate state occurs and the judgment output remains held. The indeterminate state is retained until the next trigger input occurs.



For details on how to use the external trigger input function, refer to "7.2.3 External Inputs".




7.2.2 Simultaneous Input (ALL IN)(For Master Units Only)

Setting simultaneous input in a master unit has all the slave units connected to the master unit receive the same input signal as the master unit and perform behaviors according to the input settings of the master unit.


Simultaneous input	Function
Standalone (ONE)	External inputs for the master unit and slave units are performed separately. Slave units input external signals according to the settings of external input.
Simultaneous (ALL)(Note 1)	When the master unit receives an input, all the slave units connected to the master unit also receive the same input. The external input signal state of the master unit is reflected in the slave units, regardless of the external input signal state of each slave unit.

(Note 1): If simultaneous input is set, the minimum input time for trigger input is 3 ms or more.



<Reference>  
Simultaneous input can only be set for master units connected to slave units.

Setting method



Setting item	Set value	Default value
Simultaneous input (ALL IN)	Standalone (ONE) Simultaneous (ALL)	ONE

## Setting up Extended Functions

### 7.2.3 External Inputs (EXTIN)

This function allows you to select a combination of signals to be input to external input 1, input 2, and input 3 from five types.

- **Preset**  
You can perform zero-point adjustment and shift to any preset value.  
For details, refer to “5.5.2 Preset”.
- **Reset**  
When a reset signal is input, measured values, calculated values, and other values are reset.  
For details on how to use hold, refer to “7.2.1 Hold Settings”.
- **Trigger**  
If a trigger signal is input, the judgment value (JUDGE.V) is held while the signal is being input.  
For details, refer to “7.2.1 Hold Settings”.
- **Bank A / B**  
The contents of each bank can be read by combining bank A input and bank B input.  
For details on how to combine the inputs of each bank, refer to “5.5.3 Bank Mode”.
- **Laser emission stop**  
While a laser emission stop signal is being input, laser radiation is stopped.


External input setting combinations are shown below.

External input	Input signal combinations		
	Input 1 (Pink)	Input 2 (Purple)	Input 3 (Pink/Purple)
Preset/Reset/Trigger (P/R/T)	Preset	Reset	Trigger
Bank A/Bank B/Preset (BANK/P)	Bank A	Bank B	Preset
Bank A/Bank B/Reset (BANK/R)	Bank A	Bank B	Reset
Bank A/Bank B/Trigger (BANK/T)	Bank A	Bank B	Trigger
Preset/Trigger/Laser emission stop (P/T/L)	Preset	Trigger	Laser emission stop


#### • Minimum input time

The minimum input time and standby time differ according to the input type.


##### <Preset input>



##### <Reset input>




##### <Trigger input>




### <Bank A input/Bank B input>

#### ■ When bank 1 or bank 2 is used




Note: The minimum input time is 90 ms when "BNK.DAT" (bank save selection) is set to "ALL".

#### ■ When bank 3 is used



Note: If the start of bank A input or bank B input is delayed by 8 ms or more, the content of bank 3 may be read after read processing for the input signal that is input earlier is executed.

### <Laser emission stop input>



Note: The laser radiation indicator (green) of the sensor head emitter remains unlit while a laser emission stop signal is being input.

If beam axis adjustment mode is invoked with the laser emission stop signal set to ON, "E510" will be displayed in the digital display section of the controller.


While laser emission remains stopped, "-----" is displayed indicating an indeterminate state.

#### <Reference>

- For I/O circuit diagrams for controllers, refer to "8.1.1 Controller".
- For details on simultaneous input, refer to "7.2.2 Simultaneous Input (For Master Units Only)".

# Setting up Extended Functions





## Setting method



Setting item	Set value	Default value
External input (EXT.IN)	Preset/Reset/Trigger (P/R/T) Bank A/Bank B/Preset (BANK/P) Bank A/Bank B/Reset (BANK/R) Bank A/Bank B/Trigger (BANK/T) Preset/Trigger/Laser emission stop (P/T/L)	P/R/T

### 7.2.4 External Outputs (EXTOUT)

This function allows you to select a combination of signals to be output from external output 1, output 2, and output 3 from four types. This product is equipped with an alarm signal output function. When the sensor head does not operate correctly, alarm signals enable you to take prompt action.

Set value	Display	Function
3-value		This function uses OUT1, OUT2, and OUT3 to control ON/OFF according to the judgment value.
2-value		This function uses OUT1 and OUT2 to control ON/OFF according to the judgment value. OUT3 is used to control ON/OFF when an alarm (error) occurs.
Logic		This function uses OUT1 and OUT2 to control ON/OFF as logical value representation according to the judgment value. OUT3 is used to control ON/OFF when an alarm (error) occurs.
Logic 2		OUT1 is used to control ON/OFF when all the connected controllers are in GO state. OUT2 is used to control ON/OFF when the master unit is in GO state. OUT3 is used to control ON/OFF when an alarm (error) occurs on any of the connected controllers.

#### <Reference>


- You must set judgment output operation to N.O. or N.C. For details, refer to "6.4.10 Output Operation". Default: N.O. (Normally Open)
- For each alarm output when external output is set to "2-value", "Logic", or "Logic 2", output operation is "Normally Closed" (N.C.) regardless of the set value of output operation.
- Alarm output is generated when an error or alarm occurs.  
For details on errors, refer to "10.2 Error Messages".  
Alarms are classified into measurement alarm 1 and measurement alarm 2.

Alarm type	Description	Measured value	Judgment output
Measurement alarm 1	This alarm occurs when the intensity of received light is saturated due to ambient light or when an edge exceeding the measurement capability occurs.	Previous value or ALARM (optional)	Judgment output based on the previous value or alarm output (optional)
Measurement alarm 2	This alarm occurs when stain check is activated.	Measured value	Alarm output

For details on how to set an alarm, refer to "7.2.9 Alarm Settings".

# Setting up Extended Functions

## ■ 3-value



<When N.O. is set>


Output operation		Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1	HIGH	OFF	OFF	OFF	ON	ON
Output 2	GO	OFF	OFF	ON	OFF	OFF
Output 3	LOW	OFF	ON	OFF	OFF	ON

< When N.C. is set>

Output operation		Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1	HIGH	ON	ON	ON	OFF	OFF
Output 2	GO	ON	ON	OFF	ON	ON
Output 3	LOW	ON	OFF	ON	ON	OFF

3-value output does not have alarm-specific output. Judgments can be made according to the logical judgment of 3-value.

## ■ 2-value



<When N.O. is set>

Output operation		Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1	HIGH/LOW	OFF	ON	OFF	ON	ON
Output 2	GO	OFF	OFF	ON	OFF	OFF
Output 3	Alarm	ON	ON	ON	ON	OFF


< When N.C. is set>

Output operation		Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1	HIGH/LOW	ON	OFF	ON	OFF	OFF
Output 2	GO	ON	ON	OFF	ON	ON
Output 3	Alarm	ON	ON	ON	ON	OFF

2-value output has alarm-specific output.

# Setting up Extended Functions

## ■ Logic



<When N.O. is set>

Output operation		Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1	Judgment 1	OFF	ON	OFF	ON	ON
Output 2	Judgment 2	OFF	OFF	ON	ON	ON
Output 3	Alarm	ON	ON	ON	ON	OFF





< When N.C. is set>

Output operation		Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1	Judgment 1	ON	OFF	ON	OFF	OFF
Output 2	Judgment 2	ON	ON	OFF	OFF	OFF
Output 3	Alarm	ON	ON	ON	ON	OFF

Logical output has alarm-specific output. (Output 3) Furthermore, logical output makes LOW/HIGH identifiable in logical operation of judgment 1 and judgment 2.



## ■ Logic 2

External output	Output operation			Display 
	OUT1	OUT2	OUT3	
Logic 2 	ALL GO (All connected controllers)	GO (Master unit)	Alarm (Any of connected controllers)	ON OFF  ON OFF 

<When N.O. is set>

Output operation	Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1 ALL GO	OFF	OFF	ON (Note 1)	OFF	ON
Output 2 GO	OFF	OFF	ON (Note 2)	OFF	ON
Output 3 Alarm	ON	ON	ON	ON	OFF (Note 3)

Notes: 1) Turns ON when all the connected controllers are in GO state.

2) Turns ON when the master unit is in GO state.

3) Turns OFF when an alarm (error) occurs on any of the connected controllers.

< When N.C. is set>


Output operation	Indeterminate	Below the lower limit of measurement range	Within GO range	Above the upper limit of measurement range	Alarm
Output 1 ALL GO	ON	ON	OFF (Note 1)	ON	ON
Output 2 GO	ON	ON	OFF (Note 2)	ON	ON
Output 3 Alarm	ON	ON	ON (Note 3)	ON	OFF (Note 3)

Notes: 1) Turns OFF when all the connected controllers are in GO state.

2) Turns OFF when the master unit is in GO state.


3) Turns OFF when an alarm (error) occurs on any of the connected controllers.

\_\_\_\_\_



	3-value	2-value	Logic	Logic 2
Output 1 indicator	HIGH	HIGH/LOW	Judgment 1	ALL GO
Output 2 indicator	GO	GO	Judgment 2	GO
Output 3 indicator	LOW	Alarm	Alarm	Alarm

---



Setting item	Set value	Default value
External output (EXT.OUT)	3-value (3 VAL) 2-value (2 VAL) Logic (LOGIC) Logic 2 (LOGIC2)	3 VAL

## 7.2.5 External Output Delay Timer Selection (OUT.DLY)

This function allows you to set an external output timer and external output delay timer.

Simultaneous input	Function
No timer (OFF)	The timer is set to OFF.
ON delay (ON.DLY)	The behavior required for GO judgment output of external output to change from OFF to ON is delayed by the time set in the external output delay timer. (External output delay timer: 1 to 9,999 ms)
OFF delay (OFF.DLY)	The behavior required for GO judgment output of external output to change from ON to OFF is delayed by the time set in the external output delay timer. (External output delay timer: 1 to 9,999 ms)
Single shot delay (SS.DTY)	When GO judgment output of external output turns ON, GO judgment output is forcibly turned OFF after the time set in the external output delay timer has elapsed. (External output delay timer: 1 to 9,999 ms)


<External output>

Set value	3-value	2-value	Logic	Logic 2
External output delay timer selection	Enabled	Enabled	Disabled	Enabled

<Reference>


- When "EXT.OUT" (external output) is set to "LOGIC", "OUT.DLY" (external output delay timer selection) is disabled.
- For details on "EXT.OUT" (external output), refer to "7.2.4 External Outputs".

### ■ No timer (OFF)




# Setting up Extended Functions

## ■ ON delay (ON.DLY)



## ■ OFF delay (OFF.DLY)





(\*1): The arrows (  $\longleftrightarrow$  ) shown in the above figure indicate the time set in the external output delay timer.

■ Single shot delay (SS.DTY)

When the external output delay timer setting is shorter than the elapsed time of GO judgment output


When the external output delay timer setting is longer than the elapsed time of GO judgment output



(\*1): The arrows (  ) shown in the above figure indicate the time set in the external output delay timer.

# Setting up Extended Functions

## Setting method




Setting item	Set value	Default value
External output delay timer selection (OUT.DLY)	No timer (OFF) ON delay (ON.DLY) OFF delay (OFF.DLY) Single shot delay (SS.DLY)	OFF

Setting item	Set value	Default value
External output delay timer setting (OD.TIME)	1 to 9999 (ms)	100

7.2.6 Number of Digits Displayed ( DIGIT )


This function allows you to switch the number of digits after the decimal point in the digital display section.



<Reference>

- Digital numbers are displayed right-justified, regardless of the specified number of digits displayed.
- Any numbers after the specified number of digits displayed are displayed in rounddown calculations.

Setting method



Setting item	Set value	Default value
Number of digits displayed (DIGIT)	Three digits after the decimal place (0.001) Two digits after the decimal place (0.01) One digit after the decimal place (0.1)	0.001

<Reference>

Changing the number of digits displayed has no influence on judgment output and measured values read through communication.

# Setting up Extended Functions


## 7.2.7 Analog Scaling ( ANALOG )

This function allows you to select default (DEFAULT) or free (FREE) for scaling of analog output. If you set free (FREE), you can select the method for setting the upper and lower limit values for scaling of analog output.

Analog scaling	Function
DEFAULT (default)	Analog current is output according to the maximum measurement width of the sensor head.
FREE (free)	The upper and lower limit values of analog output can be set to any desired values. For details on how to set the upper and lower limit values, refer to "Upper and lower limit values for scaling".


### ■ When "DEFAULT" (default) is set

The upper limit value is the maximum measurement width of the sensor head to be used. The lower limit value is "0.000", regardless of the sensor head.



### ■ When "FREE" (free) is set

For details on how to set the upper and lower limit values, refer to "Upper and lower limit values for scaling".





## Setting up Extended Functions

### ■ Analog voltage/current output specifications

Analog voltage/current output specifications are common to "DEFAULT" (default) and "FREE" (free) settings.


- When the voltage output range is 1 to 5 V
- When the current output range is 4 to 20 mA

Voltage output range	1 to 5 V
Resolution	0.1 mV
Alarm output (Note)	5.2 V
Error output	5.2 V
Indeterminate state	1 V
Linearity	±0.05% F.S.
Output resistance	100Ω max.

Current output range	4 to 20 mA
Resolution	0.3 μA
Alarm output (Note)	0 mA
Error output	0 mA
Indeterminate state	0 mA
Linearity	±0.25% F.S.
Maximum load impedance	250Ω max.

Note: If the set value of "ALM.CND" (alarm condition selection) is held by measurement alarm 1, when alarm 1 occurs, alarm output depends on the state of the measured value that is held when the alarm occurs.

### Setting method



Setting item	Setting range	Default value
ANALOG (analog scaling)	DEFAULT (default) FREE (free)	DEFAULT


## Setting up Extended Functions

### ■ Upper and lower limit values for scaling ( *ANAL1 / ANAL0* )


If "ANALOG" (analog scaling) is set to "FREE", you can set the upper and lower limit values for scaling to any desired values. After setting the upper limit value for scaling, set the lower limit value for scaling.

- When the lower limit value for scaling is smaller than the upper limit value for scaling

Analog voltage output




Analog current output




- When the lower limit value for scaling is greater than the upper limit value for scaling

Analog voltage output




Analog current output




- When the lower limit value for scaling is equal to the upper limit value for scaling

Analog voltage output




Analog current output



Setting method


- Setting the upper limit value for scaling



Setting item	Setting range	Default value
ANA.HI (upper limit value of scaling)	-199.999 to 199.999 (mm)	10.000

# Setting up Extended Functions

- Setting the lower limit value for scaling



Setting item	Setting range	Default value
ANA.LO (lower limit value of scaling)	-199.999 to 199.999 (mm)	0.000

## 7.2.8 Eco Mode (ECO)

This function allows you to turn OFF the backlight on the display section of the controller to save electricity when the display section is not used.


If Eco mode is set to ON, the backlight on the display section will go out when no key is operated for 30 seconds.

If you press any key when the backlight on the display section is unlit, the backlight will light up.

### <Reference>

- If an error occurs when the backlight is unlit, the backlight will light up.
- While an error is being displayed, the backlight does not go out.

### Setting method



Setting item	Setting range	Default value
ECO (Eco mode)	OFF (Eco OFF) Eco ON (ON)	OFF

## Setting up Extended Functions

### 7.2.9 Alarm Settings (ALARM)

This function allows you to specify whether to detect alarms and to set alarm detection conditions.

Alarms are divided into two types (measurement alarm 1 and measurement alarm 2).

Measurement alarm 1 occurs when the sensor head becomes unable to make measurements. This alarm occurs when an edge exceeding the measurement capability occurs or when the intensity of received light is saturated due to ambient light.

Measurement alarm 2 occurs when the sensor head becomes dirty, when the number of connected controllers is changed, or when the specified measurement direction differs from the insertion direction of the detected object. (Each function can be set to ON or OFF.) Digital measured values are output directly as measured values. However, they are reflected in judgment output.

Alarm type	Description	Measured value	Judgment output
Measurement alarm 1	This alarm occurs when the intensity of received light is saturated due to ambient light or when an edge exceeding the measurement capability occurs.	Previous value OR ALARM (optional)	Judgment output based on the previous value OR alarm output (optional)
Measurement alarm 2	Measurement alarm 2 occurs when the sensor head becomes dirty, when the specified measurement direction differs from the insertion direction of the detected object.	Measured value	Alarm output

- Alarm setting items

Alarm settings have the following items.


Alarm settings	Function	Alarm type
Alarm delay count (DELAY)	This function allows you to set the number of delays that triggers alarm output.	Measurement alarm 1 Measurement alarm 2
Alarm condition selection (ALM.CND)	This function allows you to select either the held condition or alarm condition of the last measured value for the output and display at the time of alarm occurrence.	Measurement alarm 1
Stain check (STA.CHK)	This function judges the influence of stain on the detection surface according to the intensity of received light and outputs an alarm.	Measurement alarm 2
Connected units count check (CON.CHK)	This function allows you to check the number of connected controllers.	E160 (Note)
Reverse insertion check (DIR.CHK)	This function outputs an alarm when the specified measurement direction differs from the insertion direction of the detected object.	Measurement alarm 2

Note: This function is included in the alarm settings, but error code "E160" is displayed. (No alarm is output.)

## ■ Alarm delay count

This function allows you to set the number of delays that triggers alarm output. While an alarm is being delayed, the last measured value is held.

### Setting method



Note: If you press the Enter key when the alarm delay count is outside the setting range, "\*\*\*\*\*" will be displayed in the digital display / MAIN (white), indicating an error.


Setting item	Setting range	Default value
Alarm delay count (DELAY)	1 to 1000	1000

# Setting up Extended Functions

## ■ Alarm condition selection

This function allows you to select either the held condition or alarm condition of the last normal measured value (NORM.V) for the measured value at the time of measurement alarm 1 occurrence. If you do not use measurement alarm 1, select "HOLD" (Hold last value). External output changes according to the measured value.

### Setting method



Setting item	Setting range	Default value
Alarm condition selectionA (LM.CND)	Hold last value (HOLD) Alarm output (ALARM)	HOLD





# Setting up Extended Functions


## ■ Connected units count check (for master units only)

This function checks the number of connected controllers and outputs an alarm when the number of connected controllers changes.

If the actual number of connected controllers changes from the number of connected controllers that exist when "CON.CHK" (Connected units count check) is set to ON, error "E160" will be output.

When changing the number of connected controllers, first set "CON.CHK" (Connected units count check) to OFF, change the number of connected controllers, and then set "CON.CHK" (Connected units count check) to ON again.

### Setting method




Setting item	Setting range	Default value
Connected units count check (CON.CHK)	Check OFF (OFF) Check ON (ON)	OFF

<Reference>  
 "CON.CHK" (Connected units count check) can only be set for master units.

## ■ Reverse insertion check

This function outputs measurement alarm 2 when the specified measurement direction differs from the insertion direction of the detected object.

### Setting method



Setting item	Setting range	Default value
Reverse insertion check (DIR.CHK)	Check ON (ON) Check OFF (OFF)	ON

#### <Reference>


"DIR.CHK" (Reverse insertion check) takes effect only when the operation mode is set to edge detection mode (EDGE) or central position detection mode (CEN.POS).

# Setting up Extended Functions

## 7.2.10 Key Lock Function Selection ( KEYLOC )

This function allows you to configure settings to activate key lock automatically when five minutes have elapsed since key operation was performed last time.  
The unlocking method for automatic key lock is the same as for manual key lock.

### Setting method




Setting item	Set value	Default value
Key lock (KEYLOC)	Manual (MANUAL) Automatic (AUTO)	MANUAL

<Reference>


- Time counting starts when "AUTO" is set.  
If any of all the keys to be used is pressed even once, the elapsed time count will be cleared and then time counting will start again.
- For details on how to set manual key lock, refer to "5.5.4 Key Lock".

7.2.11 Interference Prevention Function ( *INTFPR* )(For Master Units Only)

This function has the controller prevent interference caused by light going around among sensor heads. The function works among four connected controllers.




Example: Positioning a glass plate



# Setting up Extended Functions

## Setting method



Setting item	Set value	Default value
Interference prevention function (INTF.PR)	Interference prevention function ON (ON) Interference prevention function OFF (OFF)	ON


7.2.12 Sampling Cycle ( SAMPLI )

This function enables the sampling cycle to be changed according to the moving speed of the object.

Selecting "NORMAL" (standard sampling) enables measurement to be less influenced by the surrounding environment

Sampling cycle	Function
High-speed sampling (HI-SPD)	The sampling cycle is set to 0.5 ms.
Standard sampling (NORMAL)	The sampling cycle is set to 1 ms.

Setting method



Setting item	Setting range	Default value
Sampling cycle (SAMPLI)	Standard sampling (NORMAL) High-speed sampling (HI-SPD)	HI-SPD

<Reference>

- If "HI-SPD" (high-speed sampling) is used, measurement will be more influenced by ambient light.
  - If "NORMAL" (standard sampling) is used, response time will become slower.
- For details on response time, refer to "6.3.3 Average Count (Response Time)".

# Setting up Extended Functions

## 7.3 Calculation Settings ( CALC )(For Master Units Only)

This function can perform calculation processing based on the measured values of the connected controllers and display the judgment results in the digital display section of the master unit or output them from the master unit.

<Reference>


- When performing calculation settings, be sure to connect slave units to the master unit.  
If no slave unit is connected to the master unit, "MODE" (calculation mode) and "APPLI" (calculation application selection) will not be displayed.
- The calculation setting menu is only displayed for master units.

### 7.3.1 Calculation Mode ( MODE )

In calculation mode, you can specify whether to perform calculations.

Calculation mode	Function
No calculation (NOCALC)	Each slave unit connected to the master unit can be operated individually without performing calculations.
Calculation execution (CALC)	This function can use the specified application to perform calculation processing for the measured values of the master unit and the slave units connected to it and display the judgment results in the display section of the master unit or output them from the master unit.

#### Setting method



Setting item	Set value	Default value
Calculation mode (MODE)	No calculation (NO.CALC) Calculation execution (CALC)	NO.CALC



### 7.3.2 Calculation Application Selection ( *APPL I* )


When "MODE" (calculation mode) is set to "CALC", this function allows you to set calculation application selection.

You can select an application to be used for calculation.

The function of each application is described in the following table.

Application	Function	Number of slave units required
Maximum value (MAX)	The maximum value of the measured values of the connected controllers is used as the calculated value.	At least one unit
Minimum value (MIN)	The minimum value of the measured values of the connected controllers is used as the calculated value.	At least one unit
Average value (AVERAG)	The value obtained by dividing the sum of the measured values of the connected controllers by the number of controllers is used as the calculated value. [Calculated value] = ([Master unit] + [Slave unit 1] + ... + [Slave unit n]) ÷ (1 + n)	At least one unit
Standard difference (STAND)	The measured value of each connected slave unit and the measured value (used as the base) of the master unit are calculated. The value obtained by subtracting the measured value of the master unit from the measured value of each slave unit is used as the calculated value. The calculated value is output from each slave unit. [Calculated value] = [Slave unit n] - [Master unit]	At least one unit
Thickness/width (THICK)	The value obtained by adding the measured values of the master unit and slave unit to the measured object is used as the calculated value. [Calculated value] = [Master unit] + [Slave unit 1]	One unit

The CALC status mark is lit on the controller that is performing calculations.




#### <Reference>

If "THICK" (thickness/width) is selected, when the number of connected slave units is greater than the specified number, the slave unit nearest the master unit is used for calculation. Other slave units are not used for calculation.

# Setting up Extended Functions


## Setting method



Setting item	Set value	Default value
Application (APPLI)	Maximum value (MAX) Minimum value (MIN) Average value (AVERAG) Standard difference (STAND) Thickness / width (THICK)	MAX

## Maximum value ( MAX )


The largest measured value of the measured values of the master unit and slave units is used as the calculated value.



- None of the connected slave units outputs judgment results. (Always OFF)
- The response time for judgment output is the respective response times of the master unit and slave unit plus 3 ms.
- The judgment value (JUDGE.V) (calculation result) is displayed in the digital display / MAIN (white) of the master unit. The normal measured value (NORM.V) is displayed in the digital display / MAIN (white) of the slave unit.

### ■ Minimum value ( $MIN$ )

The smallest measured value of the measured values of the master unit and slave units is used as the calculated value.




The minimum measured value of the master unit is used as the calculated value of the master unit.

- None of the connected slave units outputs judgment results. (Always OFF)
- The response time for judgment output is the respective response times of the master unit and slave unit plus 3 ms.

### ■ Average value ( $AVERAG$ )

The average value of the measured values of the master unit and slave units is used as the calculated value.



$$([Master\ unit] + [Slave\ unit\ 1] + \dots + [Slave\ unit\ n]) \div (1 + n)$$
 is used as the calculated value of the master unit.  
Where, n is the number of slave units


- None of the connected slave units outputs judgment results. (Always OFF)
- The response time for judgment output is the respective response times of the master unit and slave unit plus 3 ms.

## Setting up Extended Functions

- Standard difference (STAND)

For each slave unit, the difference between the measured value of the master unit and that of the slave unit is used as the calculated value.


This application causes each slave unit to output judgment results.



- The master unit performs judgment operations as a single unit that does not perform calculations.
- The master unit cannot use the hold function.
- The response time for judgment output is the respective response times of the master unit and slave unit plus 3 ms.

- Thickness/width (*THICK*)

A measured object is placed between two sensor heads to calculate the thickness or width of the object.



- The slave unit nearest the master unit does not output judgment results. (Always OFF)  
If two or more slave units are connected, the second and subsequent slave units make normal judgments without performing calculations.


- The response time for judgment output by the master unit is the respective response times of the master unit and slave unit plus 3 ms.

<Reference>

Application settings can be selected when at least one slave unit is connected.

### 7.4 Copy Settings (COPY)

The settings on the master unit can be copied to the slave units connected to the master unit. Settings to be copied from the master unit to the slave units can be selected individually. You can also select all the settings at the same time. When "CPY.EXE" (copy execution) for the master unit is enabled (set to "YES"), copy is executed if you press the ENTER key.



<Reference>

- You cannot copy the settings stored in banks.
- Slave units are equipped with a function that prohibits copying from the master unit. For details on copy lock, refer to "7.4.4 Copy Lock (For Slave Units Only)".

# Setting up Extended Functions

## 7.4.1 Copy Individual Selection ( $\overline{CPYSEL}$ )(For Master Units Only)

This function allows you to select copy target items individually and copy them from the master unit to a slave unit.

- Copy target items

Settings	Item
Detection settings (DETECT)	Operation mode (OP.MODE)
	Measurement direction (DIRECT)
Basic settings (BASIC)	HIGH set value (HI.SET)
	LOW set value (LO.SET)
	Hysteresis (HYSTER)
	Teaching type (TEACH)
	Tolerance < $\pm$ >(TOL< $\pm$ >)
	Preset value (PR.VAL)
	Preset data selection (PR.OBJ)
	Preset save (PR.SAVE)
	Reference waveform save (BW.SAVE)
	Average count (response time)(SPEED)
	Output operation (OUTPUT)
	Analog output selection (A/O.SEL)
Advanced settings (ADVANC)	Hold settings (HOLD)
	External input (EXT.IN)
	External output (EXT.OUT)
	External output delay timer selection (OUT.DLY)
	Number of digits displayed (DIGIT)
	Eco mode (ECO)
	Alarm settings (ALARM)
	Key lock function selection (KEYLOC)

- Display of copy target items


Tick marks are displayed for the items that are specified as copy targets on the basic settings (BASIC) or advanced settings (ADVANC) screen.



<Reference>

- Executing "CHK.ALL" (copy batch selection) selects all the copy target items as copy targets.
- You can use the preset key to individually select basic settings (BASIC) or advanced settings (ADVANC) items that are to be copied or not to be copied.

## Setting method



Setting item	Set value		Default value
Copy individual selection (CPY.SEL)	OP.MODE (Operation mode):	YES/NO	YES
	DIRECT (Measurement direction):	YES/NO	YES
	SPEED (Average count (response time)):	YES/NO	YES
	HI.SET (HIGH set value):	YES/NO	YES
	LO.SET (LOW set value):	YES/NO	YES
	HYSTER (Hysteresis):	YES/NO	YES
	TEACH (Teaching type):	YES/NO	YES
	TOL<±> (Tolerance <±>):	YES/NO	YES
	PR.VAL (Preset value):	YES/NO	YES
	PR.OBJ (Preset data selection):	YES/NO	YES
	PR.SAVE (Preset save):	YES/NO	YES
	BW.SAVE (Reference waveform save):	YES/NO	YES
	OUTPUT (Output operation):	YES/NO	YES
	A/O.SEL (Analog output selection):	YES/NO	YES
	HOLD (Hold settings):	YES/NO	YES
	EXT.IN (External input):	YES/NO	YES
	EXT.OUT (External output):	YES/NO	YES
	OUT.DLY (External output delay timer selection):	YES/NO	YES
	DIGIT (Number of digits displayed):	YES/NO	YES
	ECO (Eco mode):	YES/NO	YES
	ALARM (Alarm settings):	YES/NO	YES
	KEYLOC (Key lock function selection):	YES/NO	YES


# Setting up Extended Functions

## 7.4.2 Copy Batch Selection (CHK.ALL)(For Master Units Only)

This function allows you to select all copy target items at the same time.

<Reference>  
Even if you set a particular item to "NO" (no execution) in "CPY.SEL" (copy individual selection), that item will not be removed from the copy target items if you select the item as a copy target item.

### Setting method




Setting item	Set value	Default value
Copy batch selection (CHK.ALL)	Select all for copy (YES) Do not select all for copy (NO)	YES



7.4.3 Copy Execution (CPY.EXE)(For Master Units Only)

This function allows you to copy the settings of "CPY.SEL" (copy individual selection) or "CHK. ALL" (copy batch selection) from the master unit to a slave unit.


Setting method



Setting item	Set value	Default value
Copy execution (CPY.EXE)	Execute (YES) Do not execute (NO)	YES

<Reference>

When copy is executed, "NOW" appears in the digital display section / SUB (green), and "COPY" appears in the digital display section / MAIN (white).




# Setting up Extended Functions

## 7.4.4 Copy Lock ( LOCK )(For Slave Units Only)

Copy lock can only be set for slave units.  
Setting copy lock to a slave unit allows you to prohibit copying from the master unit to that slave unit.

### Setting method



Setting item	Set value	Default value
Copy lock (LOCK)	Copy lock OFF (OFF) Copy lock ON (ON)	OFF

<Reference>

On the slave unit for which copy lock is set, while copy is being executed, "COPY" appears in the digital display section / SUB (green), and "LOCK" appears in the digital display section / MAIN (white).

Slave unit (Copy lock OFF)		→	Copy in progress	→	Copy completed
Slave unit (Copy lock ON)					
Master unit		→	Copy in progress	→	Copy completed


Finalize

7.5 Bank Settings ( BANK )

This function allows you to select the settings stored in the bank when loading them.

7.5.1 Bank Save Selection( BANK.BAT )

This function allows you to select the settings to be read from or written to the bank.




Bank save selection	Function
HIGH set value and LOW set value (THRS)	Selects the HIGH set value and LOW set value
HIGH set value, LOW set value, preset value, sensitivity adjustment, judgment level, and judgment filter (THRS.PR)	Selects the HIGH set value, LOW set value, preset value, sensitivity adjustment, judgment level, and judgment filter.
All items (ALL)	Selects all items

<Reference>

- The settings that have been read from the bank will be retained even if the power is turned OFF.
- For details on how to perform write and read operations, refer to ""5.5.3 Bank Mode"".

# Setting up Extended Functions

## Setting method



Setting item	Set value	Default value
Bank save selection (BNK.DAT)	HIGH set value and LOW set value (THRS) HIGH set value, LOW set value, preset value, sensitivity adjustment, judgment level, and judgment filter (THRS.PR) All items (ALL)	THRS

## 7.6 Calibration Settings (CALIB)

### 7.6.1 Calibration Selection (CALSEL)


This function allows you to reduce installation errors when replacing the sensor head, for example.

Calibration settings	Set value	Function
Calibration selection (CAL.SEL)	Default (DEFAULT)	Calibration is reset to the factory default state.
	User settings (USER)	Calibration is executed according to the preset value and span is corrected.
	Measured value 1 (CL.SET1)	For span adjustment, the measured object is moved to target point 1 and measured value 1 is obtained.
	Adjusted value 1 (AJ.VAL1)	A target value for measured value 1 is numerically input.
	Measured value 2 (CL.SET2)	For span adjustment, the measured object is moved to target point 2 and measured value 2 is obtained.
	Adjusted value 2 (AJ.VAL2)	A target value for measured value 2 is numerically input.

#### <Reference>

- In the following cases, calibration cannot be executed. "ERROR" is displayed in the digital display section / MAIN (white).
  - The magnitude relation between the target value and the measured value does not match (the signs of the target value and measured value do not match).
  - As a result of span adjustment, the adjusted magnification exceeds twice the factory default span.
  - The measured value is in an indeterminate state ("-----" displayed).
  - The measured value is outside the measurement range ("OVER" or "-OVER" displayed).
  - The measured value is in an alarm or error state.

#### Setting method




Setting item	Set value	Default value
Calibration selection (CAL.SEL)	Default (DEFAULT)	DEFAULT
	User settings (USER)	


## Setting up Extended Functions

- When "USER" (user settings) is set

If you set "USER" (user settings), you must set the following four values in the figure below: Measured value 1 (CL.SET1), adjusted value 1 (AJ.VAL1), measured value 2 (CL.SET2), and adjusted value (AJ.VAL2).




1. Select "USER" (user settings) and press the key.









2. "CL.SET1" (measured value 1) appears in the digital display section / SUB (green), and "-----" appears in the digital display section / MAIN (white).



3. Insert the measured object between the emitter and receiver of the sensor head, and press the key when the object is at any desired position.





- 4.** Enter adjusted value 1 (AJ.VAL1). After entering the value, press the  key.  
 LEFT/RIGHT arrow keys (  /  ): Move the digit  
 UP/DOWN arrow keys (  /  ): Change the numerical value




Setting item		Set value	Default value
User settings (USER)	Adjusted value 1 (AJ. VAL1)	-199.999 to 199.999 (mm)	0.000






- 5.** "CL.SET2" (measured value 2) appears in the digital display section / SUB (green), and "....." appears in the digital display section / MAIN (white).




- 6.** Insert the measured object between the emitter and receiver of the sensor head, and press the  key when the object is at any desired position.




# Setting up Extended Functions

- 7.** Enter adjusted value 2 (AJ.VAL2). After entering the value, press the  key.  
LEFT/RIGHT arrow keys (  /  ): Move the digit  
UP/DOWN arrow keys (  /  ): Change the numerical value



Setting item		Set value	Default value
User settings (USER)	Adjusted value 2 (AJ.VAL2)	-199.999 to 199.999 (mm)	10.000

- 8.** If a measured value is obtained correctly, " GOOD " will be displayed and then the display will be automatically returned to the calibration selection screen.





# Chapter 8

## Specifications and Dimensions

---

- 8.1. Specifications .....8-2
  - 8.1.1 Controller..... 8-2
  - 8.1.2 Sensor Head ..... 8-8
- 8.2. Dimension Drawings .....8-9
  - 8.2.1 Controller..... 8-9
  - 8.2.2 Sensor Head ..... 8-11
  - 8.2.3 Side View Attachment ..... 8-12

## Specifications and Dimensions

### 8.1. Specifications

#### 8.1.1 Controller

Type		Master unit	Slave unit		
		High-performance type		Wire-saving type	
Model No.	NPN output	HG-TC101	HG-TC111	HG-TC113	
	PNP output	HG-TC101-P	HG-TC111-P		
Number of connectable units		Up to 15 slave units can be connected to a master unit. (Up to 14 slave units can be connected if a communication unit is connected.)			
Supply voltage		24VDC $\pm 10\%$ , including 0.5V ripple (P-P)			
Current consumption (Note 2)		100mA or less (when sensor head is connected)			
Analog output (Switching type) (Note 3)	Analog voltage output	<ul style="list-style-type: none"><li>• Voltage output range: 1 to 5V / F.S. (default value)</li><li>• Output when alarm occurs: 5.2V</li><li>• Linearity: <math>\pm 0.05\%</math> F.S.</li><li>• Output impedance: 100<math>\Omega</math> max.</li></ul>		—	
	Analog current output	<ul style="list-style-type: none"><li>• Current output range: 4 to 20mA / F.S. (default value)</li><li>• Output when alarm occurs: 0mA</li><li>• Linearity: <math>\pm 0.25\%</math> F.S.</li><li>• Load impedance: 250<math>\Omega</math> max.</li></ul>		—	
Control output (Output 1 / Output 2 / Output 3)		<NPN output type> NPN open-collector transistor <ul style="list-style-type: none"><li>• Maximum sink current: 50mA (Note 4)</li><li>• Applied voltage: 30VDC or less (between output and 0V)</li><li>• Residual voltage: 1.5V or less (at 50mA sink current)</li><li>• Leakage current: 0.1mA or less</li></ul> <PNP output type> PNP open-collector transistor <ul style="list-style-type: none"><li>• Maximum source current: 50mA (Note 4)</li><li>• Applied voltage: 30VDC or less (between output and +V)</li><li>• Residual voltage: 1.5V or less (at 50mA source current)</li><li>• Leakage current: 0.1mA or less</li></ul>		—	
		Short-circuit protection			Incorporated (automatic reset type)
		Judgment output			N.O. / N.C switching type
		Alarm output			Open when alarm occurs
External output switching		Output 1, Output 2, and Output 3 can be switched to 3-value, 2-value, Logic, and Logic 2.		—	
External input (Input 1 / Input 2 / Input 3)		<NPN output type> Non-contact input or NPN open-collector transistor <ul style="list-style-type: none"><li>• Input conditions<ul style="list-style-type: none"><li>Invalid: +8V to +VDC or open</li><li>Valid: 0 to +1.2VDC</li></ul></li><li>• Input impedance: Approx. 10k<math>\Omega</math></li></ul> <PNP output type> Non-contact input or PNP open-collector transistor <ul style="list-style-type: none"><li>• Input conditions<ul style="list-style-type: none"><li>Invalid: 0 to +0.6VDC or open</li><li>Valid: +4 V to +VDC</li></ul></li><li>• Input impedance: Approx. 10k<math>\Omega</math></li></ul>		—	
		Trigger input			Input time: 2ms or more (ON)
		Laser emission stop input			Input time: 20ms or more (ON)
		Preset input			Input time: 20ms or more (ON)
		Reset input			Input time: 20ms or more (ON)
		Bank input A / B			Input time: 20ms or more (ON)

## Specifications and Dimensions

Type		Master unit	Slave unit	
		High-performance type		Wire-saving type
Model No.	NPN output	HG-TC101	HG-TC111	HG-TC113
	PNP output	HG-TC101-P	HG-TC111-P	
External input switching		Input 1, Input 2, and Input 3 can be switched to "Preset / Reset / Trigger", "Bank Input A / Bank Input B / Select (Preset, Reset, Trigger)", or "Laser emission stop".		—
Sampling cycle		1ms (standard sampling) or 0.5ms (high-speed sampling)		
Average count (response time)(Note 5)		Switching type: 1 time (2ms), 2 times (3ms), 4 times (5ms), 8 times (9ms), 16 times (17ms), 32 times (33ms), 64 times (65ms), 128 times (129ms), 256 times (257ms), 512 times (513ms), and 1,024 times (1,025ms)		
Display resolution		1 $\mu$ m		
Display range		-199.999 to 199.999mm		
Protection		IP40 (IEC)		
Contamination level		2		
Ambient temperature		-10 to +50°C (No dew condensation or icing allowed) (Note 4), Storage: -20 to +60°C		
Ambient humidity		35 to 85% RH, Storage: 35 to 85% RH		
Elevation		2,000m or less (Note 6)		
Insulation resistance		20M $\Omega$ or higher, using 250VDC megger connected between all supply terminals and case		
Withstand voltage		1,000 VAC for one minute between all supply terminals and case		
Vibration resistance		10 to 150Hz with 0.75mm amplitude at maximum acceleration of 49m/s <sup>2</sup> in X, Y, and Z directions for two hours each		
Shock resistance		98m/s <sup>2</sup> (approx. 10G) in X, Y and Z directions 5 times each		
Materials		Case: Polycarbonate, Cover: Polycarbonate, Switches: Polyacetal		
Cable		0.2mm <sup>2</sup> 2-conductor (brown and blue lead wires) / 0.15mm <sup>2</sup> 7-conductor 2m composite cable	0.15mm <sup>2</sup> 7-conductor 2m composite cable	—
Weight (main unit only)		Approx. 140g	Approx. 140g	Approx. 60g
Standards compliance		EMC Directive		

Notes: 1) Measured at a supply voltage of +24VDC and an ambient temperature of +20°C, unless otherwise indicated.

2) Current consumption does not include analog current output.

3) Linearity is a value calculated from digitally measured values at F.S. = 16mA for current output or F.S. = 4V for voltage output.

4) When slave units are connected to the master unit, the maximum sink current and source current of control output and ambient temperature vary depending on the number of connected slave units as shown below.

Number of connected slave units		Maximum sink current and source current of control output	Ambient temperature
	When communication unit is connected		
1 to 7 units	1 to 6 units	20mA	-10 to +45°C
8 to 15 units	7 to 14 units	10mA	


5) Average count (response time) is for when the sampling cycle is set to 1ms (standard sampling). Response times differ when the sampling cycle is set to 0.5ms (high-speed sampling).

6) Do not use or store this product in environments where ambient air is pressurized to an air pressure higher than the atmospheric pressure at an altitude of 0m.


## Specifications and Dimensions

### I/O circuit diagrams

#### • HG-TC101 / NPN output type



\* S1




(Note): Use shielded cables for analog output.

#### <Reference>


- All outputs are equipped with short-circuit protection. If any one of outputs 1 to 3 short-circuits, all outputs temporarily turn OFF. The outputs automatically recover when the short-circuit state is cleared.

## • HG-TC101-P / PNP output type



\* S1

Non-voltage contact or PNP open collector transistor



+4V to +V DC: Valid  
0 to +0.6 VDC or open: Invalid


(Note): Use shielded cables for analog output.

### <Reference>

- All outputs are equipped with short-circuit protection. If any one of outputs 1 to 3 short-circuits, all outputs temporarily turn OFF. The outputs automatically recover when the short-circuit state is cleared.


## Specifications and Dimensions

### ● HG-TC111 / NPN output type



\* S1

Non-voltage contact or NPN open-collector transistor



0 to +1.2 VDC: Valid


+8V to +V DC or open: Invalid

(Note): Use shielded cables for analog output.


#### <Reference>

- All outputs are equipped with short-circuit protection. If any one of outputs 1 to 3 short-circuits, all outputs temporarily turn OFF. The outputs automatically recover when the short-circuit state is cleared.
- The HG-TC111 cable does not have +V or 0V. Power is supplied from the connector of the master unit.

## ● HG-TC111-P / PNP output type



\* S1



(Note): Use shielded cables for analog output.

### <Reference>

- All outputs are equipped with short-circuit protection. If any one of outputs 1 to 3 short-circuits, all outputs temporarily turn OFF. The outputs automatically recover when the short-circuit state is cleared.
- The HG-TC111-P cable does not have +V or 0V. Power is supplied from the connector of the master unit.

## Specifications and Dimensions

### 8.1.2 Sensor Head

Type	Measurement width 10 mm / Standard type	Measurement width 10 mm / Slim type
Model No.	HG-T1010	HG-T1110
Position detection method	CMOS-based	
Installation distance	0 to 500mm	
Measurement width	10mm	
Light source	Red semiconductor laser: Class 1 [JIS / IEC / GB / FDA (Note 1)] Maximum output: 0.3mW, Peak emission wavelength: 655nm	
Sampling cycle	1ms (standard sampling) or 0.5ms (high-speed sampling)	
Repeatability (Note 2)	1μm (Installation distance: 20mm) 2.5μm (Installation distance: 100mm) 5μm (Installation distance: 500mm)	
Linearity (Note 3)	±0.12% F.S (Installation distance: 20mm) ±0.28% F.S (Installation distance: 100mm)	
Minimum sensing object (Note 4)	ø0.5 mm in (Installation distance: 500 mm 19.685 in)	
Temperature characteristics (Note 5)	±0.03%F.S./°C	
Protective structure	IP67 (IEC)(Excluding connectors)	
Contamination level	2	
Ambient temperature	-10 to +45°C (No dew condensation or icing allowed), Storage: -20 to +60°C	
Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH	
Ambient illuminance	Incandescent light: 5,000lx or less at the light-receiving face (Note 6)	
Elevation	2,000m or lower (Note 7)	
Insulation resistance	20MΩ or higher, using 250VDC megger (between all terminals and case)	
Vibration resistance	10 to 55Hz with 1.5mm amplitude in X, Y and Z directions for two hours each	
Shock resistance	196m/s <sup>2</sup> in X, Y and Z directions three times each	
Grounding method	Capacitor grounding	
Materials	Case: Aluminum die casting, Light emitting and light receiving surfaces: Glass	
Cable	0.2m 4-conductor shielded cable with round connectors	
Weight (main unit only)	Emitter: Approx. 30g, Receiver: Approx. 30g	Emitter: Approx. 30g, Receiver: Approx. 25g
Standards compliance	EMC Directive, FDA	

All the specifications shown above are based on the values that are digitally measured when the sensor head is combined with controller **HG-TC**.

Specification conditions that are not particularly specified are shown below.

- Ambient temperature: +20°C
- Average number of controller setting times: 16 times
- Measured object: Opaque knife edge
- Installation distance: 100mm
- Measured object position conditions: Middle position of installation distance / Half shading

Notes: 1) Complies with the FDA regulations in accordance with FDA Laser Notice No. 50.

2) Peak-to-peak value of variations in digital measured values at the middle position of the installation distance and under half shading conditions

3) Indicates an error with the ideal straight line of digital measured values

4) When the light is blocked at the center position of 500 mm installation distance

5) When the light is half-blocked at the center position of 100 mm installation distance

6) When the sampling cycle of the controller is set to "standard sampling"

7) Do not use or store this product in environments where ambient air is pressurized to an air pressure higher than the atmospheric pressure at an altitude of 0m.




## 8.2. Dimension Drawings


### 8.2.1 Controller

Units: mm

#### ■ HG-TC101, HG-TC101-P / Master unit of high-performance type




#### ■ HG-TC111, HG-TC111-P / Slave unit of high-performance type




## Specifications and Dimensions

### ■ HG-TC113 / Slave unit of wire-saving type




### ■ Sensor head connection cable CN-HT-C□ (option) mounting diagram (Common to HG-TC101 / HG-TC101-P, HG-TC111 / HG-TC111-P, and HG-TC113)



### 8.2.2 Sensor Head

Units: mm


■ HG-T1010 / Measurement width 10 mm, standard type



## Specifications and Dimensions

Units: mm


### ■ HG-T1110 / Measurement width 10 mm, slim type



## 8.2.3 Side View Attachment

Units: mm

### ■ HG-TSV10



# Chapter 9

## Maintenance

---

9.1 Maintenance and Inspection .....	9-2
9.1.1 Maintenance Precautions .....	9-2
9.1.2 Main Inspection Items .....	9-2

## Maintenance

---

### 9.1 Maintenance and Inspection

#### 9.1.1 Maintenance Precautions

- Always turn OFF the power before cleaning the product.
- Never use thinner, benzene, or other organic solvents to wipe off dirt or dust.
- To remove any dirt that adheres to the controller and the light emitting and light receiving surfaces of the sensor head, use compressed air or gently wipe off using a clean, soft cloth.

If the surfaces are very dirty, wipe off dirt using a cotton swab (or similar material) moistened with absolute alcohol.

#### 9.1.2 Main Inspection Items

Inspect the controller regularly to maintain performance and enable optimum use. The main inspection items are as follows:

- Have any input and output terminals become loose or come off?
- Is the supplied power within the rated voltage range (24V DC  $\pm 10\%$ )?
- Is the ambient operating temperature within the specified range (-10 to +45°C)?
- Is the ambient operating humidity within the specified range (35 to 85% RH)?
- Does any dirt or foreign objects adhere to the light emitting and receiving surfaces of the sensor head?
- Has the cumulative operating period of the sensor head or controller exceeded 87,600 hours?

# Chapter 10

## Troubleshooting

---

10.1 Troubleshooting .....	10-2
10.2 Error Messages .....	10-4

## Troubleshooting

### 10.1 Troubleshooting

Solutions to frequently encountered problems and errors are described below.

<Reference>

- Check the wiring.
- Check the voltage and capacity of the power supply.
- When the HG-T controller manufactured prior to January 2019 is used, some functions will be restricted. For details, consult your Panasonic representative.

Symptom	Cause	Solution	Reference page
Nothing is displayed in the digital display unit of the controller	Power is not supplied.	Check if the capacity of the power supply is sufficient. Connect the power supply correctly.	8-2
	The controller is not connected correctly.	Check the controller connections.	4-11
	Eco mode is ON.	Set Eco mode to OFF.	7-37
Judgment value is not displayed correctly	Laser emission stop input is ON.	Set laser emission stop input to OFF.	7-18
	The measured object is not within the measurement range.	Check if the measured object is within the measurement range.	—
	Obstacles exist within the measurement range.	Remove the obstacles.	—
	The hold function is ON.	Check the settings of the hold function.	7-9
	The sensor head is not installed correctly.	Install the emitter and receiver correctly.	4-4
	Operation Mode is not set correctly.	Check the settings of the operation Mode.	6-9
	The specified direction of measurement is opposite to the direction in which the measured object is inserted.	Change the specified direction of measurement to TOP or BOTTOM.	6-10
Display of judgment values is not stable	The reference waveform is not registered correctly.	After adjusting the beam axis, register the reference waveform.	5-14
	The average count is set to a small value (response time is fast).	Set the average count to a large value (response time is slow).	6-11
	Dust, dirt, or other foreign matters adhere to the light emitting and receiving surfaces of the sensor head.	To remove any dirt that adheres to the light emitting and light receiving surfaces of the sensor head, use compressed air or gently wipe off using a clean, soft cloth. If the surfaces are very dirty, wipe off dirt using a cotton swab (or similar material) moistened with absolute alcohol.	—
	Dust, dirt, or other foreign matters adhere to the measured object.	Remove any dust, dirt, or other foreign matters that adhere to the measured object.	—
	The receiver of the sensor head is receiving ambient light from surrounding photoelectric sensors, inverters, or other devices.	Mount a shielding plate to prevent ambient light from hitting the receiver of the sensor head. Mount a shielding plate at a certain angle to the sensor head.	—
	Dust, grit, or other substances are flying in the operating environment.	Use a dust collector or similar device to remove and prevent dust, grit, and other substances from flying in the operating environment.	—
	The sensor head is installed in a location subject to severe vibration.	Take measures against vibration.	—
	Mutual interference is occurring.	Set the interference prevention function to ON.	7-45
	The distance between the installed emitter and receiver exceeds the specified range.	Ensure that the distance between the installed emitter and receiver is within the specified range.	8-8
	The distance between the sensor head receiver and the measured object is too far.	Make the distance between the installed emitter and receiver as short as possible.	—
	The serial number of the emitter differs from that of the receiver.	Use a pair of emitter and receiver with the same serial number.	—



Symptom	Cause	Solution	Reference page
Judgment value shifts	The reference waveform is not registered correctly.	After adjusting the beam axis, register the reference waveform.	5-14
	The measured object is inclined relative to the measurement range.	Place the measured object in the correct position.	—
	The distance between the installed emitter and receiver exceeds the specified range.	Ensure that the distance between the installed emitter and receiver is within the specified range.	8-8
	Dust, dirt, or other foreign matters adhere to the light emitting and receiving surfaces of the sensor head.	To remove any dirt that adheres to the light emitting and light receiving surfaces of the sensor head, use compressed air or gently wipe off using a clean, soft cloth. If the surfaces are very dirty, wipe off dirt using a cotton swab (or similar material) moistened with absolute alcohol.	—
	Dust, dirt, or other foreign matters adhere to the measured object.	Remove any dust, dirt, or other foreign matters that adhere to the measured object.	—
	The preset value is not set correctly.	Specify the preset value correctly.	6-23
	Analog scaling is not set correctly.	Set analog scaling correctly.	7-32
Analog output is not generated correctly.	Analog output line is not wired correctly.	Wire the analog output line correctly.	4-3
Keys cannot be operated	The key lock function is ON.	Set the key lock function to OFF.	7-44

<Important>

If the product still does not operate normally after you check the above, consult your Panasonic representative.

## Troubleshooting

### 10.2 Error Messages

If an error occurs during setting or measurement, one of the errors below will appear in the digital display section / MAIN.

Error Display	Cause	Solution
E 100	Both NPN output types and PNP output types are connected.	Connect only units of the same output type.
E 110	Number of connectable units exceeded.	Make sure that no more than 15 slave units are connected to a master unit (or no more than 14 slave units are connected if a communication unit is connected).
E 120	Controllers cannot communicate with each other.	Switch OFF the power, make sure the controllers are connected correctly, and then switch ON the power again.
E 130		
E 140	The calculation function is valid but no slave units are connected.	Change calculation mode to OFF.
E 150	The calculation function is valid but an insufficient number of slave units are connected.	Change calculation mode to OFF, or change the calculation application selection setting.
E 160	The saved number of connected units does not match the actual number of connected units.	Make sure that the saved number of connected units matches the actual number of connected units and then switch ON the power again.
E 170	The master unit executed copying, but copying failed due to abnormal behavior of the slave unit.	Check whether the connected slave unit is <b>HG</b> series.
E200	<ul style="list-style-type: none"> <li>• Sensor head not connected.</li> <li>• Broken wire in sensor head connection cable.</li> <li>• Sensor head failure.</li> <li>• Sensor head other than <b>HG-T</b> series connected.</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the sensor head is correctly connected.</li> <li>• Check if there is a broken wire in the sensor head connection cable. If there is a broken wire in the sensor head connection cable, replace the cable.</li> <li>• Replace the sensor head.</li> <li>• Connect an <b>HG-T</b> series sensor head.</li> </ul>
E230	Both connected sensor heads are emitters or receivers.	Connect an emitter and receiver correctly.
E240	Emitter problem.	Replace the emitter.
E500	Unable to preset by external input.	<ul style="list-style-type: none"> <li>• Check if you attempted to preset immediately after the power was turned ON or a reset was input.</li> <li>• Check if the system is in an indeterminate state.</li> <li>• Check if the display value is outside the display upper / lower limit.</li> <li>• Check if an alarm has occurred.</li> </ul>
E510	The beam axis adjustment function was executed when laser emission stop input was ON.	Set laser emission stop input to OFF and then execute the beam axis adjustment function.
E600	Unable to write to the EEPROM of the controller.	<ul style="list-style-type: none"> <li>• Switch the power OFF and then ON, and execute initialization of the controller from setting mode.</li> <li>• If the controller does not recover after the above, it is possible that the EEPROM write count is over 1 million. Replace the controller.</li> </ul>
E610	Unable to read from the EEPROM of the controller.	
E620	The controller EEPROM write count is over the service life of 1 million times.	
E630	<ul style="list-style-type: none"> <li>• Unable to write or read to / from the EEPROM of the sensor head receiver.</li> <li>• Data is invalid.</li> </ul>	<ul style="list-style-type: none"> <li>• Switch the power OFF and then ON, and execute initialization of the controller from setting mode.</li> <li>• If the controller does not recover after the above action, consult your Panasonic representative.</li> </ul>
E640	<ul style="list-style-type: none"> <li>• Unable to write or read to / from the EEPROM of the sensor head emitter.</li> <li>• Data is invalid.</li> </ul>	

Error number	Cause	Solution
E700	The detection output load has short-circuited and excessive current is flowing.	Switch OFF the power and check the load.
E900	An error has occurred inside the controller.	Switch the power OFF and then ON, and execute initialization of the controller from setting mode.
E910		
E911		
E912		
E920		

### <Important>

If an error occurs again after you cleared it:

- Check if an excessive force is applied to the controller or the sensor head.
- If the product still does not operate normally after you check the above, consult your Panasonic representative.

(MEMO)


# Chapter 11


## Appendix

---


11.1 Menu Structure(General Function Display).....	11-2
11.2 Menu Structure(Extended Function Display).....	11-4

11.1 Menu Structure(General Function Display)






## 11.2 Menu Structure(Extended Function Display)







(MEMO)

Revision History	Revision date	Revision item
First edition	10/5/2018	
Second edition	11/12/2018	Correction of mistakes
Third edition	2/1/2019	"Chapter 6 Setting up General Functions", "Chapter 7 Setting up Extended Functions", "Chapter 11 Appendix" added

## When you purchase and use the product

The products and specifications listed in this manual are subject to change (including changes to specifications and discontinuation of manufacturing) without notice as occasioned by the improvements that we introduce into our products. Consequently, when you place orders for these products, we ask you to contact one of our customer service representatives and check that the details listed in the manual are commensurate with the most up-to-date information.

We strive to improve the quality and reliability of our products, but malfunctions generally occur in electrical parts and devices with a certain probability. Durability of products differs according to the operating environment or operating conditions under which they are used.

Before using this product, always conduct testing using an actual machine under the actual operating conditions. Continuing to use the product with deteriorated performance could generate abnormal heat, smoke, or fire due to insulation deterioration. We request that safety design (such as redundant design, fire spread prevention design, and malfunction prevention design) and regular maintenance be implemented to prevent accidents resulting in injury or death, fire accidents, social damages, and other problems due to product failures or longevity.

### **1. WARRANTIES:**

- (1) Subject to the exclusions stated in 2 (EXCLUSIONS) herein below, Panasonic Industrial Devices SUNX warrants the Products to be free of defects in material and workmanship for a period of one (1) year from the date of shipment under normal usage in environments commonly found in manufacturing industry.
- (2) Any Products found to be defective must be shipped to Panasonic Industrial Devices SUNX with all shipping costs paid by Purchaser or offered to Panasonic Industrial Devices SUNX for inspection and examination. Upon examination by Panasonic Industrial Devices SUNX, Panasonic Industrial Devices SUNX will, at its sole discretion, repair or replace at no charge, or refund the purchase price of, any Products found to be defective.

### **2. EXCLUSIONS:**

- (1) This warranty does not apply to defects resulting from any cause:
  - (i) which was due to abuse, misuse, mishandling, improper installation, improper interfacing, or improper repair by Purchaser;
  - (ii) which was due to unauthorized modification by Purchaser, in part or in whole, whether in structure, performance or specification;
  - (iii) which was not discoverable by a person with the state-of-the-art scientific and technical knowledge at the time of manufacture;
  - (iv) which was due to an operation or use by Purchaser outside of the limits of operation or environment specified by Panasonic Industrial Devices SUNX;
  - (v) which was due to normal wear and tear;
  - (vi) which was due to Force Majeure; and
  - (vii) which was due to any use or application expressly discouraged by Panasonic Industrial Devices SUNX in 4 (CAUTIONS FOR SAFE USE) hereunder.
- (2) This warranty extends only to the first purchaser for application, and is not transferable to any person or entity which purchased from such purchaser for application.

### **3. DISCLAIMERS**

- (1) Panasonic Industrial Devices SUNX's sole obligation and liability under this warranty is limited to the repair or replacement, or refund of the purchase price, of a defective Product, at Panasonic Industrial Devices SUNX's option.
- (2) THE REPAIR, REPLACEMENT, OR REFUND IS THE EXCLUSIVE REMEDY OF THE PURCHASER, AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS, ARE HEREBY EXPRESSLY DISCLAIMED. IN NO EVENT SHALL PANASONIC INDUSTRIAL DEVICES SUNX AND ITS AFFILIATED ENTITIES BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCTS, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, GENERAL TERMS AND CONDITIONS 4 OR ANY DAMAGES RESULTING FROM LOSS OF USE, BUSINESS INTERRUPTION, LOSS OF INFORMATION, LOSS OR INACCURACY OF DATA, LOSS OF PROFITS, LOSS OF SAVINGS, THE COST OF PROCUREMENT OF SUBSTITUTED GOODS, SERVICES OR TECHNOLOGIES, OR FOR ANY MATTER ARISING OUT OF OR IN CONNECTION WITH THE USE OR INABILITY TO USE THE PRODUCTS.

### **4. CAUTIONS FOR SAFE USE**

- (1) The applications shown in the catalogue are only suggestions, and it is Purchaser's sole responsibility to ascertain the fitness and suitability of the Products for any particular application, as well as to abide by Purchaser's applicable local laws and regulations, if any.
- (2) Never use the Products NOT rated or designated as "SAFETY SENSOR" in any application involving risk to life or property. When such a use is made by Purchaser, such Purchaser shall indemnify and hold harmless Panasonic Industrial Devices SUNX from any liability or damage whatsoever arising out of or in relation to such use.
- (3) In incorporating the Products to any equipment, facilities or systems, it is highly recommended to employ fail-safe designs, including but not limited to a redundant +++design, flame propagation prevention design, and malfunction prevention design so as not to cause any risk of bodily injury, fire accident, or social damage due to any failure of such equipment, facilities or systems.
- (4) The Products are each intended for use only in environments commonly found in manufacturing industry, and, unless expressly allowed in the catalogue, specification or otherwise, shall not be used in, or incorporated into, any equipment, facilities or systems, such as those:
  - (a) which are used for the protection of human life or body parts;
  - (b) which are used outdoors or in environments subject to any likelihood of chemical contamination or electromagnetic influence;
  - (c) which are likely to be used beyond the limits of operations or environments specified by Panasonic Industrial Devices SUNX in the catalogue or otherwise;
  - (d) which may cause risk to life or property, such as nuclear energy control equipment, transportation equipment (whether on rail or land, or in air or at sea), and medical equipment;
  - (e) which are operated continuously each day for 24 hours; and
  - (f) which otherwise require a high level of safety performance similar to that required in those equipment, facilities or systems as listed in (a) through (e) above.

### **5. EXPORT CONTROL LAWS**

In some jurisdictions, the Products may be subject to local export laws and regulations. If any diversion or re-export is to be made, Purchaser is advised to abide by such local export laws and regulations, if any, at its own responsibility.

Please contact .....

## **Panasonic Industrial Devices SUNX Co., Ltd.**

■ Overseas Sales Division (Head Office): 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan

■ Telephone: +81-568-33-7861 ■ Facsimile: +81-568-33-8591

[panasonic.net/id/pidsx/global](http://panasonic.net/id/pidsx/global)

For sales network, please visit our website.