# **Panasonic**

Questions about Displacement Lasers?
Have an application question?
Ready to place an order?
Contact Ramco Innovations today

**Compact Laser Displacement Sensor** 

HL-G1 Series
User's Manual

#### Introduction

Thank you for purchasing the HL-G1-series Compact Laser Displacement Sensor. Read this manual carefully and be sure you understand the information provided before attempting to install and operate the product so that the product will fully demonstrate its superior performance. Refer to the website of Panasonic Industrial Devices SUNX Co., Ltd. (http://panasonic.net/id/pidsx/global) for the latest information on the product as well as the latest version of the manual.

#### Note

- 1. The illustrations of the product in the manual may differ from the actual design of the product.
- 2. The contents of this user's manual may change without notice for possible improvements in the future.
- 3. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Panasonic Industrial Devices SUNX Co., Ltd.
- 4. The utmost attention has been paid to the creation of this manual. Should you find any errors, omissions or inaccuracies, contact the nearest office of Panasonic Industrial Devices SUNX Co., Ltd.
- Panasonic Industrial Devices SUNX Co., Ltd. shall be in no case responsible for any consequences resulting from your operation of the product.

#### Conventions

The following conventions are used to indicate and classify precautions in this manual. Always heed the information provided with them.

⚠WARNING	Indicates information that, if not heeded, is likely to result in loss of life or serious injury.
<b>∆</b> CAUTION	Indicates information that, if not heeded, could result in relatively serious or minor injury, damage to the product, or faulty operation.
O OHEON	Explains matters that should be observed or mistakes that
<b>⊕</b> CHECK	Explains matters that should be observed or mistakes that the user is apt to make.
● CHECK  © REFERENCE	the user is apt to make.

# About this Manual

Introduction	<i>Introduction</i> provides precautions on the safe and correct use of this system. Be sure to read the precautions provided in this section.	
Chapter 1 Before Use	Chapter 1 provides information on the configuration, installation, and connection of the system (including the sensor head and Setting and monitoring software HL-G1SMI.	1
Chapter 2 I/O Terminal Block	Chapter 2 provides information on the I/O lines of the sensor head.	2
Chapter 3 Functions	<b>Chapter 3</b> provides information on the functions of the system.	3
Chapter 4 Communications	Chapter 4 provides information on RS-422 and RS-485 communications control.	4
Chapter Control 5 Troubleshooting	<b>Chapter 5</b> provides information on the troubleshooting of the system.	5
Chapter 6 Specifications	<b>Chapter 6</b> provides the specifications of the sensor head.	6

# Table of Contents

About this Manual Table of Contents	1 2
Safety Precautions 4 WARNING 4 Caution 4	
Correct Handling5	
Installation Environment······	-
■ Do not install the system in the following	,
places5	
Operating Environment	5
■ Ambient Temperature, Humidity, and	
Illuminance5	
■ Power Supply Voltage······	6
■ Environment ······6	
Protective Structure6	
Warm-up Time ······7	
Countermeasures against Noise	. 7
Power Supply ·····8	
■ Applicable Power Supply ······	8
■ Power Supply Sequence for Sensor Head	8
Instantaneous Power Failure······	
Applicable Standards / Regulations	9
■ CE Compliant Conditions ·····	9
■ Contact for CE ·····9	
Laser Product Handling ·····	10
JIS/IEC/GB ······	10
■ Laser Diode Sensor ······	10
■ Precautions ·····	10
■ Warning label·····	11
FDA	12
■ Export to US ·····	12
■ FDA Standards ·····	13
Maintenance and Inspection	15
■ Maintenance Instructions·····	15
■ Inspection ······	15
<b>1</b> Before Use1-1	
1-1 System Configuration······1-	2
1-1-1 System Configuration ······ 1-	
1-1-2 List of System Components &	_
Accessories ····································	
Sensor Head Accessories1-	.3
■ Extension Cable for Sensor Head	•
(Optional for High-function Type Only) ·····	1-4
■ Setting and Monitoring Software	
HL-G1SMI (Optional for High-function	
Type Only)1-4	

■ Compact Console (Optional for High-ful	nction
Type Only)·····	···· 1-5
1-2 Part Names and Functions ····	
1-3 Installation Method·····	·····1 <b>-</b> 7
■ Extension Cable ·····	····· 1-7
Mounting Direction of Sensor Head	1-8
1-4 Measurement of transparent of	objects
1-	- 12
2 I/O Terminal Block ······	····2-1
<b>2-1</b> Functions and Arrangements of I/O	Terminal
Block ·····	·2-2
2-2 I/O Circuit······	
■ When using with NPN output (Connect NP sw	
input to 0V)	2-4
■ When using with PNP output (Connect NP sw	
input to +V) ······	2-5
2-3 Analog Output Circuit ······	2-6
2-4 Timing Chart ······	2-7
2-5 Conditions When Output Data Becon	
2-3 Conditions when Output Data Becon	
4	2-9
3 Functions ·····	2.4
3 Functions	2-1
3-1 Classification of Functions ·····	3-2
3-2 Function List & Initial Values ·	3-2
3-3 Operation of Each Function ··	3-5
3-3-1 Basic Operation ·······	3-5
■ Panel Configuration·····	3-5
■ Basic Operation·····	0.0
	3-6
■ Screen Transition in Setting Mode ··	3-9
3-3-2 Memory Change ·····	3-9 3-11
3-3-2 Memory Change ····································	·····3-9 ····3-11 ··· 3-13
3-3-2 Memory Change	·····3-9 ····3-11 ··· 3-13 ··· 3-13
3-3-2 Memory Change	3-9 3-11 3-13 3-13 3-14
3-3-2 Memory Change	3-9 3-11 3-13 3-14 3-15
3-3-2 Memory Change	3-93-11 3-13 3-13 3-14 3-15 3-16
3-3-2 Memory Change	3-9 3-11 3-13 3-13 3-14 3-15 3-16 3-16
3-3-2 Memory Change 3-3-3 Sensing Setting	3-93-113-133-133-143-153-163-163-17
3-3-2 Memory Change 3-3-3 Sensing Setting	3-93-11 3-13 3-13 3-14 3-15 3-16 3-16 3-17 .3-19
3-3-2 Memory Change 3-3-3 Sensing Setting  Sampling Cycle  Shutter Time  Light Intensity Monitor  3-3-4 Data Processing Settings  Average Times  Analysis Mode  Span  Offset  Zero-set OFF	3-93-11 3-13 3-13 3-14 3-15 3-16 3-16 3-17 .3-19 .3-21 3-22
3-3-2 Memory Change 3-3-3 Sensing Setting	3-93-11 3-13 3-13 3-14 3-15 3-16 3-16 3-17 .3-19 .3-21 3-22 3-23
3-3-2 Memory Change 3-3-3 Sensing Setting  Sampling Cycle  Shutter Time  Light Intensity Monitor  3-3-4 Data Processing Settings  Average Times  Analysis Mode  Span  Offset  Zero-set OFF  3-3-5 Output Settings	3-93-11 3-13 3-13 3-14 3-15 3-16 3-16 3-17 3-19 3-21 3-22 3-23
3-3-2 Memory Change 3-3-3 Sensing Setting	3-93-113-133-143-153-163-163-17 .3-19 .3-213-223-233-23

■ Measurement Value Display on Panel ····· 3-29	FORMAT 2 Value Setting ······ 4-10
<b>3-3-6</b> Analog Settings 3-30	FORMAT 3 All Outputs Read 4-12
■ Analog Output Selection······ 3-30	FORMAT 4 Normal Read of Buffering Data ··· 4-13
■ Analog Scaling ······ 3-31	FORMAT 5 Read of Differential Data in
3-3-7 Alarm Settings 3-33	Buffering Data······ 4-14
■ Analog Output at Alarm ······ 3-33	FORMAT 6 Binary Read of Buffering Data ···· 4-14
■ Digital Output at Alarm ······ 3-34	FORMAT RS-422 Timing (or RS-422
■ Alarm Delay Times ····································	Continuous) Output Mode ······ 4-15
<b>3-3-8</b> COM Settings 3-36	■ Error Response ······ 4-16
■ Terminating Resistor Selection ··········· 3-36	■ BCC4-18
Sensor No	<b>4-3</b> Command List4- 19
■ Baud Rate	■ Basic Settings ······· 4-19
Connection Mode ······ 3-39	■ Data Processing Settings ······ 4-19
Sending Delay Time ······ 3-40	Output Settings
3-3-9 System Settings 3-41	■ Analog Settings
■ Timing Mode 3-41	■ Alarm Settings······· 4-21
Laser Control3-42	System Settings4-22
■ Eco Mode ····································	■ Read Commands ······ 4-23
■ View Version	■ Buffering Commands ······ 4-23
<b>3-3-10</b> Other System Settings 3-45	4-4 Setting Address List ······4- 25
	■ Command Formats(MEWTOCOL)········ 4-26
Save 3-46	■ Error Response 4-26
3-3-11 Measurement Control with	Sensing Settings4-27
External Input ····· 3-47	■ Data Processing Settings ······ 4-27
■ Timing 3-47	Output Settings 4-28
■ Zero Set 3-47	■ Analog Settings
■ Reset 3-49	■ Alarm Settings 4-29
3-3-12 Buffering Settings (High-function	System Settings 4-29
type only) 3-50	■ Data Readout ············ 4-29
■ Data Buffering Operation······ 3-51	■ Buffering settings ········· 4-30
■ Buffering Mode ······ 3-52	<ul> <li>Setting for Programmable Display (GT Series)</li></ul>
■ Buffering Rate ······ 3-53	Series)
■ Accumulated Amount ······ 3-53	
■ Trigger Points ······ 3-54	<b>5</b> Troubleshooting·····5-1
■ Trigger Delay ······ 3-54	540 " 4 "
■ Trigger Conditions······ 3-55	5-1 Corrective Actions 5-2
■ Buffering Operation ······ 3-56	5-2 Initialization ····· 5-6
■ Status Readout ······ 3-56	
■ Last Data Point ············ 3-56	6 Specifications······6-1
■ Binary Readout of Buffering Data ········· 3-57	• opcomodions
	6-1 Sensor Head Specifications ······· 6-2
4 Communications Control ······4-1	6-2 Dimensions 6-8
	■ Sensor Head6-8
1-1 Communications Specifications ·····4-2	
■ Specifications······4-2	6-3 Characteristics ······6- 13
■ Pin Arrangement·······4-2	■ Beam Diameter ······ 6-13
■ Connecting Example with External Device · 4-3	■ Mutual Interference Area ······ 6-15
■ Communications Protocol ······4-6	Output Characteristics 6-18
■ Communications Condition Changes ······· 4-6	Revision history 6-20
<b>1-2</b> Type and Format of Commands ····4-7	
<b>4-2-1</b> Commands4-7	
■ Data Transmission/Reception······4-7	
<b>4-2-2</b> Command Formats 4-9	

General Purpose 4-9

# Safety Precautions

This product is used to detect objects, and does not incorporate control functions for the purpose of maintaining safety including the prevention of accidents.

Do not use this product as a human sensor to protect human bodies.

Use products that conform to the laws, regulations, and international standards, such as OSHA, ANSI, and IEC standards, for applications protecting human bodies.

In order to ensure the correct use of the product, read this user manual carefully before use.

#### **⚠WARNING**

- Incorporate safety measures, such as a double safety mechanism, into the system if the use of the system is likely to result in injury or serious consequential loss.
- Do not use the system in combustion gas atmospheres. Otherwise, the system may result in explosion.
- This product was developed and manufactured for use in industrial environments.

# **⚠**CAUTION

- Always observe the specifications including the ratings and ambient conditions.
  - Otherwise, the system may result in overheating or generate smoke.
- Do not disassemble or modify the system. Otherwise, an electric shock may be received or the system may generate smoke.
- Do not touch the wires when the system is energized. Otherwise, an electric shock may be received.

# **Correct Handling**

Pay attention to the following items when installing and using the system.

#### Installation Environment

#### Do not install the system in the following places.

- Places where the ambient temperature, humidity, or the illumination level of the light receiving surface is in excess of the operating environmental conditions.
  - (→ Refer to "Operating Environment".)
- Places that causes dew condensation as a result of radical temperature changes.
- Places with corrosive gas or flammable gas.
- Places with excessive dust, iron powder, or salt.
- Places where organic solvents, such as benzine, paint thinner, and alcohol, and strong alkaline substances, such as ammonia and sodium hydroxide are likely to adhere to the system.
- Places with strong vibration and shock.
- Places exposed to direct sunlight.
- · Places where oil, or chemicals are sprayed.
- Places where a heavy load is imposed on the sensor head.

# Operating Environment

# Ambient Temperature, Humidity, and Illuminance

#### Ambient temperature

Use the system within the range of the specifications (→ refer to Chapter 6 "Specifications").

Sensor head: -10°C to +45°C

 Keep the following storage temperature range in the case of storing the sensor head.

Sensor head: -20°C to +60°C

- The life of the semiconductor laser depends on the operating ambient temperature. Take appropriate measures, such as the use of a cooling fan, to drop the ambient temperature of the sensor head as much as possible if the sensor head is used close to heat radiating objects.
- The sensor head radiates heat as well. Therefore, be sure to install the sensor head in places with as good thermal conductivity as possible. Mount the sensor head to an aluminum or steel plate with a minimum surface area of 200 cm<sup>2</sup> if the

ambient temperature is 40°C or higher.

In the case of installing two or more sensor heads in parallel, mount each sensor head to an aluminum or steel plate with a minimum surface area of  $200 \text{ cm}^2$  and make sure that the ambient temperature does not exceed  $40^{\circ}\text{C}$ .

#### Ambient humidity

• Use the system within a relative humidity (RH) range of 35% to 85%. Do not use the system in places that may cause dew condensation as a result of radical temperature changes.

#### Ambient illuminance of light receiving surface

Make sure that the illumination level of the light receiving surface does not exceed 3,000 lx under incandescent light.

#### ■ Power Supply Voltage

Be sure to supply a rated voltage of 21.6 to 26.4 VDC.

#### Environment

- The internal circuit may be damaged if an external surge voltage (single-polarity, full-wave voltage) in excess of 500 V  $\pm$  1.2 x 50  $\mu$ s is imposed. Insert a surge absorber between power input terminals if the external surge voltage is likely to exceed 500 V.
- Always keep the emitter and receiver of the sensor head clean. Make sure that the
  emitter and receiver are free of substances that refract light, such as water, oil, or
  fingerprints, or surface water, or matters that block light, such as dust and dirt.
  Clean the emitter and receiver with a soft lint-free cloth or lens cleaning paper.
- Check that the receiver will not receive direct ambient light the same as the laser light in wavelength, such as sunlight. Mount an appropriate object, such as a light shield plate, to the sensor head if high accuracy is especially required.
- Do not use the system in places with flammable or corrosive gas or excessive dust, places where water is sprayed, places exposed to direct sunlight, or places with strong vibration or shock.

#### **Protective Structure**

• The sensor head is of penetration-resistant type, but the connector is not of dust, water-, or corrosion-proof construction. Therefore, Do not use the product underwater or in the rain. Pay attention to the operating environment.

#### Warm-up Time

In order to ensure the performance of the system, allow a warm-up time of at least 30 minutes after the system is turned ON.

# Countermeasures against Noise

- Install the system separated as much as possible from noise generating sources, such as high-tension lines, high-voltage equipment, power lines, power equipment, machines generating high-voltage ON/OFF surges, welding machines, and inverter motors.
- Install the system separated as much as possible from radio equipment incorporating transmission circuitry, such as amateur radio transmitters.
- Do not touch the connector parts when the system is energized. Keep in mind that
  the internal circuit may be damaged if an excessive level of static electricity is
  imposed on the connector parts.
- Separate the sensor cable from other wires at least 100 mm, and make sure that
  the sensor cable is not in parallel with them. Separate the sensor cable from
  high-voltage and power circuit lines. Shield the sensor cable with grounded
  conduits if it is unavoidable to lay the sensor cable together with high-voltage or
  power circuit lines.
- Separate the I/O signal lines at least 100 mm away from power lines and power supply lines. All signal lines should be connected as short as possible.
- The analog output of the system is adversely influenced by heavy noise in the power supply. In that case, use a noise filter or noise-cut transformer.
- It is recommended to use shield cables for I/O signal wires and connect the shields to the frame ground (FG) for countermeasures against noise.
- The analog output is easily affected by external noise. Use the shield cable and lay it as short as possible.

# Power Supply

#### Applicable Power Supply

- Select a power supply with a maximum ripple of 0.5 V (peak to peak) and a minimum current capacity of 0.5 A.
- Be sure to ground the FG terminal in order to prevent an adverse influence of high-frequency noise if a commercially available switching regulator is used for the power supply.
- A transformer may be connected to the power supply on the condition that the transformer is of isolation type. The product or the power supply may be damaged if an auto transformer is used.
- In order to protect the system from abnormally high voltages from the power supply line, be sure to use an isolated power supply with a built-in protective circuit.
- In the case of using a power supply that does not incorporate a protective circuit, be sure to connect the power supply to the system through a protective element, such as a fuse.

#### ■ Power Supply Sequence for Sensor Head

- Arrange a power supply sequence so that the sensor head will be turned ON earlier than the I/O power supply.
- Arrange a power supply sequence so that the I/O power supply will be turned ON
  earlier than the sensor head.
- Do not turn ON the sensor head again within 10 seconds after the sensor head is turned OFF.
- The system will be ready to operate approximately 40 to 50 seconds after the system is turned ON, depending on the contents of settings. No outputs are determined during startup. Do not output anything during the period.
- An analog voltage of 11 V and an analog current of approximately 21.6 mA will be output until the system becomes ready to operate.
- Do not turn OFF the system while system settings are being saved. In the worst
  case, the sensor head system may be damaged and fail to restart.

#### Instantaneous Power Failure

If an instantaneous power failure occurs, the system will operate continuously or go to the initial power-on state, depending on the duration of the power failure. Do not use the system in environments where instantaneous power failures occur.


# Applicable Standards / Regulations

#### ■ CE Compliant Conditions

Make sure that the length of signal and power lines connected to the product is less than 30 m.

Attach a ferrite core to the head cable as shown below.

Recommended ferrite core: SEIWA ELECTRIC MFG. Co., Ltd.E04SR200935AB or equivalent one



#### ■ Contact for CE

Panasonic Marketing Europe GmbH Panasonic Testing Center Winsbergring 15, 22525 Hamburg, Germany

# **Laser Product Handling**

# JIS/IEC/GB

#### Laser Diode Sensor

The laser is classified in accordance with JIS (JIS C 6802: 2005), IEC (IEC 60825-1: 2007) and GB (GB 7247.1: 2012) standards.

Model No.	HL-G1□□-A-C5 HL-G1□□-S-J	HL-G1□□A-RA-C5 HL-G1□□A-RS-J
Wavelength	655 nm	655 nm
Max. output	1 mW	0.39 mW
Class	2	1

#### Precautions

- 1) Be careful not to stare at the laser beam directly or the reflected light of the mirror surface
- 2) Install the sensor so the laser beam will be located higher or lower than eye level in order not to watch the beam directly while the system is in operation.
- 3) Contact the nearest office of Panasonic Industrial Devices SUNX Co., Ltd. if the system breaks down. The product is not provided with a function to stop laser beam radiation automatically when the sensor head is disassembled. Do not disassemble the sensor head, or otherwise you may be exposed to the laser beam.
- 4) Do not use the system in methods other than that specified in this manual.


A CALIT LON	You may be exposed to hazardous laser radiation if the system is controlled or adjusted in procedures not specified in this manual.	
Z:ZCAUTTON	controlled or adjusted in procedures not specified in this manual.	

5) Read the descriptions of the warning label carefully before use.

The warning label (English) is affixed to the side of the sensor head. Warning labels in Japanese, Korean, and Chinese are enclosed. Use them as needed.

# ■ Warning label

• Diffuse reflection type











#### <Label position>



• Specular reflection type



#### <Label position>



#### **FDA**


#### ■ Export to US

The laser product mounted on equipment and exported to the United States is subjected to the regulation of the Food and Drug Administration (FDA). In order to prevent the users' injury caused by laser products, the FDA specifies PART 1040 (Performance Standards for Light-Emitting Products). The FDA classifies laser products according to the degree of risk and provides safety measures for respective classes. ( refer to "FDA Standards".)

#### Certification and Identification Label



#### <Label position>



#### ■ FDA Standards

Requirements		Class*1				
		IIa	II	IIIa	IIIb	IV
Performance (all laser products)						
Protective housing [1040.10(f)(1)]	R*2	$R^{*2}$	R*2	R*2	$R^{*2}$	$R^{*2}$
Safety interlock [1040.10 (f) (2)]	R*3,4	R*3,4	R*3,4	R*3,4	R*3,4	R*3,4
Location of controls [1040.10(f)(7)]	N/A	R	R	R	R	R
Viewing optics [1040.10(f)(8)]	R	R	R	R	R	R
Scanning safeguard [1040.10(f)(9)]	R	R	R	R	R	R
Performance (laser system)						
Remote interlock connector [1040.10(f)(3)]	N/A	N/A	N/A	N/A	R	R
Key control [1040.10(f)(4)]	N/A	N/A	N/A	N/A	R	R
Emission indicator [1040.10(f)(5)]	N/A	N/A	R	R	$R^{*10}$	$R^{*10}$
Beam attenuator [1040.10(f)(6)]	N/A	N/A	R	R	R	R
Manual reset mechanism [1040.10(f)(10)]	N/A	N/A	N/A	N/A	N/A	R*13
Performance (specific-purpose products)						
Medical [1040.11(a)]	S	S	S	S*8	S*8	S*8
Surveying, leveling, alignment [1040.11(b)]	S	S	S	S	NP	NP
Demonstration [1040.11(c)]	S	S	S	S	S*11	S*11
<u>Labeling (all laser products)</u>						
Certification/identification [1010.2,3]	R	R	R	R	R	R
Protective housings [1040.10(g)(6),(7)]	D	R*5	R*5	R*5	R*5	R*5
Aperture [1040.10(g)(4)]	N/A	N/A	R	R	R	R
Class warning [1040.10(g)(1),(2),(3)]	N/A	$R^{*6}$	R*7	R*9	R*12	R*12
Information (all laser products)						
User information [1040.10(h)(1)]	R	R	R	R	R	R
Product literature [1040.10(h)(2)(i)]	N/A	R	R	R	R	R
Service information [1040.10(h)(2)(ii)]	R	R	R	R	R	R

R: Required

N/A: Not applicable

S: Requirements: Same as for other products of that Class.

NP: Not permitted

D: Depends on level of inner radiation

- \*1 Class is based on the maximum level of laser exposure during operation.
- \*2 Required wherever and whenever such human access to laser radiation levels that exceed the limits of Class I is not necessary for the product to perform its intended function.
- \*3 Required at the protective housing which is designed to be removed or displaced during operation or maintenance, if removal or displacement of the protective housing could permit human access to laser or collateral radiation.
- \*4 The requirements for interlock differ depending on the class of inner radiation.
- \*5 The contents of label differ depending on the level and wavelength of laser radiation inside the protective housing.
- \*6 Warning statement label
- \*7 CAUTION logotype
- \*8 The method to measure the level of laser radiation to human body is required.
- \*9 CAUTION if 2.5mWcm<sup>-2</sup> or less, DANGER if greater than 2.5mWcm<sup>-2</sup>.
- \*10 Time difference is needed between instruction and emission.
- \*11 Exception should be provided for demonstration of laser products or light shows using laser of Class IIIb or IV.
- \*12 DANGER logotype
- \*13 Required on and after August 20, 1986.

# Maintenance and Inspection

#### Maintenance Instructions

- Be sure to turn OFF the system to stop laser emission before cleaning the system.
- Molded resin is used in some parts of the system. Do not use organic solvents such as paint thinner or benzine to wipe the dirt on the system.
- Do not wipe the glass portion of the laser aperture too strongly. Scratches on the glass may cause measurement errors.

#### (1) Cleaning Emitter and Receiver on Front Side of Sensor Head

- Always keep the emitter and receiver of the sensor head clean. Make sure that the
  emitter and receiver are free of substances that refract light, such as water, oil, or
  fingerprints, or surface water, or matters that block light, such as dust and dirt.
  Inspect the surfaces regularly and always keep them clean.
- Blow away large particles of dust, if any, using a camera lens blower.
- To remove small particles of dust or fingerprints, use soft lens cleaning cloth or lens cleaning paper and lightly wipe them out.
- Use cloth moistened with a small amount of alcohol to wipe out tough dirt carefully.

#### Inspection

Inspect the system regularly to maintain the performance of the system and make it possible to use the system under optimum conditions.

#### Major Inspection Items

- Check that no I/O terminal connections are loose or disconnected.
- Check that the glass surface on the laser aperture is free of dust, dirt or fingerprints.
- Check that the power supply voltage is within the rated range (21.6 to 26.4 VDC).
- Check that the operating ambient temperature during use is within the specification range (a sensor head temperature range of -10°C to 45°C).
- Check that operating ambient humidity (RH) is within a range of 35% to 85%.



# 1 Before Use


This Chapter provides information on the configuration, installation, and connection of the system (including the sensor head and Setting and Monitoring Software HL-G1SMI).


1-1 System Configuration·····	1-2
1-1-1 System Configuration · · · · · · · ·	1-2
1-1-2 List of System Components &	
Accessories · · · · · · · · · · · · · · · · · · ·	1-3
1-2 Part Names and Functions · · · ·	1-6
1-3 Installation Method	1_7

# 1-1 System Configuration

# 1-1-1 System Configuration

The system configuration and equipment connecting cables are shown below.





USB-RS-422/485 converter

Recommended: SI-35USB (LINEEYE made) or GT02 series or GT12 series (Panasonic Industrial Devices SUNX made)

The user may use a different converter at the user's own discretion.

#### **O**CHECK

Dedicated software (to be downloaded from the website of Panasonic Industrial Devices SUNX) is required if the GT02 or GT12 series is used as a converter.


# 1-1-2 List of System Components & Accessories


#### ■ Sensor Head Accessories

The accessories of the sensor head are shown below.

Sensor head (Standard type)

Sensor head (high-function type)





Sensor Head Instruction Manual



Japanese / English and Chinese / Korean

#### Warning label

#### Diffuse reflection





Sticker: English


Attachments: Japanese x 1 set

Chinese x 1 set Korean x 1 set

#### Specular reflection



 Extension Cable for Sensor Head (Optional for High-function Type Only)



 Setting and Monitoring Software HL-G1SMI (Optional for High-function Type Only)

Software for the Setting and Monitoring Software HL-G1SMI can be downloaded from the website of Panasonic Industrial Devices SUNX Co., Ltd. (http://panasonic.net/id/pidsx/global).


#### ■ Compact Console (Optional for High-function Type Only)

The GT-series Programmable Display of Panasonic Industrial Devices SUNX Co., Ltd. is available as a compact console for the HL-G1. Write dedicated screen data to the Programmable Display so that the Programmable Display will display HL-G1 settings and measurement values transmitted over RS-422 and RS-485 communication.

#### Compact Console



Compact console brackets and screws



Terminal block for compact console




GT-series product numbers applicable


No. of connecti on units	Product name	Screen	Backlight	Body color	Part no.
	GT02G		C / O / D 1	Pure black	AIG02GQ14D
Single	G102G	3.8-type STN	Green/Orange/Red	Hairline silver	AIG02GQ15D
connection	GT02M	240 x 96 dots	White/Pink/Red	Pure black	AIG02MQ14D
G				Hairline silver	AIG02MQ15D
	GT12G		STN 320 x 120 dots	Pure black	AIG12GQ04D AIG12GQ14D
Multi connection (1 to 4 units)	4	4.6-type		Hairline silver	AIG12GQ05D AIG12GQ15D
	320 120	320 x		Pure black	AIG12MQ04D AIG12MQ14D
	GT12M		White.	White/Pink/Red	Hairline silver

#### **O**CHECK

The screen data and User's Manual (Console-dedicated version) can be downloaded from the website of Panasonic Industrial Devices SUNX Co., Ltd. (http://panasonic.net/id/pidsx/global).

# 1-2 Part Names and Functions






- Laser Indicator (LASER)
   Lights up in green during laser emission.
- (2) Alarm Indicator (ALARM)
  Lights up in orange if a measurement alarm results.
- (3) OUT1 Indicator (OUT1)
  Lights up in yellow during OUT1 output.
- (4) OUT2 Indicator (OUT2)
  Lights up in yellow during OUT2 output.
- (5) OUT3 Indicator (OUT3)
  Lights up in yellow during OUT3 output.
- (6) [ENTER] Key
  Used to enter items.
- (7) Digital Display
  Displays measurement values and system errors.
- (8) [UP] Key
  Used to select items.
- (9) [DOWN] Key
  Used to select items.
- (10) Emitter
  Emits the laser light.
- (11) Receiver
  Receives reflected light from measurement targets.

# 1-3 Installation Method

Before installing each device, read carefully the explanation of the setting environment, concern about noise and radiation, and power supply.

#### (→ Refer to "Introduction" – "Correct Handling".)

Fix the sensor head securely with M4 screws inserted into the two screw holes of the sensor head.




#### **OCHECK**

- The tightening torque should be 0.8N·m or less.
- Never impose force around the connectors of the sensor head cable and extension cable. Do not bend the cables near the connectors. Doing so may result in cable disconnection.
- Pay utmost attention not to bend the sensor cable in excess if the sensor needs to be moved.

#### Extension Cable

 Do not pull the cable with a force of 29.4N or over when wiring the cable when the sensor head is fixed. The cable may be bent with a radius of 30 mm or over. However, do not bend the cable within 20 mm of the sensor head.




#### ■ Mounting Direction of Sensor Head

Mount the sensor head in the direction shown below toward the measuring target in order to ensure the precise and stable measurement operation of the sensor head.

#### · Installation direction toward the moving target


#### Measurement of targets with extremely different adjacent colors or materials

When measuring a moving target that has extremely different adjacent colors or materials, set the direction of the sensor head as shown below in order to minimize the measurement error of the sensor head.




#### · Measurement of rotating targets

When measuring a rotating target, set the direction of the sensor head as shown below in order to minimize the adverse influence of vertical oscillation or displacement.




#### · Measurement of targets with level differences

When measuring a moving target that has level differences, set the direction of the sensor head as shown below in order to minimize interference caused by the edges of the target.




#### • Measurement of targets in narrow space or slots


When measuring a target in a narrow space or slot, set the direction of the sensor head as shown below in order not to block the light path between the emitter and receiver.



#### • When mounting the sensor head to a wall surface

Set the direction of the sensor head as shown below so that the receiver will not receive multi-reflected light from the wall. If the wall reflectance is high, painting the surface matte-black is effective.






#### Sensor head angle to the center of measurement target for a diffuse reflection-type sensor

Mount the sensor head so that the emitter and receiver will be located in parallel to each other as shown in the illustration on the right-hand side.

→ Refer to "6-1 Sensor Head Specifications" for the measurement center distance and measurement range.




Model name	Measurement center distance	Measurement range	
HL-G103-A-C5	30 mm	±4 mm	
HL-G103-S-J	30 111111		
HL-G105-A-C5	50 mm	±10 mm	
HL-G105-S-J	50 mm		
HL-G108-A-C5	85 mm	±20 mm	
HL-G108-S-J	05 111111		
HL-G112-A-C5	120 mm	±60 mm	
HL-G112-S-J	120 111111	100 111111	
HL-G125-A-C5	250 mm	±150 mm	
HL-G125-S-J	250 111111	± 100 mm	

• Sensor head angle to the center of measurement target

for a specular reflection-type sensor

Attach so that the receiver will receive light reflected directly as shown in the figure to the right.



Model name	Measurement center distance	Measuremen t range	Installation angle	
HL-G103A-RA-C5	26.3 mm	±2 mm	15°	
HL-G103A-RS-J	20.3 11111	±2 IIIII	10	
HL-G105A-RA-C5	47.3 mm	±5 mm	10.39°	
HL-G105A-RS-J	47.3 11111	±3 IIIII	10.59	
HL-G108A-RA-C5	82.9 mm	±10 mm	7.53°	
HL-G108A-RS-J	02.9 111111	±10 IIIII	7.55	

# 1-4 Measurement of transparent objects

Because the measured value for the closest reflected wave will be output from the sensor when an HL-G1 series specular reflection-type unit measures a multi-reflecting reflector such as transparent glass, only surface measurement is possible.

To accurately measure the surface of a transparent object, it is necessary to separate the reflected wave from the front surface and the reflected wave from the back surface.

The following chart summarizes the thicknesses of glass that can be measured.

Model name	HL-G103A-R□	HL-G105A-R□	HL-G108A-R□
Measurable glass thickness (index of refraction of 1.55)		2.0 mm or more	4.0 mm or more

# **2**I/O Terminal Block

This chapter provides information on the I/O lines of the sensor head.

2-1 Functions and Arrangements of I/O Terr	nina
Block · · · · · · · · · · · · · · · · · · ·	2-2
<b>2-2</b> I/O Circuit· · · · · · · · · · · · · · · · · · ·	2-4
2-3 Analog Output Circuit·····	2-6
2-4 Timing Chart · · · · · · · · · · · · · · · · · · ·	2-7
2-5 Conditions When Output Data Become	
Unfixed	2-9

# **2-1** Functions and Arrangements of I/O Terminal Block

#### **Analog Output Lines**

No.	Name	Function	Wiring color	
7	A(V)	Analog voltage output	Shield single	Black
8	AGND	Analog ground	conductor	Біаск
9	A(I)	Analog current output	Shield single	Cmaxx
10	AGND	Analog ground	conductor	Gray

#### I/O Terminal Block

No.	Name	Function	Wiring color	
1	OUT1	Judgment output 1 Black		ick
2	OUT2	Judgment output 2	White	
3	OUT3	Judgment output 3 or alarm output	Gray	
4	TM	Timing input	Pink	
5	MI	Multi-input Zero-set ON, Zero-set OFF, Reset, Memory change, Teaching, Save, and Laser Control inputs		olet
6	NP	NPN/PNP type switching input Pink/Viole		Violet
11	+SD	Transmission data Twisted-		Green
12	-SD	Transmission data	pair wire Sky Blue	
13	+RD	Reception data	Twisted- Orange	
14	-RD	Reception data pair wire		Yellow
15	SG	Signal ground	Shield	
16	+ V	24 VDC input for power supply	Brown	
17	0V	Power supply ground	Blue	

#### **O**CHECK


Line colors on a label for connection included in sensor head produced before December 2010 describes line colors before this modification. Therefore, kindly confirm the following content before use.

#### Content of Modification

No.	Before changes				After	
INO.	Name	Function	Wiring color			Wiring color
11	+SD	Transmission data	Twisted-	Black	<b></b>	Green
12	-SD	Transmission data	pair wire	White		Sky Blue
13	+RD	Reception data	Twisted-	Orange		Orange
14	-RD	Reception data	pair wire	White		Yellow

\* Multi-input wire (MI) varies with the period of input as shown below.

Period of input	Function
30 ms	Zero-set ON
80 ms	Reset
130 ms	Memory change (M0)
180 ms	Memory change (M1)
230 ms	Memory change (M2)
280 ms	Memory change (M3)
330 ms	Teaching a (Determines displacement judgment value a)
380 ms	Teaching b (Determines displacement judgment value b)
430 ms	Zero-set OFF (Cancel)
480 ms	Save
530 ms	Laser ON
580 ms	Laser OFF



Enter MI input for the desired period with a tolerance of  $\pm 10$  ms (T $\pm 10$  ms).


Two or more MI inputs can be entered in sequence on the condition that a minimum interval of 10 ms is set between adjacent MI inputs.


#### **O**CHECK

- No SD/RD lines are prepared for HL-G1 $\square$ -A-C5 standard types.
- The action of NP switching input is determined by the input state of the sensor head with the power turned ON.
- The sensor head does not save setting changes made over the multi-input line. Save the settings over the multi-input line, through the panel, with the communications command, or with the operation of the console if the settings need to be maintained after the system is turned OFF.


# 2-2 I/O Circuit


■ When using with NPN output (Connect NP switching input to 0V)






# ■ When using with PNP output (Connect NP switching input to +V)





# 2-3 Analog Output Circuit




#### **O**CHECK


- Do not short-circuit the analog output terminals or apply voltage to them.
- Use shielded wires for the analog output terminals.

# 2-4 Timing Chart


• NORMAL measurement (with timing mode set to "Hold")



• NORMAL measurement (with timing mode set to "One-shot")



#### PEAK measurement



\* The function of multiple input varies with the period of input.

Zero set ON: 30ms Zero set OFF: 430 ms Reset: 80 ms

Laser ON: 530 ms Laser OFF: 580 ms

- A zero set will be enabled by timing input while the HOLD status is valid.
- A reset input by timing input during the HOLD status will cause a data unfixed status. The system will hold this status until the timing input is cancelled.
- No zero set will be enabled while the data unfixed status is kept on hold.
- The system will hold reset input while the data unfixed status is valid until the timing input is cancelled.
- Judgment output is determined by the measured value and "displacement judgment". The output will become LO judgment while the data unfixed status is valid.
- When any data unfixed status other than that caused by reset input is valid, the console displayed value, analog output, and judgment output will become the same in performance.
- Analog output during the data unfixed status is indicated by the initial setting.
- If the system has been set to "Offset", the offset value will be added when a zero set is executed.
- If a zero set is executed during PEAK to PEAK measurement, the present measurement value will become zero (i.e., the reference value of measurement). Therefore, the measurement value will start from a negative (-) value if the system is reset while a zero set is executed.
- If "digital output at alarm" is fixed, the judgment output of the sensor head will be interlocked with the fixed value.

#### Processing of zero set/timing/reset inputs

	On timing input	Reset input (during data unfixed time)
Zero set input (ON/OFF)	Reflected at the time of zero set input (on console displayed value and analog output).	
Timing input		The data unfixed status is kept on hold.
Reset input	A data unfixed status will occur at the time of reset input (HOLD status while timing input is ON).	

#### Function of timing input (level)


Analysis mode	Function
NORMAL measurement	The measurement value will be kept on hold with timing input turned ON in this mode, and the hold status will be canceled with the timing input turned OFF.
measurement VALLEY	The measurement value will be kept on hold at the moment the input signal turned ON in this mode, and the hold status will be canceled with the input signal turned OFF. The peak (bottom) value will be reset when the HOLD status is cancelled.
	The measurement value will be kept on hold at the moment the input signal is turned ON in this mode, and the hold status will be canceled with the input signal turned OFF. The data will be set to zero when the HOLD status is cancelled.

## 2-5 Conditions When Output Data Become Unfixed

The operation status will be judged as a data unfixed status (i.e., there is no determined data) immediately after settings changes are made, the system is reset, or laser stop input is turned ON. This status is not an alarm status.

The data unfixed status starts at the time of restarting measurement after setting refreshment or resetting until the number of data measurement times reaches an average. Under the data unfixed status, a digital output of -999.9999 [mm] and an analog output of  $11.000 \, \text{[V]}$  or  $21.6 \, \text{[mA]}^{*1}$  will be turned ON.

- \*1 This is the initial value. Under the data unfixed status, the analog output of the system can be changed to a fixed value. For more information, → refer to "3-3-7 Alarm Settings" "Analog Output at Alarm".
- \*2 Under the data unfixed status, the zero set input will be ignored.
- \*3 For cancelling the data unfixed status, > refer to Chapter 5 "Troubleshooting".



	Data unfixed status	Alarm status
Status	Measurement data is unfixed. (Average buffer has not reached the setting number of times.)	Measurement disabled status due to poor light intensity or when the target object is off the measurement range.
Measurement Value Display		The previous value (default) is kept on hold.
Analog output	The previous value (default) is kept on hold.	The previous value (default) is kept on hold.
Digital output (High function type only)	-999.9999 [mm]	The previous value (default) is kept on hold.
Judgment Output	LO judgment	Interlocks with digital output
Alarm output	Interlocks with alarm status	ON

The following conditions will result in the data unfixed status.

- Reset input after the power is turned ON
- Sampling cycle switching
- Initialization
- Laser control interruption
- Average times switching
- \* There are cases where the data unfixed status does not occur depending on the setting conditions.

# 3

# **Functions**

This Chapter provides information on the functions of the system.

3-1 Classification of Functions3-2
3-2 Function List & Initial Values3-2
3-3 Operation of Each Function3-5
3-3-1 Basic Operation3-5
3-3-2 Memory Change 3-11
3-3-3 Sensing Setting 3-13
3-3-4 Data Processing Settings 3-16
3-3-5 Output Settings
3-3-6 Analog Settings 3-30
3-3-7 Alarm Settings 3-33
3-3-8 COM Settings 3-36
3-3-9 System Settings 3-41
3-3-10 Other System Settings3-45
3-3-11 Measurement Control with External
Input 3-47
3-3-12 Buffering Settings (High-function type
only)3-50

# 3-1 Classification of Functions

In this system, all functions are classified into eight categories to ensure stable measurement and various outputs.

Classification	Panel display	Function		
Sensing Settings	Pro I	Function settings for precise and stable measurement by controlling the received light intensity of the sensor.		
Data Processing Settings	Prod	Function settings for processing measurement values.		
Output Settings	Pro3	Function settings related to output data processing.		
Analog Settings	Pray	Function settings related to analog output processing.		
Alarm Settings	ProS	Function settings related to alarm output processing.		
COM Settings	ProB	Function settings related to communication.		
System Settings	Prol	System settings such as "Initialization," "Save," and communications settings.		
Buffering Settings	*	Function settings related to buffering.		

<sup>\*</sup> This function is available to high-function type serial communication for which no panel settings are possible.

## 3-2 Function List & Initial Values

Class	Function	Details Initial value		Ref. page
	Memory Change	Changes memory for saving the setting contents.  Default: M0	☆	3-11
settings	Sampling Cycle	Sets the sampling cycle for measurement.  Default: 500 µs	0	3-13
Sensing set	Controls the receiving light intensity of the sensor according to the amount of reflected light from measurement targets.  Default: Auto			
Š	Light Intensity Monitor	Checks the current received light intensity.		3-15
sing	Average Times	Sets the average number of times of moving average.  Default: 1024	0	3-16
cess	Analysis Mode	Sets the analysis mode. Default: Normal measurement	0	3-17
a Process Settings	Span	Sets the measurement coefficient. Default: 1.0000	0	3-19
Data Processing Settings	Offset	Sets the measurement offset. Default: 00000 mm	0	3-21
	Zero-set OFF	To release the zero-set state. Default: OFF	0	3-22

Class	Fur	nction	Details Initial value			Ref. page	
Output Settings	Judgment Output Selection		Sets the operation of the output block. Default: 2-state		0	3-23	
	Displace Threshold a Threshold b		Sets threshold a and threshold b.	Default: +(detection range) Default: -(detection range)	0	3-25	
nt Sc	Judgment	Hysteresis	Sets the hysteresis.	s the hysteresis. Default: +(0.2% of setting range)			
Outp	Judgment Delay	Output OFF	Delays the timing of from ON.	of judgment output switched OFF Default: OFF	0	3-27	
	Measurem Display on		Turns OFF the righ	tmost digits on the digital display. Default: SET 1	0	3-29	
	Analog Ou Selection	tput	Selects the desired voltage output.	output type from current output and  Default: Current output	0	3-30	
ings		Meas A		Default: Negative measurement range	0		
Sett		Meas B	Performs scaling the analog current	Default: Positive measurement range	0		
Analog Settings	Analog	Current a	output and the	Default: +4.000 mA	0	2 21	
Ā	Scaling	Current b	analog voltage	Default: +20.000 mA	0	3-31	
		Voltage a	output to any desired value.	Default: 0.000 V	0		
		Voltage b	desired value.	Default: 10.000 V	0	1	
sbu	Analog Output at Alarm		Sets the analog output status at alarm operation.  Default: Holds previous value		0	3-33	
Alarm Settings	Digital Output at Alarm		Sets the digital output status at alarm operation.  Default: Holds previous value		0	3-34	
Alar	Alarm Delay Times		Holds the previous normal value up to the setting number of times if an alarm is issued. Default: 8 times		0	3-35	
	Terminating Resistor Selection		Selects the terminating resistor for the sensor head connecting to the host device over RS-422/485.  Default: R3		☆	3-36	
COM Settings	Sensor no.		Sets the number of each sensor head multi connected to an RS-485 device.  Default: 01		☆	3-37	
S W	Baud rate		Sets the communication	ation speed. Default: 38400 bps	☆	3-38	
8	Connection Mode		Selects the performance settings for measurement data output to the host device. Default: RS-485 Multiple		☆	3-39	
	Sending Delay Time			delay time in response to each red from the host device. Default: 0ms		3-40	
	Timing Mo	de	Sets the timing inpu	at mode. Default: Hold	☆	3-41	
	Laser Con	trol	Switches laser emission/stop. Default: Emission		☆	3-42	
System Settings	Eco Mode		Turns OFF the LED indicators on the control panel for energy saving while the system is in RUN mode.  Default: Eco OFF		☆	3-43	
stem	View Versi	on	Displays the program version of the sensor.		-	3-44	
Sy	Initializatio	n	Initializes the memory settings currently in use.		×	3-45	
	Save		Saves all memory settings.		×	3-46	
	Timing		Holds the measurement value. Default: OFF		-	3-47	

Class	Function	Details Initial value		Ref. page
	Zero-set Sets the measurement value to zero.		-	3-47
	Reset	Resets the measurement value. Default: OFF		3-49
	Buffering Mode	Sets the buffering mode. Default: Continuous mode	☆	3-52
	Buffering Rate	Loads measurement data for a long duration by decimating the measurement data during data accumulation.  Default: 1/10	☆	3-53
	Accumulated Amount	Sets the amount of accumulated data.  Default: 3000 data items	☆	3-53
sbı	Trigger Point	Sets the trigger generation position in the accumulated data.  Default: 300	☆	3-54
Suffering Settings	Trigger Delay	Delays the timing of accumulation after the trigger generation.  Default: 0	☆	3-54
Bufferin	Trigger Conditions	Sets the conditions of trigger generation.  Default: At timing input ON	☆	3-55
ш	Buffering Operation	Starts buffering with buffering-related parameters set in advance.		3-56
	Status Readout	Checks the operation status of accumulation.	-	3-56
	Last Data Point	Reads out the accumulation status from the amount of measurement data.	-	3-56
	Binary Readout of Buffering Data	Reads out the accumulated data.	-	3-57

- \* Memory change
- O: Up to four types of settings can be saved by performing memory change.
- ×: Settings cannot be changed by performing memory change.
- ☆: Settings are saved as common settings for all memories. Settings cannot be executed on a memory-to-memory basis.

#### **OCHECK**

- COM settings and buffering settings are functions dedicated to the high-function type. These settings are not used for the standard type.
- Buffering settings cannot be made through the control panel. Make settings with serial communications commands.
- Each set value is saved in either one of the following ways depending on the operating method selected.
- <Control panel of sensor head>

Press the [ENTER] key to save after a set value change is made.

<Serial communications command (High-function type only)>


Execute the "Save" command after making a setting change.

The execution of the "Save" command is required after making a setting change in the case of using the Setting and Monitoring Software HL-G1SMI for the dedicated console (sold separately).

# 3-3 Operation of Each Function

## 3-3-1 Basic Operation

#### ■ Panel Configuration



(1) [ENTER] Key

Used to enter items.

(2) Digital Display

Displays measurement values, set values, and system errors.

(3) [UP] Key

Used to select items.

(4) [DOWN] Key

Used to select items.

#### Digital Display

The decimal point position varies with each model.

Measurement value and set value

Data unfixed status

Alarm status with the "digital output at alarm" set to a fixed value.


HL-G103-□
HL-G105-□/HL-G108-□/HL-G112-□
HL-G125-□

HL-G125-□

#### Basic Operation

The following section explains how to operate the system in RUN mode after the system is turned ON, make function changes in the system, and reset the system to RUN mode, along with the shortcut functions of the system in RUN mode.

The operation of the system common to each function is explained below. For more information on settings peculiar to the respective functions, → refer to "3-3-2 Memory Change" through "3-3-9 System Settings."



#### (1) RUN mode

The measurement value will appear on the digital display in this mode.

The system will be set to this mode when the system is turned ON.

RS-422/485 write and read commands will be received while the system is in this mode.

#### (2) Setting mode

Use this mode to make setting changes.

RS-422/485 write commands cannot be received while the system is in this mode.

An error code indicating that the system is in setting mode will be returned if a write command is received.

Refer to the next page for the transition of the screen while the system is in setting mode.

#### (3) Zero set

The measurement value will be set to zero in this mode.

#### (4) Reset

The measured value kept on hold by the system in measurement mode will be reset.

#### (5) Threshold a

The screen will change to the threshold-a setting screen.

#### (6) Threshold b

The screen will change to the threshold-b setting screen.

#### (7) Initialization


Initialization deletes all settings and returns them to the factory default settings.

## Supplemental remarks


Setting changes in the control panel of the sensor head will be saved in the internal memory.


#### • Making Setting Value Changes

"Span," "Offset," "Displacement judgment," "Analog scaling," "Number of alarm delay times" setting values can be changed freely.



## ■ Screen Transition in Setting Mode





- \*1 Not displayed when "Voltage" is selected for "Analog Output Selection."
- \*2 Not displayed when "Current" is selected for "Analog Output Selection."

## 3-3-2 Memory Change

nnr

The memory to save setting contents can be changed with M0 through M3.

Setting	Function	Panel display
MO	Memory M0	- AO
M1	Memory M1	ňl
M2	Memory M2	70
M3	Memory M3	Ĺ,

<sup>\*</sup> indicates the default value.

#### **OCHECK**

- Select the first number to be changed when the system goes into setting mode.
- Data unstability may result when the memory change is executed.
- If setting changes are made with a serial communications command, save the changes so that the changes will be reflected when the system is turned ON again.

#### Setting Procedure

1 Display the "Memory Change" screen while the system is in setting mode.



2 Press the [ENTER] key. The memory will be displayed.





3 Press the [UP]/[DOWN] key to make memory changes. (Example: Changing the memory to "M3".)





4 Press the [ENTER] key to determine the memory.





#### Memory Saving Settings

Each function that has been set can be saved in four ways in the memory area in the sensor head.

Measurement and judgment conditions can be saved individually according to the type of measurement object. Therefore, memory number changes will be possible without entering the set values for a wide variety of functions.

Memory changes are made with external commands and settings in the control panel.

#### Storable Functions in Memory

The function settings that can be stored in the memory are divided into two types. One of them can be stored in each specified memory number and the other one can be stored as setting values common to all memories.

For the above two types of storable functions in detail, → refer to "3-2 Function List & Initial Values".

## 3-3-3 Sensing Setting

Prol

■ Sampling Cycle

SAAPL

This function is used to make measurement cycle settings.

#### TECHN I QUE

When measuring an object with poor received light intensity, such as black rubber, extend the sampling cycle to get sufficient light to perform stable measurement.

Cycle	Frequency	Panel display	Meas. object
200 μs	5 kHz	200	Bright
500 μs	2 kHz	500	of meas. object
1 ms	1 kHz		Brightness of
2 ms	500 Hz	2000	Dark

<sup>\*1</sup> The measurement range may become narrow depending on measurement object type.

#### • Setting Procedure

Display the "Sensing Setting" screen while the system is in setting mode.



Press the [ENTER] key. The "Sampling Cycle" screen will be displayed.





3 Press the [ENTER] key. The present sampling cycle will be displayed.





4 Press the [UP]/[DOWN] key to make sampling cycle changes. (Example: Changing the sampling cycle to 1 ms.)





**5** Press the [ENTER] key to determine the sampling cycle.





<sup>\*2</sup> indicates the default value.

#### ■ Shutter Time



The shutter time controls the receiving light intensity of the sensor according to the amount of reflected light from measurement targets.

If the shutter time is set to AUTO, the light intensity feedback function automatically controls the light intensity to an optimum level. In the case of fixing the shutter time, use the light intensity monitor and select a fixed value of approximately 1000 to 1300.

Setting	Function	Initial value
AUTO	Shutter time automatic setting	Ruko
1 to 31	Fixed (See the table below.)	nuco

#### Setting Procedure

Display the "Sensing Setting" screen while the system is in setting mode.



Press the [ENTER] key. The "Sampling Cycle" screen will appear.





3 Press the [DOWN] key once. The "Shutter Time" screen will be displayed.





4 Press the [ENTER] key. The present shutter time will be displayed.





Press the [UP]/[DOWN] key to make shutter time changes. (Example: Changing the shutter time to 31.)





6 Press the [ENTER] key and determine the shutter time.





The following table shows the relation between the set values for shutter time and actual shutter apertures.

Set value	Shutter						
Set value	aperture						
AUTO	Auto	8	0.24%	16	1.95%	24	15.9%
1	0.04%	9	0.31%	17	2.54%	25	20.7%
2	0.05%	10	0.40%	18	3.30%	26	26.9%
3	0.06%	11	0.53%	19	4.29%	27	35.0%
4	0.08%	12	0.68%	20	5.58%	28	45.5%
5	0.11%	13	0.89%	21	7.25%	29	59.2%
6	0.14%	14	1.16%	22	9.43%	30	76.9%
7	0.18%	15	1.50%	23	12.3%	31	100%

## 

This function is used to check the current received light intensity.

The peak light intensity will be displayed in a range of 0 to 4095.

#### • Setting Procedure

1 Display the "Sensing Setting" screen while the system is in setting mode.



Press the [ENTER] key. The"Sampling Cycle" screen will appear.





Press the [DOWN] key twice. The "Meas Suf Selection" screen will be displayed.





**4** Press the [ENTER] key. The present light intensity will be displayed.





## 3-3-4 Data Processing Settings

Prod

■ Average Times

RUE

This function is used to set the average number of times of moving average. Use the function to stabilize unstable measurement values (including variations).

Setting	Function	Panel display
1 time	1-time moving average processing	-
4 times	4-time moving average processing	<b>4</b>
16 times	16-time moving average processing	[ 18]
64 times	64-time moving average processing	<b>5</b> 4
256 times	256-time moving average processing	258
1024 times	1024-time moving average processing	1024

<sup>\*</sup> indicates the default value.

#### **OCHECK**

Data unstability may result until the movement average buffer reaches the setting number of times. When the data becomes unstable, the analog output, digital output and judgment output will change. ( refer to "2-5 Conditions When Output Data Become Unfixed"). If there is an alarm when the moving average buffer is cleared, moving averaging will start after the alarm state is cleared. Moving averaging based on the previous data will be performed if an alarm occurs until the setting number of times is reached after moving averaging starts.

#### Setting Procedure

1 Display the "Data Processing Setting" screen while the system is in setting mode.



Press the [ENTER] key. The "Average Times" screen will be displayed.





3 Press the [ENTER] key. The present number of average times will be displayed.





Press the [UP]/[DOWN] key to change the number of average times. (Example: Changing the number of average times to 256.)





5 Press the [ENTER] key and determine the number of average times.






# ■ Analysis Mode **RARLY**

This function is used to set the analysis mode.

The following table shows the function of each analysis mode.



\* indicates the default value.

#### TECHN I QUE

Peak to Peak can be used for vibration or eccentricity measurement.

#### Setting Procedure

- 1 Display the "Data Processing Setting" screen while the system is in setting mode.
- Prod

- 2 Press the [ENTER] key. The "Average Time" screen will be displayed.
- ENTER FLIE
- 3 Press the [DOWN] key once. The "Analysis Mode" screen will be displayed.



**4** Press the [ENTER] key. The present analysis mode will be displayed.



Fress the [UP]/[DOWN] key to make analysis mode changes. (Example: Switching to PEAK to PEAK mode.)





**6** Press the [ENTER] key to determine the mode setting.






# ■ Span **SPAn**

The system can output measurement values with a span (factor) multiplied.

Final measurement value = Span x measurement value + offset



Setting range	Function	Initial value
0.1000 to +9.9999	Set a span in a range from 0.1000 to +9.9999.	<u> </u>

#### **OCHECK**

The display limit of the measurement value is  $\pm 95.000$ . Make sure that the setting value does not exceed the display limit.

#### Setting Procedure

1 Display the "Data Processing Setting" screen while the system is in setting mode.



**2** Press the [ENTER] key. The "Average Time" screen will be displayed.



3 Press the [DOWN] key twice. The "Span" screen will be displayed.



4 Press the [ENTER] key. The present span will be displayed. The leftmost digit will be selected.



5 Press the [UP]/[DOWN] keys together to change the selected digit. After all the changed digits have blinked the sign can be changed. For details, refer to page 3-8 "Making Setting Value Changes."



Press the [UP]/[DOWN] key to change the value of the selected digit. (Example: Changing the value to 2.0000.)





Press the [ENTER] key to determine the span.





#### ■ Offset



A desired setting value can be added to/subtracted from the measurement value.

#### TECHN I QUE

Measurement judgment will be possible from an offset in combination with "displacement judgment" by setting the size of the master workpiece (reference measurement object) for the offset, measuring the master workpiece, and turning the "zero set" ON.

Setting range	Function	Initial value
-95000 to +95000	-Set an offset in a range from 95000 to +95000. (The decimal point position varies with each model.)	

#### O CHECK

- Set "Offset" and turn "Zero Set" ON to make the setting value an offset value.
- The display limit of the measurement value is ±95000. Make sure that the setting value does not exceed the display limit.

#### Setting Procedure

1 Display the "Data Processing Setting" screen while the system is in setting mode.



2 Press the [ENTER] key. The "Average Time" screen will be displayed.





3 Press the [DOWN] key three times. The "Offset" screen will be displayed.





4 Press the [ENTER] key. The present offset value will be displayed. The leftmost digit will be selected.





5 Press the [UP]/[DOWN] keys together to change the selected digit. After all the changed digits have blinked the sign can be changed. For details, refer to page 3-8 "Making Setting Value Changes."



6 Press the [UP]/[DOWN] key to change the value of the selected digit or its sign. (Example: Changing the value to +2.500 [mm].)





7 Press the [ENTER] key and determine the offset value.





# ■ Zero-set OFF ☐-clr

This function cancels the zero set for measurement values.

Setting	Function	Panel display
Reset	The zero set is not canceled.	YES
Hold	The zero set is canceled.	מח

#### Supplemental remarks

- External multi input (MI) can turn the zero set ON and OFF. (→ refer to "2-1 Functions and Arrangements of I/O Terminal Block.")
- Setting Procedure
  - 1 Display the "Data Processing Setting" screen while the system is in setting mode.



**2** Press the [ENTER] key. The "Average Time" screen will be displayed.





3 Press the [DOWN] key four times. The "Zero-set OFF" screen will be displayed.





**4** Press the [ENTER] key. "Yes/No" will be displayed.





5 Press the [UP]/[DOWN] key to make "Yes/No" changes. (Example: Maintaining the zero-set state.)





**6** Press the [ENTER] key.





## 3-3-5 Output Settings




#### 

This function makes it possible to select the operation of the output block.

An alarm will not be output if "3-state" is selected.

The final decision process is done in digital measurements. When an alarm is turned ON, the value will be set to +999.9999 with which judgment processing will be performed, provided that a fixed value has been set with "digital output at alarm".



\* indicates the default value.

#### **OCHECK**

OUT3 settings are related to the operation of the output lines. An alarm is output through the OUT3 output line unless a 3-state value has been set. The OUT3 indicator on the sensor head and the OUT3 output readout function, however, will be turned OFF without being interlocked with the alarm. Check the alarm state with the alarm indicator and alarm readout function.

#### Setting Procedure

1 Display the "Output Setting" screen while the system is in setting mode.



2 Press the [ENTER] key. The "Judgment Output Selection" screen will be displayed.





3 Press the [ENTER] key. The present output type will be displayed.





4 Press the [UP]/[DOWN] key to make output type changes. (Example: Changing the output type to "Independent.")





5 Press the [ENTER] key to determine the output type.





## ■ Displacement Judgment

This function is used to set an upper limit (threshold a), lower limit (threshold b), and hysteresis for the judgment of measurement values.

Item	Panel display Setting range		Function
Threshold a	FX-8	-95000 to +95000	Sets threshold a,
Threshold b	FX-P	-95000 to +95000	threshold b and
Hysteresis	HY5	0 to +95000	hysteresis.

Supplemental remarks The following default values apply.

4	The felic wing default values upply.					
	Diffuse reflection			Specular reflection		
Type	Threshold	Threshold	Hystere	Threshold	Threshold	Hystere
	а	b	sis	а	b	sis
30 mm	+4mm	-4mm	8µm	+2mm	-2mm	8µm
50 mm	+10mm	-10mm	20µm	+5mm	-5mm	20µm
85 mm	+20mm	-20mm	40µm	+10mm	-10mm	40µm
120 mm	+60mm	-60mm	120µm	-	-	-
250 mm	+150mm	-150mm	300µm	-	-	-

#### **O**CHECK

- Set the value so that |Threshold a Threshold b| is larger than the hysteresis  $\times$  2.
- The decimal point position varies with each model.

#### TECHNIQUE

Pressing [▲] for at least 2 seconds will set Threshold a. Also, pressing [▼] for at least 2 seconds will set Threshold b.

- Setting Procedure(Setting Threshold a)
- 1 Display the "Output Setting" screen while the system is in setting mode.



2 Press the [ENTER] key. The "Judgment Output Selection" screen will be displayed.



3 Press the [DOWN] key once. The "Threshold a" screen will be displayed.



4 Press the [ENTER] key. The present threshold will be displayed. The leftmost digit will be selected.



5 Press the [UP]/[DOWN] keys together to change the selected digit. After all the changed digits have blinked the sign can be changed. For details, refer to page 3-8 "Making Setting Value Changes."





**6** Press the [UP]/[DOWN] key to change the selected digit or its sign. (Example: Changing the value to +5 [mm].)





7 Press the [ENTER] key to determine the threshold.





# ■ Judgment Output OFF Delay


This function delays the timing of switching ON to OFF of judgment output.

#### TECHNIQUE

This function is useful for applying output to a control device when the output is changing at high speed.

Setting	Function	Panel display
OFF	Output according to the sampling cycle.	۵۶۶
2 ms	2-ms OFF-delay	272
4 ms	4-ms OFF-delay	442
10 ms	10-ms OFF-delay	1042
20 ms	20-ms OFF-delay	20AS
40 ms	40-ms OFF-delay	4042
100 ms	100-ms OFF-delay	10045
Hold	Output once turned ON will be kept on hold. The output kept on hold will be released with reset input.	Hol d
*	indicates the default value	

<sup>\*</sup> indicates the default value.



The solid lines shows OFF setting actions. OFF timing will be delayed according to the OFF-delay set time as shown by the dotted lines.

#### **OCHECK**

- If actual output is turned ON earlier than the OFF-delay set time, the OFF-delay set time will be enabled from the point where the output is turned OFF.
- If "Logic" or "Independent" or "2-state" is selected with the judgment output selection function, OUT3 (alarm output) will not be OFF-delayed regardless of OFF-delay settings.
- The output indicator will not be OFF-delayed.

- Setting Procedure
  - 1 Display the "Output Setting" screen while the system is in setting mode.



**2** Press the [ENTER] key. The "Judgment Output Selection" screen will be displayed.





3 Press the [DOWN] key four times. The "OFF-delay" screen will be displayed.





**4** Press the [ENTER] key. OFF-delay settings will be displayed.





Press the [UP]/[DOWN] key to make OFF-delay setting changes. (Example: Changing the setting to Hold.)





**6** Press the [ENTER] key to determine the OFF-delay setting.





## ■ Measurement Value Display on Panel

n-45P

The rightmost digits on the digital display can be turned OFF.

Setting	Function	Panel Display
FULL	All the digits are displayed.	FLILL
Set 1	The rightmost digit is OFF.	SEE I
Set 2	The rightmost two digits are OFF.	SEE 2

<sup>\*</sup> indicates the default value.

#### Setting Procedure

1 Display the "Output Setting" screen while the system is in setting mode.

Pro3

- 2 Press the [ENTER] key. The "Judgment Output Selection" screen will be displayed.
- ENTER OLI 51
- 3 Press the [DOWN] key five times. The "Measurement Value Display on Panel" screen will be displayed.
- SELECT N- d5P
- 4 Press the [ENTER] key. The "Measurement Value Display on Panel" screen will be displayed.
- ENTER SEL I
- 5 Press the [UP]/[DOWN] key to make a setting change for the measurement value display on the panel. (Example: Changing the present setting to Set 2.)
- SELECT SELECT
- **6** Press the [ENTER] key to determine the setting for the measurement value display on the panel.
- ENTER 5-655

#### • Set2 usage example

In this example "FULL" is changed to "Set2."



## 3-3-6 Analog Settings

Pray

■ Analog Output Selection



This function selects the desired output type from current output and voltage output.

The accuracy of selected analog output will be guaranteed.

Setting	Function	Panel display
Current	Output current	-all
Voltage	Output voltage	الم-ملك

<sup>\*</sup> indicates the default value.

- Setting Procedure
  - 1 Display the "Analog Setting" screen while in setting mode.



Press the [ENTER] key. The "Analog Output Selection" screen will be displayed.





3 Press the [ENTER] key. The present output type will be displayed.





4 Press the [UP]/[DOWN] key to make output type changes. (Example: Changing the output type to voltage output.)





5 Press the [ENTER] key to determine the output type.






## Analog Scaling

This function scales analog current output or analog voltage output to any desired value.

Measurement values A and B on any two measurement point can be scaled with currents a and b or voltages a and b on any two points. Analog output is turned ON according to the scaling set for analog output selection.



Item	Panel display	Setting range	Function	Initial value
Meas A	ñ-8	-95000 to +95000		Negative measurement range
Meas B	ŭ-b	-95000 to +95000	MI	Positive measurement range
Current a	c-8	+4.000 to 20.000	Make measurement value, current,	4000
Current b	c-P	+4.000 to 20.000	and voltage settings.	20000
Voltage a	u-8	0 to +10.000		
Voltage b	n-P	0 to +10.000		10,000

<sup>\*1</sup> Not displayed when "Voltage" is selected for "Analog Output Selection."

#### Supplemental remarks

The following default measurement values A and B apply.

Type	Diffuse reflection		Specular reflection	
Type	Meas. Val A	Meas. Val B	Meas. Val A	Meas. Val B
30 mm	-4 mm	+4 mm	-2 mm	+2 mm
50 mm	-10 mm	+10 mm	-5 mm	+5 mm
85 mm	-20 mm	+20 mm	-10 mm	+10 mm
120 mm	-60 mm	+60 mm	-	-
250 mm	-150 mm	+150 mm	-	-

<sup>\*2</sup> Not displayed when "Current" is selected for "Analog Output Selection."

#### **OCHECK**

- The display limit of the measurement value is  $\pm 95000$ . Make sure that the setting value does not exceed the display limit.
- Check the input range of your input device such as AD board before setting.
- The decimal point position of measurement values varies with each model.

#### Setting Procedure

Setting current a (current for measurement value A)

**1** Display the "Analog Setting" screen while in setting mode.



2 Press the [ENTER] key. The "Analog Output Selection" screen will be displayed.





3 Press the [DOWN] key twice. The "Current a" screen will be displayed.





4 Press the [ENTER] key. The present set value will be displayed. The leftmost digit will be selected.





5 Press the [UP]/[DOWN] keys together to change the selected digit. After all the changed digits have blinked the sign can be changed. For details, refer to page 3-8 "Making Setting Value Changes."





6 Press the [UP]/[DOWN] key to change the value of the selected digit. (Example: Changing the value to 5.000 [mA].)





7 Press the [ENTER] key to determine the set value.





# 3-3-7 Alarm Settings

ProS

## Analog Output at Alarm

RL-R

This function is used to set the analog output status at alarm operation.

Analog output in the alarm state (where measurement is disabled owing to lack of light) can be kept on hold or set to a fixed value selectively.

Setting Function		Panel display
Hold Holds the analog output immediately before the alarm.		Hol d
Fixed Value	Fixed-value output	FL

<sup>\*</sup> indicates the default value.

#### Supplemental remarks

- A fixed current output of 21.6 [mA] or voltage output of +11.000 [V] applies.
- The fixed value is applied to the side set with "Analog Output Selection."

#### **OCHECK**

- Check the input range of your input device such as AD board before setting.
- The above settings will apply when there is data unstability.

#### Setting Procedure

 Display the "Alarm Setting" screen while in setting mode.



2 Press the [ENTER] key. The "Analog output at alarm" will be displayed.





3 Press the [ENTER] key. The Hold/Fix will be displayed.





4 Press the [UP]/[DOWN] key to set the system to Hold/Fix. (Example: Changing the selection to the fixed value.)





5 Press the [ENTER] key to determine the set value.



RL-R

## ■ Digital Output at Alarm



This function is used to set the digital output status at alarm operation.

This function makes settings related to digital output (on the digital display block of the sensor head and measurement values over serial communication) in the alarm state (where measurement is disabled owing to lack of light). The digital data will be set to +99999 if the fixed value is selected. The measurement value immediately before the alarm will be displayed if the system is set to hold.

#### TECHN I QUE

Selecting the fixed value can detect the alarm issued status easily from the measurement result. With this convenient function, the alarm status can be confirmed as well when the measurement value is loaded by data buffering function.

Setting	Function	Panel display
Hold	Holds the digital output immediately before the alarm.	Hold
Fixed Value	Fixed-value output	FL

<sup>\*</sup> indicates the default value.

#### **OCHECK**

• If the alarm state occurs after the fixed value is selected, judgment output interlocked with digital output will be turned ON.

#### Setting Procedure

1	Display the "Alarm Setting" screen while in setting mode.		ProS
2	Press the [ENTER] key. The "Analog output at alarm" screen will be displayed.	ENTER	RL-R
3	Press the [DOWN] key once. The "Digital output at alarm" screen will be displayed.	SELECT	RL-d
4	Press the [ENTER] key. The present Hold/Fix will be displayed.	ENTER	Hal d
5	Press the [UP]/[DOWN] key to select Hold/Fix. (Example: Changing the selection to the fixed value.)	SELECT	FL
6	Press the [ENTER] key to determine the set value.	ENTER	RL-d

# ■ Alarm Delay Times │ 🖁



This function holds the previous normal value up to the setting number of times if an alarm is issued.

The previous normal value will be kept on hold up to the setting number of delay times if an alarm is issued (where measurement is disabled owing to lack of light).


Alarm output (OUT3) will be turned ON when the alarm status continues more than the setting number of delay times, and analog output and digital output will be turned ON according to the setting for analog output at alarm and the setting for digital output at alarm, respectively.

#### TECHNIQUE

This function is effective if the user does not require the output of instantaneous alarms resulting for the surface condition changes of measurement objects.

Setting range	Function	Initial value
0 to 65534	0 (OFF) to 65534 times	נייינו נייינו נייינו נייינו
65535	Holds the measurement value before the alarm.	[ 00008]

#### Setting Procedure





2 Press the [ENTER] key. The "Analog output at alarm" screen will be displayed.





**3** Press the [DOWN] key twice. The "Alarm Delay Times" screen will be displayed.





4 Press the [ENTER] key. The number of alarm delay times will be displayed. The leftmost digit will be selected.





5 Press the [UP]/[DOWN] keys together to change the selected digit.





6 Press the [UP]/[DOWN] key to change the value of the selected digit. (Example: Changing the value to 0 times (OFF).)





**7** Press the [ENTER] key and determine the number of delay times.



# 3-3-8 COM Settings



Make COM settings through the control panel. No COM settings are possible with serial communications commands.

## ■ Terminating Resistor Selection

LErn I

This function selects the terminating resistor for the sensor head connecting to the host device over RS-422/485.

Be sure to select R3 if the system is connected to RS-422 equipment.

If a number of sensor heads are connected to RS-485 equipment, set R3 for the terminating sensor and the rest of the sensors to OFF.

\* The communication of the system, if unstable, may be improved by selecting R1 or R2.

Setting	Function	Panel display
OFF	Turn OFF terminating resistors	مجج
R1	Terminating resistor R1	<b>-</b> !
R2	Terminating resistor R2	-2
R3	Terminating resistor R3	

<sup>\*</sup> indicates the default value.

#### Setting Procedure

1 Display the "COM Setting" screen while the system is in setting mode.



Press the [ENTER] key. The "Terminating Resistor Selection" screen will be displayed.





3 Press the [ENTER] key. The present terminating resistor will be displayed.





4 Press the [UP]/[DOWN] key to change the terminating resistor. (Example: Changing the resistor to OFF.)





5 Press the [ENTER] key to determine the terminating resistor.





■ Sensor No.

This function is used to set the number of each sensor head multi connected to an RS-485 device.

Be sure to set each connecting sensor head number with no duplication.

Setting range	Function	Initial value
01 to 16	Set sensor numbers 01 through 16 in sequence.	

- Setting Procedure
  - 1 Display the "COM Setting" screen while in setting mode.



2 Press the [ENTER] key. The "Terminating Resistor Selection" screen will be displayed.





- 3 Press the [DOWN] key once. The "Sensor No." screen will be displayed.



- **4** Press the [ENTER] key. The present sensor number will be displayed.
- ENTE



5 Press the [UP]/[DOWN] key to change the sensor number. (Example: Changing the sensor number to 16.)





### Supplemental remarks

Press the [UP]/[DOWN] keys together for at least 2 seconds to move the set value at high speed.

6 Press the [ENTER] key to determine the sensor number.





## ■ Baud Rate

# -REE

This function is used to set the communication speed.

Setting	Function	Panel display
9600	9,600 bps	327
19200	19,200 bps	1357
38400	38,400 bps	3847
115200	115,200 bps	115,24
230400	230,400 bps	230,45
460800	460,800 bps	48082
921600	921,600 bps	35 187

<sup>\*</sup> indicates the default value.

### **O**CHECK

• Lower the communication speed if stable communication with the host device is not possible.

#### Setting Procedure

1 Display the "COM Setting" screen while in setting mode.



Press the [ENTER] key. The "Terminating Resistor Selection" screen will be displayed.





3 Press the [DOWN] key twice. The "Baud Rate" screen will be displayed.





4 Press the [ENTER] key. The communication speed will be displayed.





5 Press the [UP]/[DOWN] key to make communication changes. (Example: Changing the communication speed to 115,200 bps.)





**6** Press the [ENTER] key to determine the communication speed.





### ■ Connection Mode



This function is used to select the performance settings for measurement data output to the host device.

Select the operation settings for measurement data output to the host device.

This section provides information on the condition that the RS-422 device is connected 1-to-1 and the RS-485 device is connected 1-to-N (sensor heads) to the system. For the connection method, → refer to "4-1 Communications Specifications - Connecting Example with External Device." For details of the dedicated output format, → refer to "4-2 Type and Format of Commands".

Setting	Connection method	Function	Panel display
RS-422 handshake		Transmits the result data (a response command) in response to a request command from the host device. All commands can be received.	422- 1
RS-422 Timing	IRS-477 Toutnut format when timing input is ON while		422-2
RS-422 Continuous		Transmits the measured value continuously in the exclusive output format after this mode is selected.	422-3
RS-485 Multiple	RS-485	Up to 16 sensor heads are connected to the host device. Transmits the result data (a response command) in response to a request command from the host device. No sensors outside the designated range will not respond.	485-ñ

<sup>\*</sup> indicates the default value.

#### Setting Procedure

1 Display the "COM Setting" screen while in setting mode.



Press the [ENTER] key. The "Terminating Resistor Selection" screen will be displayed.





3 Press the [DOWN] key three times. The "Connection Mode" screen will be displayed.





4 Press the [ENTER] key. The present connection mode will be displayed.





5 Press the [UP]/[DOWN] key to change the connection mode. (Example: Changing the connection to RS-485 multi connection.)





**6** Press the [ENTER] key to determine the connection mode setting.





## Sending Delay Time



This is a useful function if the connection mode is set to RS-485 multi.

Select the sensor's delay time in response to each command transmitted from the host device.

Setting	Function	Panel display	Setting	Function	Panel display
0	No delay time		10	Delay time 10ms	
0.1	Delay time 0.1ms		20	" 20ms	20
0.2	" 0.2ms		50	" 50ms	50
0.5	" 0.5ms		100	" 100ms	
1	" 1ms		200	" 200ms	200
2	" 2ms	7	500	" 500ms	500
5	" 5ms	5	1000	" 1000ms	

<sup>\*</sup> indicates the default value.

#### Setting Procedure

1 Display the "COM Setting" screen while in setting mode.



2 Press the [ENTER] key. The "Terminating Resistor Selection" screen will be displayed.





3 Press the [DOWN] key four times. The "Sending Delay Time" screen will be displayed.





**4** Press the [ENTER] key. The delay time setting will be displayed.





5 Press the [UP]/[DOWN] key to change the connection mode. (Example: Changing the delay time to 20 ms.)





**6** Press the [ENTER] key to determine the sending delay time setting.





#### OCHECK

When sending the next command after HL-G1 returns a response while the RS-485 is connected, leave time of at least 200µs or more.

# 3-3-9 System Settings

■ Timing Mode

This function is used to set the timing input mode.

Set the operation of the system with timing input turned ON.
For the operation of the system in this mode, refer to "2-4 Timing Chart."

Setting	Function	Panel display
Hold	Measurement hold with timing input	Hold
One Shot	Measurement variable with timing input	15Hat

- \* indicates the default value.
- Setting Procedure
  - 1 Display the "System Setting" screen while in setting mode.



2 Press the [ENTER] key. The "Timing Mode" screen will be displayed.





3 Press the [ENTER] key. Hold/One Shot will be displayed.





4 Press the [UP]/[DOWN] key to select Hold or One Shot. (Example: Changing the selection to "One Shot.")





5 Press the [ENTER] key to determine the set value.





# 

This function is used to select the laser emission/stop.

This function makes it possible to stop unrequired laser emission while the system is not in measurement operation.

Setting Function Pane		Panel display
Emission	Laser emission is ON	۵۵
Stop	Laser emission is OFF	off

<sup>\*</sup> indicates the default value.

#### **OCHECK**

The system will be in a data unficed state when the laser control is set to "Stop," and the data unstable state continues until "Emission" is set again.

The state returns to the measurement state when the laser is emitted again.

#### Setting Procedure

1	Display the "System Setting" screen while the system is in setting mode.		Pro?
2	Press the [ENTER] key. The "Timing Mode" screen will be displayed.	ENTER	<b>L</b> 1
3	Press the [DOWN] key once. The "Laser Control" screen will be displayed.	SELECT	LASEr
4	Press the [ENTER] key. The ON/OFF will be displayed.	ENTER	מח
5	Press the [UP]/[DOWN] key to select ON/OFF. (Example: Changing the selection to OFF.)	SELECT	off
6	Press the [ENTER] key to determine the set value.	ENTER	LASEr

# ■ Eco Mode **Eco**

This function turns OFF the LED indicators on the control panel while in RUN mode for energy saving.

Setting	Details	Panel display
Eco-OFF	Eco Mode is OFF.	E-055
Eco-ON	Only LEDs on the digital display will be turned OFF.	[E-an]
Eco-FULL	Other than LASER indicator, All the LEDs will be turned OFF.	E-FLIL

<sup>\*</sup> indicates the default value.

#### Supplemental remarks

- The display will be restored by switching while the LEDs are turned OFF while
  the system is in eco mode. The LEDs will be turned OFF again if the system is
  not operated for 20 seconds.
- The LEDs will be always lit while the system is in setting mode.

#### Setting Procedure

1 Display the "System Setting" screen while the system is in setting mode.



2 Press the [ENTER] key. The "Timing Mode" screen will be displayed.





3 Press the [DOWN] key twice. The eco mode screen will be displayed.





4 Press the [ENTER] key. The present mode setting will be displayed.





5 Press the [UP]/[DOWN] key to make mode changes. (Example: Changing the mode to Eco-FULL.)





6 Press the [ENTER] key to determine the mode setting.





■ View Version

This function is used to take the following procedure that displays the program version of the sensor.

- Setting Procedure
  - 1 Display the "System Setting" screen while in setting mode.



Press the [ENTER] key. The "Timing Mode" screen will be displayed.





3 Press the [DOWN] key three times. The "View Version" screen will be displayed.





4 Press the [ENTER] key. The present version will be displayed.





# 3-3-10 Other System Settings

#### Initialize

This function is used to delete all the setting contents in the memory and returns them to the factory default settings.

#### **OCHECK**


- When the initialization of the system is executed through the operation of the panel, all settings will return to the factory default settings. When the initialization of the system is executed through the operation of the panel, all settings except COM settings and environment settings will return to the factory default settings.
- The initialized setting contents will not be saved if the system is initialized with the communications command from the high-function type. To maintain the initialized state after the system is turned OFF, be sure to execute the "Save" command.
- When the "initialization" is executed, the data unfixed status may occur temporarily.

#### Setting Procedure

1 Turn ON the system while pressing the [ENTER] key.

The initial screen will be displayed after the startup screen appears.

The memory is initialized and the system is set to RUN mode.



#### Save

There is a difference in setting saving method between the operation of the panel and the use of the communications command.

Setting Changes in Control Panel of Sensor Head

Press the [ENTER] key and save the change in each item.

When the system is turned ON again, the last saved settings will be reflected.

• Setting Changes over RS422/485 Communication (High-function type only: E.g., communications command, dedicated console (sold separately), and Setting and Monitoring Software HL-G1SMI)

Be sure to execute "Save" to maintain setting changes after the system is turned ON again.

The timing input state cannot be saved. Timing input will be OFF right after the system is turned ON or a memory change is made.

Saving input over the multi-input (MI) line

Multi-input can be entered for a certain period to save settings made.

For details,  $\rightarrow$  refer to "2-1 Functions and Arrangements of I/O Terminal Block".

# 3-3-11 Measurement Control with External Input

### Timing

This function makes it possible to hold the measurement value at the desired timing.

The measurement value will be kept on hold with external input timing (TM). The judgment output is kept on hold as well simultaneously.

Timing settings can be executed with communications command but not with the operation of the panel.

For the operation of the system in this mode,  $\rightarrow$  refer to "2-4 Timing Chart".

#### TECHNIQUE

"Judgment Output" will be kept on hold by setting the timing input to "ON" at the desired timing. This enables loading of the judgment result at a later time.

#### **OCHECK**

- The timing input status cannot be stored by executing "Save". Timing input will be OFF right after the system is turned ON or a memory change is made.
- If the timing mode is set to "One Shot," the internal memory will be cleared (set to timing OFF) after one-shot processing is executed when timing ON is executed with a communications command.
- If the timing mode is set to "Hold," the external input status will be reflected on the memory.

#### Zero Set

This function makes it possible to set the measurement value to zero at the desired timing.

The measurement value can be set to zero at the desired timing by using external multi input (MI).

Input a specified pulse width as multi input.

Zero set settings can be executed with communications commands and the operation of the panel.

For the operation of the system in this mode,  $\rightarrow$  refer to "2-4 Timing Chart".

#### **OCHECK**

- An offset value will be set by executing "Zero Set" after setting the offset value.
- The sensor head does not save setting changes made over the multi-input line.
   Save the settings over the multi-input line, through the panel, with the communications command, or with the operation of the console if the settings need to be maintained after the system is turned OFF.

### • Setting Procedure

1 Press the [UP]/[DOWN] keys together while in Run mode. Zero Set will be executed.





#### ■ Reset

The function resets the measurement value.

At the time of making a peak measurement, valley measurement, or peak-to-peak measurement with external multi input (MI), the measurement value kept on hold at the desired timing can be reset.

Input a specified pulse width as multi input.

The pulse width can be input into the high-function type through a communications command.

For details, → refer to "2-4 Timing Chart".

#### TECHN I QUE

All judgment outputs will be turned OFF when "Reset" is executed. This function can be applied to judge each measurement object for peak, valley, or peak-to-peak measurements.

#### CHECK

- The data will be in an unfixed status when "Reset" is executed, and the analog output outputs the alarm set in the "Analog Output at Alarm" (initial value holds the analog output immediately before the alarm), and the judgment output becomes a HI judgment.
- If Reset ON is executed by a communications command, the memory contents will be cleared to zero after Reset is executed.

#### Setting Procedure

1 Press the [UP]/[ENTER] keys together while in Run mode.
Reset will be executed.





# 3-3-12 Buffering Settings (High-function type only)

Buffering is a function to accumulate measurement data in the sensor head memory and load them to external control devices.

A maximum of 3,000 measurement data items can be temporarily accumulated in the built-in memory of the sensor head before loading them to the external control device, such as a PC. All accumulated data can be loaded by using communication control over RS-422 or RS-485 or with the Setting and Monitoring Software HL-G1SMI.

#### TECHNIQUE

The Setting and Monitoring Software HL-G1SMI makes it possible to accumulate and retrieve measurement data with the operation of the mouse in the case of using the buffering function. This Intelligent Monitor SIM is useful for the confirmation or verification of measurement data because it converts the data into CSV data format. CSV data can be used for graphic display, save, replay of the measurement data, and opened in Excel.

#### Supplemental remarks


For buffering over RS-422/485, → refer to "4-3 Command List".

The Setting and Monitoring Software HL-G1SMI can be downloaded from the website of Panasonic Industrial Devices SUNX.

### **OCHECK**

- It is necessary to write a program over RS-422/485 to execute buffering.
- Buffering settings cannot be set through the control panel. Make settings with serial communications commands.

### ■ Data Buffering Operation



### **O**CHECK


No settings related to buffering can be changed while the system is in buffering operation. Change the settings after stopping the buffering operation of the system.

### ■ Buffering Mode

There are two types of buffering modes, either one of which can be selected. "Continuous Mode" is set by default.


#### Continuous Mode

- Data accumulation to the built-in memory of the sensor head start with the start of buffering.
- Accumulation will stop when the amount of accumulation reaches the setting value or when buffering operation stops.



#### Trigger Mode

- When buffering operation starts, trigger generation will be set to stand-by status.
- The measurement data before and after the trigger point where the trigger is generated is accumulated into the built-in memory of the sensor head.
- Accumulation will stop when the amount of accumulation reaches the setting value or when buffering operation stops.



### Buffering Rate

The buffering rate can be set for accumulating the measurement data for a long duration by taking adequate sampling cycle intervals.

Select from 1 (all measurement data), 1/2, 1/4, etc. to 1/65535.

The buffering rate is set to "1/10" by default.

If 1/4 is selected for example, measurement data will be accumulated once every four sampling cycles.

#### TECHNIQUE

All measurement data can be accumulated. If measurement data deviation is small at each sampling cycle, however, the duration of data accumulation longer than that performed per sampling cycle can be set with an appropriate accumulation interval of measurement data specified. This is useful for the effective use of memory since the accumulated amount of data items is limited.

#### Accumulated Amount

This function sets the accumulated amount of measurement data items.

This function sets the accumulated amount of measurement data items in a range of 1 to 3000.

The accumulated amount is set to "3000" by default.

### **O**CHECK

Accumulation will not start unless the "trigger point" settings for the "accumulated amount" of data items are correct.

### ■ Trigger Points

When the buffering mode is set to trigger mode, measurement data can be loaded by setting the data as a trigger point at the generation of the trigger.

The setting range is in a range of 1 to the "accumulated amount" of data items. The value is set to 300 by default.

#### **OCHECK**

- Accumulation will not start if the "trigger point" is set to a larger value than the setting "accumulation amount."
- If the "Trigger Delay" function is set, the system can load the measurement data from the trigger delayed data point after the setting trigger is generated.

### Trigger Delay

This function is used for delaying the timing of trigger detection when the buffering mode is set to trigger mode.

This function is used to set the number of sampling times for the trigger delay. The setting range is 0 to 65535.

The status during the trigger delay is indicated as "Accumulating." The trigger delay is set to "0" by default.

#### For trigger mode:

This function is used to load measured data between the moment the preset trigger is generated and the moment the delayed trigger point set by this function.

### **OCHECK**

When the buffering rate is already set, the trigger delay will be counted with the extended sampling in accordance with the setting.

### ■ Trigger Conditions


This function is used for setting the trigger generation conditions when the buffering mode is set to trigger mode.

A value the same as or higher or lower than a threshold or the time of alarm occurrence or release can be set as a trigger condition if timing input is ON. The value is set to "At timing input ON" by default.

#### □ CHECK

• Keep in mind that the "Alarm Delay Times" set will become effective if "At alarm occurred" is set as a trigger condition.

Ex) If the "Buffering Mode" is set to trigger mode, the operation of each trigger condition is shown below:



### **O**CHECK

Normally, the measurement value is kept on hold when timing input is ON. Only if the buffering mode is set to "trigger mode" and this function is set to "At timing input ON," however, the measurement value will not be kept on hold at the moment timing input is ON while the system is in buffering operation.

### Buffering Operation

This function accumulates data while the system is in buffering operation.

Set necessary parameters in advance and start buffering.

#### **OCHECK**

- All settings related to buffering cannot be changed during buffering.
- Non-buffering status cannot be set by only stopping buffering.

#### Status Readout

This function checks the status of measurement data accumulation.

Use this function for checking the accumulation status before reading out the accumulated data. When the status is checked, the sensor head responds one of the following conditions.

Status	Details			
Non-buffering	Buffering is not executed at all after turning on the power supply or after initialization or buffering is stopped while waiting for the trigger after buffering has started.			
Wait for Trigger	Waiting for the trigger after buffering has started.			
Accumulating	Buffering has started and measurement data is being accumulated or trigger has been generated and measurement data is being accumulated.			
Accumulation Completed	The accumulation amount has reached the setting value or buffering has stopped.			

#### Last Data Point

The accumulation status can be read out from the data amount.

The "Final Data Point" will be set to "0" when the "Status Readout" is set to Non-buffering or Wait for Trigger.

### ■ Binary Readout of Buffering Data

The accumulated measurement data in the sensor head memory can be read out.

Data in a range from 1 to the readout result of the last data point is specified and read out.

### **O**CHECK

To read out the buffering data, stop buffering and check the "Final Data Point." The accumulated data to the final data point can be read out only when the result of "Status Readout" is Accumulation Completed and the final data point is other than 0.



4

# **Communications Control**

This Chapter provides information on RS-422 and RS-485 communications control.

4-1 Communications Specifications 4-2
4-2 Type and Format of Commands-4-7
<b>4-2-1</b> Commands4-7
4-2-2 Command Formats4-9
4-3 Command List 4-19
4-4 Setting Address List 4-25

# 4-1 Communications Specifications

## Specifications

The system has the following specifications. The user can make setting changes according to the external host device in use.

Item	Setting		
	RS-422	RS-485	
Communication mode	Full duplex	Semi-duplex	
Communication speed	9,600/19,200/ <b>38,400</b> /115,200/230,400/460,800/ 921,600 bps		
Synchronization system	Start-stop transmission (Asynchronous)		
Transmission code	ASCII		
Data length	8 bits		
Parity check	None		
Stop bit length	1 bit		
End code	CR(0DH)		
BCC	Yes*1		

<sup>\*1</sup> To omit BCC calculation, enter "\*\*" (2AH, 2AH) to BCC.

### ■ Pin Arrangement


		Wiring color		Signal direction		
N	o. Wiring			HL-G1	External host device	Description
1	l Twisted-	Green	+SD	Output -	→ Input	Transmitted data signal (+) Usually connected to +RD (+RXD) of external device
1	pair wire	Sky Blue	-SD	Output -	→ Input	Transmitted data signal (-) Usually connected to -RD (-RXD) of external device
1	3 Twisted-	Orange	+RD	Input	Output	Received data signal (+) Usually connected to +SD (+TXD) of external device
1	pair wire	Yellow	-RD	Input	Output	Received data signal (-) Usually connected to -SD (-TXD) of external device
1	5 Shield		SG	← Connec	ted →	Signal ground Connected to SG (SG) of external device

<sup>\*2</sup> Settings in bold letters indicate default settings (before shipping).

### Connecting Example with External Device

#### • RS-422 1-to-1 connection


Select "RS-422 handshake", "RS-422 timing", or "RS-422 continuous" for the COM setting connection mode. Set the prefix to 01.



- (Note 1) The transmission data cable and reception data cable are both twisted-pair cables.
- (Note 2) The shield is connected to the 0-V side of the power supply line inside the sensor
- (Note 3) Be sure to connect the signal ground.
- (Note 4) The sensor is of non-isolated type. Make sure that the potential difference between the sensor and RS-422 connecting device does not exceed 4V. A difference in potential in excess may cause the connecting device or the sensor to malfunction.

#### RS-485 1-to-N connection

Select "RS-485 multi" for COM setting connection mode. Set the prefix with no duplication.



- (Note 1) The transmission data cable and reception data cable are both twisted-pair cables.
- (Note 2) The shield is connected to the 0-V side of the power supply line inside the sensor.
- (Note 3) Be sure to connect the signal ground.
- (Note 4) The sensor is of non-isolated type. Make sure that the potential difference between the sensor and RS-485 connecting device does not exceed 4V. A difference in potential in excess may cause the connecting device or the sensor to malfunction.
- (Note 5) The sensor has a built-in terminating resistor. Be sure to turn ON the terminating resistor of the terminating sensor.
- (Note 6) Perform transition wiring for the transmission path.

(Note 7) Connect the wires according to the specification of the top equipment. (Note 8) When sending the next command after HL-G1 returns a response while the RS-485 is connected, leave time of at least  $200\mu s$  or more.

#### Communications Protocol

- Make communications specification settings.
- 1. Make communications specification settings for the HL-G1.

The table in "4-1 Communications Specifications" - "Specifications" shows the communications specifications for the HL-G1. Make settings according to the operating conditions.

#### 2. Make communication specifications for the host device.

Read through the operation manual of the external host device and change the communications settings for the host device in conformity with the settings for the HL-G1. Otherwise, make settings for the HL-G1 in conformity with the settings for the external host device.

### Communications Condition Changes

When the baud rate is changed, save the setting and restart the sensor head so that the setting will be reflected.

# 4-2 Type and Format of Commands

### 4-2-1 Commands


### Data Transmission/Reception

#### • Data Transmission/Reception

This section explains how to set or change various parameters or confirm and read measurement values by sending commands from an external host device to the HL-G1.


#### (1) Normal sequence to read setting data

The following data transmitting/receiving sequence will be used when request communication data instructing setting data read (with the head character of the command on the request communication data set to R) transmitted from the external host device to the HL-G1 is normal.




### (2) Normal sequence to transmit/receive data on data setting or operation instruction

The following data transmitting/receiving sequence will be used when request communication data instructing setting data read (with the head character of the command on the request communication data set to W) transmitted from the external host device to the HL-G1 is normal.



#### (3) Abnormal sequence to transmit/receive data

The following data transmitting/receiving sequence will be used if request communication data transmitted from the external host device to the HL-G1 is abnormal (with data range error or garbled characters).



### 4-2-2 Command Formats

The following section explains seven types of command formats transmitted from an external host device to the HL-G1.


# General Purpose

The following command formats are used to read or make general measurement mode settings or operating conditions.


#### Read Command

Read command formats are used to read operating conditions.

#### Request communication data



#### Normal response data






Reading the sampling cycle setting value for sensor 01 in the RS-422 handshake mode or the RS-485 multi-mode

#### Request communication data




#### Normal response data




#### • Data Setting/Operation Instruction Command

Data setting/operation instruction command formats are used to make data settings or give operating instructions.

#### Request communication data



#### Normal response data






Setting an average number of 256 times for sensor 02 in the RS-485 multi-mode.

#### Request communication data



#### Normal response data




# FORMAT 2 Value Setting


The following value setting command formats are used to set seven-digit numeric values (measurement values and numeric values) with the decimal point omitted.

#### Read Command

Request communication data



#### Normal response data



7-character integral part (no zero suppress)


Ex

Reading the present measurement value for sensor 03 in the RS-485 multi-mode.

Request communication data




## Normal response data




## Data Setting/Operation Instruction Command

#### Request communication data




Normal response data

7-character integral part (no zero suppress)




Ex

Setting +5.5 [mm] as displacement judgment threshold a for sensor 04 in the RS-485 multi-mode.




#### Normal response data




## FORMAT 3 All Outputs Read

The following special command formats are used to read all measurement value, received light intensity, and judgment output conditions together.

#### Request communication data




#### Normal response data



Ex


Reading all "logic" outputs of judgment output selection for sensor 01 in the RS-422 handshake mode or the RS-485 multi-mode.





## ©RMAT 4 Normal Read of Buffering Data


The following special command formats are used to read buffering measurement data in 7-digit numeric sequence format.




## Read of Differential Data in Buffering Data

The following special command formats are used to read buffering measurement data in signed differential sequence format.

#### Request communication data



#### Normal response data



Data is stored in the following head data format in the specified head point. The difference from the previous data will be returned for data on the second point and each succeeding point.


#### Head data format:

1-character symbol + 7-digit integral part (no zero suppress)


<Example using the reply command shown above>

## FORMAT 6 Binary Read of Buffering Data

The following special command formats are used to read buffering measurement data in binary sequence format.



#### Normal response data




\* Binary data on each point of response data is in 4 bytes in order of the lowest byte to highest byte. (Little endian)

## RS-422 Timing (or RS-422 Continuous)

## **Output Mode**

The following dedicated command formats are used to output data if "RS-422 timing" or "RS-422 continuous" is selected in "3-3-8 COM Setting" - "Connection Mode".

#### Sensor transmission data



· RS-422 Timing


The measured value data when the timing input is turned ON will be output while the timing input is ON.

·RS-422 Continuous

Measured value data is output repeatedly in the above format on and after the RS-422 continuous output mode is selected.

# ■ Error Response

Error response data is common to all formats.



#### • Error code

Error code	Code type	Description					
01	Command error	The command is undefined.					
02	Address error	The start address is larger than the end address or the address is larger than 999999 when the RDD or WDD command is executed.  The address length has not reached the prescribed length when the RDD or WDD command is executed.					
03	Data error	The data length does not correspond to the command. The data length has not reached the prescribed length.					
04	BCC error	BCC check was not conformable.					
11	Communication error	A parity error occurred during data reception. A framing error occurred during data reception. An overrun error occurred during data reception.					
21	Control flow error	The system is in setting mode.					
22	Execution error	Calibration or analog scaling is not executable.					
31	Buffering condition error 1	An attempt was made to make a buffering setting change without stopping buffering.					
32	Buffering condition error 2	An attempt was made to start buffering with an inadequate buffering setting.					
33	Buffering condition error 3	Data was read after buffering operation started.  Data was read while the system was not in the accumulation completed status.  Data in excess of the final data point was specified and read.					


## **O**CHECK

• If an abnormal response is received, check if there are any errors such as transmission data errors. Correct such errors, if any. If an error occurs regardless of the absence of mistakes, it may be a temporal phenomenon caused by noise or other external reasons or the external host device may have a system error. Turn the sensor head or system turned OFF and ON.

#### ■ BCC

BCC is a horizontal parity check code used to improve the reliability of data communication. The exclusive OR is executed from the header (%) to final characters of communication data, and the exclusive OR in 8-bit data is converted to 2-character ASCII code. The sensor head is used to compare the exclusive OR from the header to final characters of the message received, and check if the exclusive OR coincides with the transmitted value of the PC. If the BCC at the time of transmission differs from that after reception, it indicates that some error has occurred in the message while in transmission. In the case of omitting BCC calculation, accommodate \*\* (2AH, 2AH) in the BCC. If data is transmitted with the BCC omitted, the BCC in the response data will be \*\* (2AH, 2AH) as well.

#### **BCC Creation Example**



# 4-3 Command List

## ■ Basic Settings

	Item Command		mand	Data	Data Description	
S			RSP WSP	+00000	200 [μs]	
ngs	Sampling	g RSP		+00001	500 [μs]	
etti	Sampling Cycle			+00002	1 [ms]	GODWA 1
sic S				+00003	2 [ms]	FORMAT
Bas	Shutter Time	RFB	WFB	+00000 to +00031	+00000: Auto +00001 to +00031: Fixed	

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## ■ Data Processing Settings

	Item	Com	mand	Data	Description	Format	
				+00000	Once		
				+00001	4 times		
	Average Times	RAV	WAV	+00002	16 times		
	Average Times	INAV	VVAV	+00003	64 times		
				+00004	256 times		
gs				+00005	1024 times	_	
Settings				+00000	Normal measurement	FORMAT	
	Analysis Mode	RHM	WHM	+00001	Peak measurement		
sing				+00002	Valley measurement		
Proces				+00003	Peak-to-peak measurement		
	Zero Set	D70	RZS WZS	+00000	OFF		
Data	Zelo Set	KZS	VVZS	+00001	ON		
	Zero Set Amount	RZV	_	-9500000 to +9500000	-950.0000 to +950.0000 [mm]	FORMAT 2	
	Span	RMK	WMK	+01000 to +99999	+0.1000 to +9.9999	FORMAT 1	
	Offset	RML	WML	-9500000 to +9500000	-950.0000 to +950.0000 [mm]	FORMAT 2	

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## Output Settings

	Item		Com	mand	Data	Description	Format	
					+00000	Logic		
	Judgment Output		DOD	WOD	+00001	Independent	(FORMAT	
	Selection		KOD	WOD	+00002	2-state	(FORWAI	
					+00003	3-state		
		Threshold a	RHA	WHA	-9500000 to +9500000	-950.0000 to +950.0000 [mm]		
	Displacement Judgment	Threshold b	RHB	WHB	-9500000 to +9500000	-950.0000 to +950.0000 [mm]	FORMAT 2	
Settings		Hysteresis		WHH	+0000000 to +9500000	+000.0000 to +950.0000[mm]		
Set					+00000	OFF		
Output					+00001	2[ms]		
Out					+00002	4[ms]		
	Judgment Out	put	ROF		+00003	10[ms]		
	OFF-delay		1.01	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	+00004	20[ms]	_	
					+00005	40[ms]	FORMAT 1	
					+00006	100[ms]		
					+00007	Hold		
	Magguramant	Volue			+00000	FULL	_	
	Measurement Value Display on Panel		RDS	WDS	+00001	SET 1		
	1 7				+00002	SET 2		

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## ■ Analog Settings

	Item		Command		Data	Description	Format		
	Analog Outpu	analog Output		WAS	+00000	Output current	(FORMAT		
	Selection		IXAS	WAS	+00001	Voltage output	(FORWAI		
	Analog Scaling	A	RAL	WAL	-9500000 to +9500000	-950.0000 to +950.0000 [mm]	FORMAT 2		
Settings	0		Measurement Value		RAH	WAH	-9500000 to +9500000	-950.0000 to +950.0000 [mm]	(FORWAI
	Analog Scaling	a	RVL	WVL	+00000 to +10000	+00.000 to +10.000 [V]			
Analog	Voltage	b	RVH	WVH	+00000 to +10000	+00.000 to +10.000 [V]	(FORMAT		
	Analog	a	RIL	WIL	+04000 to +20000	+04.000 to +20.000 [mA]	(FORIVIAL		
	Scaling Current		RIH	WIH	+04000 to+20000	+04.000 to +20.000 [mA]			

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## ■ Alarm Settings

	Item Command		Data	Description	Format		
	Analog Output	DΛΛ	WAA	+00000	Hold		
gs	at Alarm	IVAA	VVAA	+00001	Fixed value		
Settings	Digital Output	DVD	RAD WAD	+00000	Hold		
Se	at Alarm	NAD	WAD	+00001	Fixed value	FORMAT 1	
Alarm	Alarm Delay Times	Alarm Delay RHC WHC		100000 to	+00000 to +65535 [times] (0: OFF, 65535: Previous normal value kept on hold)		

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## ■ System Settings

	Item	Com	mand	Data	Description	Format
				+00000	M0	
	Memory	DMC	14/140	+00001	M1	
	Change	RIVIC	WMC	+00002	M2	
				+00003	M3	
	Timing Mode	DTM	WTM	+00000	Hold	
	Timing Mode	KIW	VVIIVI	+00001	One shot	
	Laser Control	RLR	WLR	+00000	Stop	
	Laser Control	KLK	VVLIX	+00001	Emission	
ng	Eco Mode			+00000	Eco-OFF	
Setting		RDP	WDP	+00001	Eco-ON	FORMAT 1
				+00002	Eco-FULL	
System	Initialize	V	WIN	+00000	None	
Sy	Initialize	-	VVIIN	+00001	Initialize	
	Save		WWR	+00000	None	
	Save	-	VVVV	+00001	Save	
	Timing	RTI	WTI	+00000	OFF	
	Tilling	1011	VV 11	+00001	ON	
	Reset	RRS	WRS	+00000	OFF	
	Reset	KKS	WKS	+00001	ON	
	Display Hold	RHD	ID WHD	+00000	OFF	
	Display Hold	טרוא	טחט	+00001	ON	

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## ■ Read Commands

	Item	Comr	mand	Data	Description	Format		
	Measurement Value Read	RMD	ı	-9500000 to +9500000	-950.0000 to +950.0000[mm]	FORMAT 2		
	Read Received Light Intensity	RID	ı	+00000 to +04095	+00000 to +04095			
	Alarm status	ROA		+00000	Alarm OFF			
and	Alailli status	NOA	•	+00001	Measurement Alarm ON			
Command	OUT1 Terminal	ninal R74	RZA -		+00000	OUT1 OFF	CODUAT 1	
Son	Read	INZA	'	+00001	OUT1 ON	(FORMAT		
ad (	OUT2 Terminal	rminal RZB		+00000	OUT2 OFF			
Re	Read	NZD	ı	+00001	OUT2 ON	7		
	OUT3 Terminal	RZC		+00000	OUT3 OFF			
	Read	KZC		+00001	OUT3 ON			
	All Outputs Read	utputs RMB		-	Mesured value/Received light intensity /OUT1/OUT2/OUT3/AL	FORMAT 3		

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## ■ Buffering Commands

	Item		Com	mand	Data	Description	Format		
	Buffering N	Mode	DBD	WBD	+00000	Continuous			
	Duffering N	riode	KDD	VV DD	+00001	Trigger			
	Buffering F	Rate	RBR	WBR	+00001 to +65535	+00001 to +65535			
р	Accumulate	ed Amount	RBC	WBC	+00001 to +03000	+00001 to +03000			
Command	Trigger Point		Trigger Point		RTP	WTP	+00001 to +03000	+00001 to + accumulated amount	FORMAT 1
	Trigger Delay		RTL	WTL	+00001 to +65536	+00000 to +65535	(FORMAL		
erir					+00000	At timing input ON			
Buffering				W/TD	+00001	At or higher than threshold			
	Trigger		KIK	WTR	+00002	Lower than threshold			
	Conditions				+00003	At an alarm occurred			
					+00004	At an alarm released			
	Threshold		RBL	WBL	-9500000 to +9500000	-950.0000 to +950.0000[mm]	FORMAT 2		

Deeffering Output	DDC	WBS	+00000	Stop	
Buffering Operation	KBS	WBS	+00001	Start	
			+00000	Non-buffering	
			+00001	Wait for Trigger	
Status Readout	RTS	-	+00002	Accumulating	FORMAT
			+00003	Accumulation Completed	
Last Data Point	RLD	-	+00001 to +03000	+00001 to accumulated amount	
Data Read (Normal)	RLA	-	-	5-character head point + 5-character end point Data point within the range from the head data point to the end data point is specified.	(FORMAT 4
Data Read (Difference)	RLB	-	-	5-character head point + 5-character end point Data point within the range from the head data point to the end data point is specified.	(FORMAT 5
Data Read (Binary)	RLC	-	-	5-character head point + 5-character end point Data point within the range from the head data point to the end data point is specified.	FORMAT 6

<sup>\*1.</sup> The data section consists of 5 digits (zero suppress is omitted) indicated in decimal.

## 4-4 Setting Address List

In the case of connecting the sensor to our Programmable Logic Controller (PLC) or Programmable Display (GT Series), data can be exchanged by using data area write/read commands over MEWTOCOL-COM communications.

Our FP-series PLC is provided with data write (F145: Data send) and data read (F146: Data receive) commands. Programming is possible with ease without being aware of the command format of the NEWTOCOL-COM Communications if these commands are used.

For details, refer to the FP series Programming Manual.

#### **OCHECK**

In case using without protecting the following, the sensor may be operated unexpectedly. Thus, be sure to protect followings.

In case the unexpected operation is occurred, turn OFF the power and start up for initialization.

- · Do not write and read an address not listed.
- Do not write to an unwritable adress (NG in the list.)
- Do not write in a value other than specified data range to each adress.

#### [MEWTOCOL-COM Communications]


When the sensor receives a command from the PLC or GT Series, the sensor will transmit a response to the command. The PLC and GT Series can exchange data with the sensor in the NEWTOCOL-COM communications procedure.

\* NEWTOCOL-COM is a communications protocol developed for our FP-series PLC.


## ■ Command Formats(MEWTOCOL)

#### • Data Area Read

Request communication data




#### Data Area Write



## ■ Error Response

Error response data is common to all formats.



# ■ Sensing Settings

Address	Item	Data Range	Write	Read	Remarks
DT00050	Sampling Cycle	0~+3	OK	OK	
DT00051	Shutter Time	0~+31	OK	OK	

# ■ Data Processing Settings

Address	Item		Data Range	Write	Read	Remarks
DT00056	Average Tim	ies	0~+5	OK	OK	
DT00053	Analysis Mo	de	0~+3	OK	OK	
DT00061	Zero Set		0~+1	OK	OK	
DT00062	Zero Set	(Lo)	-9500000~	NG	OV	Data type:
DT00063	Amount	(Hi)	+9500000	NG	OK	2 word
DT00057	Cnon	(Lo)	+01000~	OIV	OK	Data type:
DT00058	Span (Hi)		+99999	OK	UK	2 word
DT00059	Offset (Lo)		-9500000~	OIV	OW	Data type:
DT00060	Oliset	(Hi)	+9500000	OK	OK	2 word

## Output Settings

Address	Item		Data Range	Write	Read	Remarks	
DT00054	Judgment Selection	Output	0~+3	OK	OK		
DT00064	Displacement	(Lo)	-9500000~	OK	OIZ	Data type:	
DT00065	Judgment Threshold a	(Hi)	+9500000	OK	OK	2 word	
DT00066	Displacement	(Lo)	-9500000~	OIZ	OIZ	Data type:	
DT00067	Judgment Threshold b	(Hi)	+9500000	OK	OK	2 word	
DT00068	Displacement	(Lo)	+00000000~	OIZ	OIZ	Data type:	
DT00069	Judgment Hysteresis	(Hi)	+9500000	OK	OK	2 word	
DT00055	Judgment OFF-delay	Output	0~+7	OK	OK		
DT00088	Measurement Display on Par	Value rel	0~+2	OK	OK		

## ■ Analog Settings

Address	Item	1	Data Range	Write	Read	Remarks	
DT00070	Analog Selection	Output	0~+1	OK	OK		
DT00071	Analog	(Lo)	-9500000~			Data type:	
DT00072	Scaling Measureme nt Value A	(Hi)	+9500000	OK	OK	2 word	
DT00073	Analog	(Lo)	-9500000~			Data type:	
DT00074	Scaling Measureme nt Value B	(Hi)	+9500000	OK	OK	2 word	
DT00075	Analog	(Lo)	-9500000 <i>∼</i>	OIZ	OIZ	Data type:	
DT00076	Scaling Voltage a	(Hi)	+9500000	OK	OK	2 word	
DT00077	Analog	(Lo)	-9500000~	OIZ	OIZ	Data type:	
DT00078	Scaling Voltage b	(Hi)	+9500000	OK	OK	2 word	
DT00079	Analog	(Lo)	-9500000~	017	017	Data type:	
DT00080	Scaling Current a	(Hi)	+9500000	OK	OK	2 word	
DT00081	Analog	(Lo)	-9500000~	OIZ	OIZ	Data type:	
DT00082	Scaling Current b	(Hi)	+9500000	OK	OK	2 word	

## ■ Alarm Settings

Address	Item	Data Range	Write	Read	Remarks
DT00083	Analog Output at Alarm	0~+1	OK	OK	
DT00084	Digital Output at Alarm	0~+1	OK	OK	
DT00085	Alarm Delay Times	0~+65535	OK	OK	

# ■ System Settings

Address	Item	Data Range	Write	Read	Remarks
DT00104	Memory Change	0~+3	OK	OK	
DT00105	Timing Mode	0~+1	OK	OK	
DT00106	Laser Control	0~+1	OK	OK	
DT00107	Eco Mode	0~+2	OK	OK	
DT00108	Initialize	0~+1	OK	NG	
DT00109	Save	0~+1	OK	NG	
DT00111	Timing	0~+1	OK	OK	
DT00112	Reset	0~+1	OK	OK	

## ■ Data Readout

Address	Item		Data Range	Write	Read	Remarks
DT00400	Measure	(Lo)	-9500000~			Data type:
DT00401	ment Value Read	(Hi)	+9500000	NG	OK	2 word
DT00414	Read R Light Inte	leceived nsity	0~+4095	NG	OK	
DT00410	Alarm stat	tus	$0\sim +1$	NG	OK	
DT00411	OUT1 T Read	Terminal	0~+1	NG	OK	
DT00412	OUT2 T Read	Terminal	0~+1	NG	OK	
DT00413	OUT3 T Read	Terminal	0~+1	NG	OK	

# ■ Buffering settings

Address	Item		Data Range	Write	Read	Remarks		
DT01950	Buffering M	ode	0~+1	OK	OK			
DT01951	Buffering Rate		+1~+65535	OK	OK			
DT01952	Accumulated Amount	1	+1~+3000	OK	OK			
DT01953	Trigger Point		+1~+3000	OK	OK	Settings within sepecified no. of the accumulated amount		
DT01954	Trigger Dela	у	0~+65535	OK	OK			
DT01955	Trigger Cond	ditions	0~+4	OK	OK			
DT01956 DT01957	Trigger Conditions Threshold	(Lo) (Hi)	-9500000~ +9500000	OK	OK	Data type: 2 word		
DT01960	Buffering Op	eration	0~+1	OK	OK			
DT01959	Status Reado	out	0~+3	NG	OK			
DT01962	Last Data Po	int	0~+3000	NG	OK			
DT02000 DT02001	Buffer Data No.1	(Lo) (Hi)	-9500000~ +9500000	NG	OK	· Reading out		
			-9500000~ +9500000	NG	OK	data of up to last data point •Data type:		
DT07998 DT07999	Buffer Data No.3000	(Lo) (Hi)	-9500000~ +9500000	NG	ОК	2 word		

# ■ Setting for Programmable Display (GT Series)

For more details about these settings, refer to the User's Manual (dedicated Console Version).

Address	Item	Da	ıta Range	Write	Read	Remarks
		0	OFF			Hold
DT00113	Display Hold	+1	ON	OK	OK	DT00400/00401
		+1	ON			measurements
		0	FULL			Deflecting to
DT00089	Display console measurement	+1	Set 1	OK	OK	Reflecting to Measurements of
	value	+2	Set 2	OK	OK 	DT00400/00401
		+3	Set 3			D100400/00401
		0	White /		OK	
		U	Green			
DT00117	Backlight color	+1	OUT2ON	OK		
D100117	display	+1	red	OK	OK	
		+2	OUT2OFF			
		-4	red			
DT00119	Touch beep	0	ON	OK	OK	
D100119	тоисп оеер	+1	OFF	OK	OK	



# **5**Troubleshooting

This Chapter provides information on the troubleshooting of the system.

Read this Chapter if something seems to be wrong with the system.

5-1	Corrective A	ct	io	n	s							5-2
5-2	Initialization											5-6

## 5-1 Corrective Actions

If an error or trouble occurs during use of the system or a system failure is suspected, read this chapter carefully first and carry out the corresponding corrective actions.

#### Trouble type

SET Trouble in sensor head settings.

[COM] Trouble in communication control.

MEAS Trouble in the measurement method or display of measurement values.

LED Trouble in alarm or error LED indications.

[LASER] Trouble in laser emission.

## **O**CHECK

- For the details of conditions where measurement value is unfixed, → refer to "2-5 Conditions When Output Data Become Unfixed".
- For problems related to memory saving and terminal settings, → refer to "3-3-2 Memory Change".

Туре	Problem	Cause	Corrective action	Ref. page
	The sensor head indicator does not light up. The sensor head does not operate.	The connecting cable is not connected properly.	Check the connection between the sensor head and connection cable.	1-2
		The connecting cable is disconnected.	Check the wiring between the connection cable and connector.	2-2
SET		Power is not supplied to the controller.	Check the connection between the 24-VDC external power and sensor head.	2-2
		The operation of the sensor head is stopped.	Turn ON the sensor head again.	3-6
		The eco mode is set to "Eco-FULL".	The LED will be lit by operating any switch. Make eco-mode settings if necessary.	3-40
LASER	The laser beam is not emitted.	The laser control setting is turned OFF and saved.	Save the laser control setting turned ON, otherwise the system will start with the laser beam turned OFF.	3-39 3-43

Туре	Problem	Cause	Corrective action	Ref. page
	There is a difference between the actual	The measurement object is fluctuating or vibrating.	Stop the fluctuation or vibration of the measurement object.	1-8
MEAS	distance to the measurement object and measurement value.	The measurement object is tilted.	Place the measurement object as perpendicularly as possible.	1-8
		The received light waveform is saturated or insufficient.	Adjust the received light intensity using the shutter time.	3-14
MEAS	The correct	The measurement object is out of the measurement range.	Check the measurement range of the sensor head used.	6-9
	measurement value is not displayed.	The scaling is not set correctly.	Set the correct scaling.	3-29
	displayed.	The light emitter/receiver is dirty.	Remove the dirt on the light emitter/receiver.	6 1-6
	Measurement values vary.	The moving average is small.	Increase the number of moving average.	3-16
		The light emitter/receiver is dirty.	Remove the dirt on the light emitter/receiver.	6 1-6
MEAS		The mounting direction of the sensor head is wrong.	Check the mounting direction of sensor head.	1-7
		The sensor head or measurement object is tilted.	Check the mounting of the sensor head and the setting position of the measurement object.	1-7
	The measurement	The measurement object is out of the measurement range.	Check the measurement range of the sensor head used.	6-9
MEAS	value is not displayed, while "-	The timing input remains ON.	Set the timing input to OFF.	3-47
(LED)	displayed in the measurement value.	The timing input is pink, and the NPN type / PNP type switching input is pink/purple. The wiring is not wired correctly.	Correctly wire the NPN type / PNP type switching input.	2-2
(SET)	The OUT indicator turns ON/OFF, however the output does not turn ON/OFF.	The NPN type / PNP type switching input is not wired correctly.	Correctly wire the NPN type / PNP type switching input, based on the output being used is either NPN or PNP.	2-2

Туре	Problem	Cause	Corrective action	Ref. page
		The wiring is incorrect.	RS-422 and RS-485 are different in wiring. Connect the wires correctly. Use a twisted-pair cable to ensure stable communication.	4-2 4-3 4-4
		The RS-422/485 connecting cable is disconnected.	Check the connection between RS-422/485 cable and connector.	4-2
	RS-485 communication	The wrong connection mode and baud rate are selected.	Connect the connection mode and baud rate correctly.	3-36
COM	control cannot be done. Normal communication over RS-422/485	The communications settings for the external equipment are wrong.	Check the settings for the external equipment (e.g., the communications board) and be sure to set the correct RS-422/485 communications specifications.	4-2
	is impossible.	The sensor number settings are wrong.	If a number of sensors are connected over RS-485, be sure to set a unique sensor number for each sensor.	3-35 4-4
		The selection of the terminating sensor is wrong.	Select the terminating resistor (R3) only for the terminating sensor head only. Be sure to turn OFF the terminating resistor of the rest of the sensor heads.	3-34
		The communication quality is degraded as a result of the wiring condition.	The communication condition may be improved by lowering the baud rate. The communication condition may be improved by selecting the R1 or R2 terminating resistor.	3-34 3-36
COM	RS-485 communication control cannot be done. Normal	Check that the correct Sending delay time is set.	In the case of connecting a number of units over RS-485, reception errors in the host device can be avoided by delaying the sensor's response time.	3-38
	communication over RS-422/485 is impossible	An incorrect data format or command is transmitted.	Refer to the error codes and send the data with the correct format and command.	4-8 4-16
		Several commands are sent continuously without waiting receiving responses from the controller.	Send the next command after the controller transmits the response to the previous command.	4-6
SET	The settings are wrong.	The settings were not saved while RS-422/485 communication was used.	The execution of the Save command is required after making setting changes with the communications command (by using the Setting and Monitoring Software HL-G1SMI or the dedicated console. The set value will be discarded with the power turned OFF if the set value is not saved.	3-43

Туре	Problem	Cause	Corrective action	Ref. page	
	The elerm	Move the position of the beam projection spot or change the mounting direction of the sensor head so the reflected beam should not be blocked.	1-9		
MEAS LED	The alarm indicator lights up and measurement cannot be done.  If an alarm occurs, check the error code of alarm output read by RS-422/485 communication.	indicator lights up and measurement cannot be done.  ↓  The beam emitting spot is applied to the R portion (curved surface) of the measurement object.		Apply the beam projection spot to the top of R portion or adjust the beam diameter so it comes larger by moving the measurement object back and forth within the measurement range.	1-8
		The reflected beam has directionality because the surface of the object is hairline-finished.	Check the mounting direction of sensor head.	1-7	
		The received light intensity is insufficient because the sampling cycle is too short.	Set a longer sampling cycle or shutter time (when shutter time is set to a fixed value).	3-13 3-14	
MEAS LED	The alarm indicator lights up and measurement cannot be done. The measurement range is limited.	The sampling cycle is too long and this causes excessive received light intensity beyond the adjustable range.	Set a shorter sampling cycle and reduce the emitted light intensity (enter a smaller number to the shutter time).	3-13 3-14	

# 5-2 Initialization

- Initialization deletes all settings and returns them to the factory default settings.
- For more information, → refer to "3-3-10 Other System Settings -Initialization".
- •After initialization, the default settings will not be saved if serial (RS-422/485) communication is used. To save the default settings after the power is turned OFF, → refer to "3-3-10 Other System Settings Save".

# **6**Specifications

This Chapter provides the specifications of the sensor head.

6-1 Sensor Head Specifications6-2
<b>6-2</b> Dimensions 6-8
■ Sensor Head6-8
6-3 Characteristics6-13
■ Beam Diameter6-13
■ Mutual Interference Area ······6-13
■ Output Characteristics6-18

# 6-1 Sensor Head Specifications

• Diffuse reflection Type

Mode	l No	Standard Type	HL-G103-A- C5	HL-G105-A- C5	HL-G108-A- C5	HL-G112-A- C5	HL-G125-A- C5	
Wiode	i ivo.	High-func tion Type	HL-G103-S-J	HL-G105-S-J	HL-G108-S-J	HL-G112-S-J	HL-G125-S-J	
Suppl	y volt	age	24 VDC ±10% including ripple 0.5 V (P-P)					
Curre	nt cor	nsumption			100 mA max.			
Meas	ureme	ent method	Diffuse reflection					
Measi distan		ent center	30 mm	50 mm	85 mm	120 mm	250 mm	
Measi	ureme	ent range	±4 mm	±10 mm	±20 mm	±60 mm	±150 mm	
Beam	sour	ce	Red semiconductor laser Class 2 (JIS/IEC/GB/FDA laser notice No. 50)  Max output: 1 mW, Emission peak wavelength: 655 nm					
Beam	diam	eter (*1)	0.1×0.1 mm	0.5×1 mm	0.75×1.25 mm	1.0×1.5 mm	1.75×3.5 mm	
Beam eleme		iving	CMOS image sensor					
Resol	ution		0.5 μm	1.5 μm	2.5 μm	8 μm	20 μm	
Linea	rity		$\pm 0.1\%$ F.S. $\pm 0.3\%$ F.S.					
Temperature characteristics		±0.08% F.S./°C						
Samp	ling c	ycle	200 μs, 500 μs, 1 ms, 2 ms					
og		Voltage	Output range: 0 to 10.5 V (normal), 11 V (at alarm) Output impedance: $100\Omega$			m)		
Analog output		Current	Outp		20.8 mA (norm impedance: 300		(at alarm)	
			Judgment output or alarm output (switchable) NPN open-collector transistor/PNP open-collector transistor (switchable)					
OUT1 OUT2 OUT3		Settings for NPN> Peak in-flow current: 50 mA Applied voltage: 3 to 24 VDC (between output and 0 V) Residual voltage: 2 V max. (at in-flow current of 50 mA) Leak current: 0.1 mA or less Settings for PNP> Peak out-flow current: 50 mA Residual voltage: 2.8 V max. (at in-flow current of 50 mA) Leak current: 0.1 mA or less						
	Outp	ut operation	Open when the output is ON.					
		t-circuit ection	Incorporated (Auto-reset)					
NP switching input		At 0 V: NPN open-collector output At supply voltage of 24 VDC: PNP open-collector output						

Applicable standards		Conforming to EMC Directive		
Accessory		Laser warning label: 1 set		
Mass		Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)		
Cable extension (Only High-function type)		Extendable to 20 m with an optional extension cable (sold separately).		
Cable length		Standard Type:5 m, High-function Type:0.5m		
Material		Casing: PBT, Front cover: Acrylic, Cable: PVC		
Ambie	ent height	2000 m or less		
Ambie	ent humidity	35 to 85%RH, At storage: 35 to 85%RH		
Ambient temperature		-10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C		
Ambient illumination (*2)		3,000 lx max. (illumination level of light receiving surface under incandescent light)		
Shock	k resistance	500m/s <sup>2</sup> three times each in X, Y, and Z directions		
Vibrat	tion resistance	Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hour each in X, Y, and Z directions		
Dieled	ctric Withstand	1000 VAC for 1 min. (between charged parts and casing)		
	ation resistance	20 MΩ min. at 250-VDC megger (between charged parts and casing)		
	ion degree	2		
	ctive structure	IP67		
Digital	display	Red LED for sign and 5-digit display		
띡	Output indicator	quantity  Yellow LED (No. of indicators: 3) ON at output		
Indicator	Alarm indicator	Orange LED ON when measurement is impossible as a result of insufficient or excessive light		
	Laser radiation indicator	Green LED ON at laser radiation		
Communications interface (Only High-function type)		RS-422 or RS-485 (switchable)  Baud rate: 9,600/19,200/38,400/115,200/230,400/460,800/921,600 bps  Data length: 8 bits, stop bit length: 1 bit, parity check: none, BCC: yes, end coc CR		
Multiple input		Zero set, zero set OFF, reset, memory change, teaching, save, or laser contro depending on input time.  NPN operation: Depending on time to connect 0 V PNP operation: Depending on time to connect positive terminal of external power supply		
Timin	g input	NPN operation: ON when connecting or connected to 0 V (depending on settings)  PNP operation: ON when connecting or connected to positive terminal of external power supply (depending on settings)		

The following measurement conditions are applied unless otherwise specified; power voltage: 24 VDC, ambient temperature:  $20^{\circ}$ C, sampling cycle:  $500 \, \mu$ s, average number of sampling times:  $1024 \, \text{times}$ , measurement center distance, and measurement object: white ceramic.

- \*1 The diameter is the size of the object at the measurement center distance and determined by 1/e<sup>2</sup> (approximately 13.5%) of the center beam intensity. The reflectance around the detecting point may be higher than at the point due to leak light outside the specified area, and this may affect the measurement value.
- \*2 Variance is  $\pm 0.1\%$  F.S. or less depending on the ambient illuminance.

• Specular reflection Type

• Sp	ecul	ar reflectior	ı Type				
NA I . I	ı Nı.	Standard Type	HL-G103A-RA-C5	HL-G105A-RA-C5	HL-G108A-RA-C5		
Mode	l No.	High-func tion Type	HL-G103A-RS-J	HL-G105A-RS-J	HL-G108A-RS-J		
Suppl	y volt	age	24 VDC ±10% including ripple 0.5 V (P-P)				
Curre	nt coi	nsumption	100 mA max.				
Measi	urem	ent method	Specular reflection				
Measi distan		ent center	26.3 mm	47.3 mm	82.9 mm		
Measi	urem	ent range	±2 mm	±5 mm	±10 mm		
Beam	sour	ce	Red semiconductor laser Class 1 (JIS/IEC/GB/FDA laser notice No. 50)  Max output: 0.39 mW, Emission peak wavelength: 655 nm				
Beam	diam	neter (*1)	0.1×0.1 mm 0.2×0.2				
Beam eleme		iving	CMOS image sensor				
Resol	ution		0.5 μm	1.5 μm	2.5 μm		
Linear	rity		±0.2% F.S.				
Tempe			±0.08% F.S./°C				
Samp	ling c	cycle	200 μs, 500 μs, 1 ms, 2 ms				
og ut	Voltage		Output range: 0 to 10.5 V (normal), 11 V (at alarm) Output impedance: $100\Omega$				
Analog output		Current	Output range: 3.2 to 20.8 mA (normal), 21.6 mA (at alarm) Load impedance: 300Ω max.				
			Judgment output or alarm output (switchable) NPN open-collector transistor/PNP open-collector transistor (switchable)				
OUT1 OUT2 OUT3  Output operation			Settings for NPN> Peak in-flow current: 50 mA Applied voltage: 3 to 24 VDC (between output and 0 V) Residual voltage: 2 V max. (at in-flow current of 50 mA) Leak current: 0.1 mA or less Settings for PNP> Peak out-flow current: 50 mA Residual voltage: 2.8 V max. (at in-flow current of 50 mA) Leak current: 0.1 mA or less				
		out operation	Open when the output is ON.				
	Short-circuit protection		Incorporated (Auto-reset)				
NP switching input		ng input	At 0 V: NPN open-collector output At supply voltage of 24 VDC: PNP open-collector output				
Timing input		ut	NPN operation: ON when connecting or connected to 0 V (depending on settings)  PNP operation: ON when connecting or connected to positive terminal of external power supply (depending on settings)				

quantity       Output indicator     Yellow LED (No. of indicators: 3) ON at output       Digital display     Red LED for sign and 5-digit display       Protective structure     IP67       Pollution degree     2       Insulation resistance     20 MΩ min. at 250-VDC megger (between charged parts and casing)       Dielectric Withstand     1000 VAC for 1 min. (between charged parts and casing)				
interface (Only High-function type)  Baud rate: 9,600/19,200/38,400/115,200/230,400/460,800/921,600 bps Data length: 8 bits, stop bit length: 1 bit, parity check: none, BCC: yes, end code: CR  Laser radiation indicator	Multip	ole input	depending on input time.  NPN operation: Depending on time to connect 0 V  PNP operation: Depending on time to connect positive terminal of external	
Conly High-function type   Data length: 8 bits, stop bit length: 1 bit, parity check: none, BCC: yes, end code: CR	Comr	munications	RS-422 or RS-485 (switchable)	
Indicator	interface (Only High-function		Baud rate: 9,600/19,200/38,400/115,200/230,400/460,800/921,600 bps Data length: 8 bits, stop bit length: 1 bit, parity check: none, BCC: yes, end cod	
Output indicator         Yellow LED (No. of indicators: 3) ON at output           Digital display         Red LED for sign and 5-digit display           Protective structure         IP67           Pollution degree         2           Insulation resistance         20 MΩ min. at 250-VDC megger (between charged parts and casing)           Dielectric Withstand         1000 VAC for 1 min. (between charged parts and casing)           Vibration resistance         Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions           Shock resistance         500m/s² three times each in X, Y, and Z directions           Ambient illumination (*2)         3,000 lx max. (illumination level of light receiving surface under incandescent light)           Ambient temperature         -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C           Ambient height         2000 m or less           Material         Casing: PBT, Front cover: Acrylic, Cable: PVC           Cable length         Standard Type:5 m, High-function Type:0.5m           Cable extension (Only High-function type)         Extendable to 20 m with an optional extension cable (sold separately). and approx. 380 g (with packing)           Mass         Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 160 g (with packing)				
Output indicator         Yellow LED (No. of indicators: 3) ON at output           Digital display         Red LED for sign and 5-digit display           Protective structure         IP67           Pollution degree         2           Insulation resistance         20 MΩ min. at 250-VDC megger (between charged parts and casing)           Dielectric Withstand         1000 VAC for 1 min. (between charged parts and casing)           Vibration resistance         Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions           Shock resistance         500m/s² three times each in X, Y, and Z directions           Ambient illumination (*2)         3,000 lx max. (illumination level of light receiving surface under incandescent light)           Ambient temperature         -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C           Ambient height         2000 m or less           Material         Casing: PBT, Front cover: Acrylic, Cable: PVC           Cable length         Standard Type:5 m, High-function Type:0.5m           Cable extension (Only High-function type)         Extendable to 20 m with an optional extension cable (sold separately). and approx. 380 g (with packing)           Mass         Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 160 g (with packing)	ndicator	Alarm indicator	ON when measurement is impossible as a result of insufficient or excessive light	
Protective structure  Pollution degree  2  Insulation resistance  Dielectric Withstand  Tool VAC for 1 min. (between charged parts and casing)  Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions  Shock resistance  Shock resistance  Shock resistance  Shock resistance  Ambient illumination  (*2)  Ambient temperature  Too'C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C  Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Cable extension  (Only High-function type)  Standard Type: Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 360 g (with packing)  High-function Type: Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	_	Output indicator	· · · · · · · · · · · · · · · · · · ·	
Pollution degree  Insulation resistance  20 MΩ min. at 250-VDC megger (between charged parts and casing)  Dielectric Withstand  1000 VAC for 1 min. (between charged parts and casing)  Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions  Shock resistance  500m/s² three times each in X, Y, and Z directions  Ambient illumination  (*2)  Ambient temperature  -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C  Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  2000 m or less  Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension  (Only High-function type)  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Digital	display	Red LED for sign and 5-digit display	
Dielectric Withstand   1000 VAC for 1 min. (between charged parts and casing)	Prote	ctive structure	IP67	
Dielectric Withstand  1000 VAC for 1 min. (between charged parts and casing)  Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions  Shock resistance  500m/s² three times each in X, Y, and Z directions  Ambient illumination  (*2)  Ambient temperature  -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C  Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  2000 m or less  Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Cable extension  (Only High-function type: 5 m, High-function Type: 0.5 m  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type: Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type: Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Pollu	tion degree	2	
Vibration resistance  Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions  500m/s² three times each in X, Y, and Z directions  Ambient illumination (*2)  Ambient temperature  -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C  Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Insula	ation resistance	$20 \text{ M}\Omega$ min. at 250-VDC megger (between charged parts and casing)	
Shock resistance  Is Alierctions  Shock resistance  Is Alierctions  Shock resistance  Shock resistance  Is Aliertions  Shock resistance  Shock resistance  Is Aliertions  Shock resistance  Shock resistance  Shock resistance  Is Aliertions  Shock resistance  Shock RH  Standard Type: Abrock cover: Acrylic, Cable: PVC  Cable extension  (Only High-function Type: O.5m  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type: Approx. 70 g (without cable), approx. 320 g (including cable),  and approx. 380 g (with packing)  High-function Type: Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Diele	ctric Withstand	1000 VAC for 1 min. (between charged parts and casing)	
Ambient illumination (*2)  3,000 lx max. (illumination level of light receiving surface under incandescent light)  -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C  Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  2000 m or less  Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Vibration resistance		Endurance: 10 to 55 Hz (at 1-minute cycle), 1.5-mm double-amplitude two hours each in X, Y, and Z directions	
(*2) Ilight)  Ambient temperature  -10°C to 45°C (No dew condensation or icing allowed), At storage: -20°C to +60°C  Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  2000 m or less  Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension  (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Shoc	k resistance	500m/s <sup>2</sup> three times each in X, Y, and Z directions	
Ambient humidity  35 to 85%RH, At storage: 35 to 85%RH  Ambient height  2000 m or less  Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)			3,000 lx max. (illumination level of light receiving surface under incandescen	
Ambient height  2000 m or less  Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)				
Material  Casing: PBT, Front cover: Acrylic, Cable: PVC  Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Ambi	ent humidity	35 to 85%RH, At storage: 35 to 85%RH	
Cable length  Standard Type:5 m, High-function Type:0.5m  Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Ambi	ent height	2000 m or less	
Cable extension (Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Material		Casing: PBT, Front cover: Acrylic, Cable: PVC	
(Only High-function type)  Extendable to 20 m with an optional extension cable (sold separately).  Standard Type:Approx. 70 g (without cable), approx. 320 g (including cable), and approx. 380 g (with packing)  High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	Cable length		Standard Type:5 m, High-function Type:0.5m	
Mass and approx. 380 g (with packing) High-function Type:Approx. 70 g (without cable), approx. 110 g (including cable), and approx. 160 g (with packing)	(Only High-function		Extendable to 20 m with an optional extension cable (sold separately).	
Applicable standards Conforming to EMC Directive	Mass		and approx. 380 g (with packing) High-function Type:Approx. 70 g (without cable), approx. 110 g (including	
	Applicable standards		Conforming to EMC Directive	


The following measurement conditions are applied unless otherwise specified; power voltage: 24 VDC, ambient temperature: 20°C, sampling cycle: 500 µs, average number of sampling times: 1024 times, measurement center distance, and measurement object: aluminum vapor deposition surface reflection mirror.

- \*1 The diameter is the size of the object at the measurement center distance and determined by 1/e<sup>2</sup> (approximately 13.5%) of the center beam intensity. The reflectance around the detecting point may be higher than at the point due to leak light outside the specified area, and this may affect the measurement value.
- \*2 Variance is  $\pm 0.1\%$  F.S. or less depending on the ambient illuminance.

# 6-2 Dimensions


## ■ Sensor Head

• Diffuse reflection Standard Type (HL-G1 - A-C5)




Model No.	Measurement center distance	θ
HL-G103-A-C5	30mm	30°
HL-G105-A-C5	50mm	21°
HL-G108-A-C5	85mm	15°
HL-G112-A-C5	120mm	11°
HL-G125-A-C5	250mm	6.2°

#### • diffuse reflection High-function Type (HL-G1<sub>--</sub>S-J)




Model No.	Measurement center distance	θ
HL-G103-S-J	30mm	30°
HL-G105-S-J	50mm	21°
HL-G108-S-J	85mm	15°
HL-G112-S-J	120mm	11°
HL-G125-S-J	250mm	6.2°


#### • Specular reflection Standard Type (HL-G103A-RA-C5)




• Specular reflection High-function Type (HL-G103A-RS-J)




#### • Specular reflection Standard Type (HL-G105A-RA-C5)




• Specular reflection High-function Type (HL-G105A-RS-J)



#### • Specular reflection Standard Type (HL-G108A-RA-C5)




#### • diffuse reflection High-function Type (HL-G108A-RS-J)



# 6-3 Characteristics


### ■ Beam Diameter

•Diffuse reflection type



	Beam Diameter					
Model No.	а	b	С	d	е	f
HL-G103-S-J HL-G103-A-C5	0.15mm	0.15mm	0.1mm	0.1mm	0.15mm	0.15mm
HL-G105-S-J HL-G105-A-C5	1.2mm	0.6mm	1.0mm	0.5mm	0.9mm	0.4mm
HL-G108-S-J HL-G108-A-C5	1.5mm	0.9mm	1.25mm	0.75mm	1.0mm	0.6mm
HL-G112-S-J HL-G112-A-C5	1.8mm	1.2mm	1.5mm	1.0mm	0.8mm	0.5mm
HL-G125-S-J HL-G125-A-C5	2.5mm	1.5mm	3.5mm	1.75mm	4.5mm	2.0mm

## •Specular reflection type




Model No.	Beam Diameter					
	а	b	С	d	е	f
HL-G103A-RS-J HL-G103A-RA-C5	0.15mm	0.15mm	0.1mm	0.1mm	0.15mm	0.15mm
HL-G105A-RS-J HL-G105A-RA-C5	0.15mm	0.15mm	0.1mm	0.1mm	0.15mm	0.15mm
HL-G108A-RS-J HL-G108A-RA-C5	0.2mm	0.2mm	0.2mm	0.2mm	0.2mm	0.2mm

#### ■ Mutual Interference Area


In the case of installing two or more diffuse reflective sensor heads side by side, mutual interference will occur if the laser spots of the other sensor heads fall within the shaded area ( ) shown below. Install the sensor heads so that the laser spots of the other sensor heads will fall outside the shaded area ( ).

#### • 30-mm Type (HL-G103-A-C5/HL-G103-S-J)




Unit: mm

#### • 50-mm Type (HL-G105-A-C5/HL-G105-S-J)




Unit: mm

#### • 85-mm Type (HL-G108-A-C5/HL-G108-S-J)




Unit: mm

#### • 120-mm Type (HL-G112-A-C5/HL-G112-S-J)




## • 250-mm Type (HL-G125-A-C5/HL-G125-S-J)



Unit: mm

## ■ Output Characteristics


#### • Diffuse reflection type



\*1 In the figure above, analog output setting is used as the initial setting.

	Standard type	High-function type	Measurement center distance (D)	Measurement method (R)
30-mm type	HL-G103-A-C5	HL-G103-S-J	30 mm	±4 mm
50-mm type	HL-G105-A-C5	HL-G105-S-J	50 mm	±10 mm
85-mm type	HL-G108-A-C5	HL-G108-S-J	85 mm	±20 mm
120-mm type	HL-G112-A-C5	HL-G112-S-J	120 mm	±60 mm
250-mm type	HL-G125-A-C5	HL-G125-S-J	250 mm	±150 mm

#### • Specular reflection type



\*1 In the figure above, analog output setting is used as the initial setting.

	Standard type	High-function type	Measurement center distance (D)	Measurement method (R)
30-mm type	HL-G103A-RA-C5	HL-G103A-RS-J	26.3 mm	±2 mm
50-mm type	HL-G105A-RA-C5	HL-G105A-RS-J	47.3 mm	±5 mm
85-mm type	HL-G108A-RA-C5	HL-G108A-RS-J	82.9 mm	±10 mm

## Revision history

Released date	Revision No.
October 2010	A first release
January 2011	The 1st edition
March 2011	The 2nd edition
January 2012	The 3rd edition
March 2013	The 4th edition
September 2013	The 5th edition
December 2013	The 6th edition
October 2014	The 7th edition
January 2015	The 8th edition



Please contact ...

#### Panasonic Industrial Devices SUNX Co., Ltd.

- Overseas Sales Division (Head Office): 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan
   Telephone: +81-568-33-7861 Facsimile: +81-568-33-8591
- panasonic.net/id/pidsx/global

About our sale network, please visit our website.

© Panasonic Industrial Devices SUNX Co., Ltd. 2015 WUME-HLG1-8

January, 2015 PRINTED IN JAPAN