377

FIBER SENSORS

LASER SENSORS

MICRO PHOTOELECTRIC SENSORS

Adjustable Range Reflective Photoelectric Sensor Amplifier Built-in RX-LS200

panasonic.net/id/pidsx/global

Related Information

General terms and conditions F-7
Glossary of terms P.1455~

Sensor selection guide......P.271~

General precautions......P.1458~





SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS STATIC ELECTRICITY PREVENTION DEVICES

> LASER MARKERS

PLC HUMAN MACHINE INTERFACES

ENERGY CONSUMPTION VISUALIZATION

FA COMPONENTS

MACHINE VISION

COMPONENTS

SYSTEMS UV CURING SYSTEMS

> Selection Guide

mplifie Built-ii

Amplifierseparated

CX-400

CY-100

EX-10

EX-20

EX-30

EX-40

CX-440

EQ-30

EQ-500

MQ-W RX-LS200 RX

Power Supply Built-in

colored objects at a certain distance

Hardly affected by color

Detection of different

The color or size of the object does not affect its sensing performance.

Robust

Its robust enclosure is made of die-cast zinc alloy.

ENVIRONMENTAL RESISTANCE


Waterproof IP67 (IEC)

The equipment on which the sensor is mounted can be washed without any problem.

Note: However, take care that if it is exposed to water splashes during operation. It may detect a water drop itself.

Insusceptible to dust

The sensing performance is less affected by dust as it does not depend on the incident light intensity.




Hardly affected by background

PNF

PNP output type available

The sensor does not detect the background beyond the set distance since it is of distance adjustable type.



However, changing the angle of the sensor is necessary when the background object has a specular surface.

BASIC PERFORMANCE


High-speed response time: 1 ms

It can be used on a high speed assembly line.

Adjustable Range & Fixed-focus Reflective Type


The sensing range for which the sensor detects an object is determined by the incident beam angle, regardless of the incident light intensity.

RX-LS200



APPLICATIONS

Detecting lids of cups



ORDER GUIDE


Туре	Appearance	Sensing range	Model No.	Output
NPN output		50 to 200 mm 1.969 to 7.874 in	RX-LS200	NPN open-collector transistor
PNP output			RX-LS200-P	PNP open-collector transistor

5 m cable length type

5 m 16.404 ft cable length type (standard: 3 m 9.843 ft) is also available for NPN output type. Model No.: RX-LS200-C5

Accessory

• MS-RX-1 (Sensor mounting bracket)



Two M4 (length 16 mm 0.630 in) hexagon-socket-head bolts are attached.

OPTIONS

Designation	Model No.			Description	Narrow-view slit mask • OS-RXL-□	Selection Guide Amplifier Built-in Power Supply Built-in
	OS-RXL-1		2.5 × 24 mm 0.098 0.945 in			Amplifier- separated
Narrow-view slit mask	OS-RXL-2	Slit size	3.0 × 24 mm 0.118 0.945 in	The sensing view is narrowed laterally so that the effect of the object's surroundings is reduced.		CX-400
	OS-RXL-3		3.5 × 24 mm 0.138 0.945 in			CY-100 EX-10
Protective tube	PT-RX500	Length	500 mm 19.685 in	Cable is protected from external forces. It does not rust as it is made of stainless steel.	Protective tube	EX-20 EX-30
	PT-RX1000		1,000 mm 39.370 in		• PT-RX500 • PT-RX1000	EX-40 CX-440
					Protective tube	EQ-30
						EQ-500 MQ-W
						RX-LS200
						RT-610
amco Nationa	1			www.PanasonicSensors.com	1-800-2	280-6933

<u>378</u>





LIGHT CURTAINS / SAFETY COMPONENTS



WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC HUMAN MACHINE INTERFACES



MACHINE VISION SYSTEMS UV CURING SYSTEMS

1-800-280-6933


FIBER SENSORS

Amplifier-separated

SPECIFICATIONS


LASER SENSORS	Туре		Adjustable range reflective				
PHOTO-			NPN output type	PNP output type			
PHOTO- ELECTRIC SENSORS MICRO	Iten	n Model No.	RX-LS200	RX-LS200-P			
PHOTO- ELECTRIC SENSORS	Sen	sing range	50 to 200 mm 1.969 to 7.874 in with white not	n-glossy paper (50 × 50 mm 1.969 × 1.969 in)			
AREA	Hyst	teresis	10 % or less of operation distance with white non-glossy paper (50 × 50 mm 1.969 × 1.969 in)				
SENSORS	Repeatability		Along sensing axis: 1 mm 0.039 in or less, Perpendicular to sensing axis: 0.5 mm 0.020 in or less				
CURTAINS / SAFETY COMPONENTS	Sup	ply voltage	12 to 24 V DC ±10 % Ripple P-P 10 % or less				
PRESSURE / FLOW SENSORS	Current consumption		40 mA or less				
SENSORS INDUCTIVE PROXIMITY SENSORS PARTICULAR USE SENSORS	Output		 NPN open-collector transistor Maximum sink current: 100 mA Applied voltage: 30 V DC or less (between output and 0 V) Residual voltage: 1.5 V or less (at 100 mA sink current) 0.4 V or less (at 16 mA sink current) 	 PNP open-collector transistor Maximum source current: 100 mA Applied voltage: 30 V DC or less (between output and +V) Residual voltage: 1 V or less (at 100 mA source current) 0.4 V or less (at 16 mA source current) 			
SENSOR OPTIONS		Utilization category	DC-12 or DC-13				
SIMPLE WIRE-SAVING		Output operation	Switchable either Light-ON or Dark-ON				
UNITS		Short-circuit protection	Incorporated				
WIRE-SAVING SYSTEMS	Response time		1 ms or less				
MEASURE- MENT	Operation indicator		Red LED (lights up when the output is ON)				
SENSORS	Stability indicator		Green LED (lights up under stable light received condition or stable dark condition)				
STATIC ELECTRICITY PREVENTION DEVICES	Distance adjuster		2-turn mechanical adjuster				
LASER	Pollution degree		3 (Industrial environment)				
MARKERS		Protection	IP67 (IEC)				
PLC	nce	Ambient temperature	-25 to 60 °C -13 to 140 °F (No dew condensation or icing allowed), Storage: -30 to 70 °C -22 to 158 °F				
HUMAN MACHINE	sista	Ambient humidity	35 to 85 % RH, Storage: 35 to 85 % RH				
INTERFACES ENERGY	al re	Ambient illuminance	Incandescent light: 3,500 tx at the light-receiving face				
CONSUMPTION VISUALIZATION COMPONENTS	Environmental resistance	EMC	EN 609	947-5-2			
FA	/iron	Voltage withstandability	1,000 V AC for one min. between all supply	terminals connected together and enclosure			
	En	Insulation resistance	20 M Ω , or more, with 250 V DC megger between all supply terminals connected together and enclosure				
MACHINE VISION SYSTEMS		Vibration resistance	10 to 500 Hz frequency, 1.5 mm 0.059 in amplitude (10 G max.) in X, Y and Z directions for two hours each				
UV CURING SYSTEMS		Shock resistance	500 m/s ² acceleration (50 G approx.) in λ	K, Y and Z directions for three times each			
STSTEMS	Emi	tting element	Infrared LED (peak emission wavelength: 880 nm 0.035mil, modulated)				
	Material		Enclosure: Die-cast zinc alloy, Indicator cover: Polyethersulphone, Lens: Polycarbonate				
	Cable		0.15 mm ² 3-core oil, heat and cold resistant cabtyre cable, 3 m 9.843 ft long				
	Cable extension		Extension up to total 100 m 328.084 ft is possible with 0.3 mm ² , or more, cable.				
Selection Guide	Weight		Net weight: 85 g approx.				
Amplifier Built-in		essories	MS-RX-1 (Sensor mounting bracket				
Power Supply Built-in	Note	Where measurement condi	tions have not been specified precisely, the conditions used were	e an ambient temperature of +23 °C +73.4 °F.			

I/O CIRCUIT AND WIRING DIAGRAMS



Ramco National

I/O CIRCUIT AND WIRING DIAGRAMS



Isor

Gray non-glossy paper (Lightness: 3)

0.

- Right

Ó

- Center

Operating point { (mm in)

Se 100

0

4 0.157

Left


distance


Setting 50


Gray non

glossy paper (Lightness: 3)

10 0.39/







Correlation between sensing object size and sensing range



0 0.079 → Down 0.157 Center Operating point { (mm in)

50 × 50 mm

Non-glossy

Up

(Vertical)

Setting distance: 150 mm

5.906 in with slit mask

6 mm

Ó

Center

Operating point { (mm in)


0.

Down

pape

-18

These curves show the characteristics with the maximum sensing range set to 100 mm 3.937 in, 200 mm 7.874 in, each, with white non-glossy paper (50 × 50 mm 1.969 × 1.969 in).



50 × 50 mn

-11

Ser

0.

0.157

4 0.157

glossy

0

- Center

Operating point { (mm in)

	MICRO PHOTO- ELECTRIC SENSORS
	AREA SENSORS
	LIGHT CURTAINS / SAFETY COMPONENTS
	PRESSURE / FLOW SENSORS
	INDUCTIVE PROXIMITY SENSORS
	PARTICULAR USE SENSORS
	SENSOR OPTIONS
	SIMPLE WIRE-SAVING UNITS
-	WIRE-SAVING SYSTEMS
	MEASURE- MENT SENSORS
	STATIC ELECTRICITY PREVENTION DEVICES
	LASER MARKERS
	PLC
	HUMAN MACHINE INTERFACES

ENERGY

VISUALIZATIC

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

0.157

Down


380

FIBER SENSORS

.mplifie uilt-in Power Supply Built-in Amplifier-separated

CX-400 CY-100 EX-10 EX-20 EX-30 EX-40 CX-440 EQ-30 EQ-500 MQ-W RX-LS20 RX RT-610

SENSING CHARACTERISTICS (TYPICAL)



PRECAUTIONS FOR PROPER USE


• Never use this product as a sensing device for personnel protection.




 In case of using sensing devices for personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.

Mounting

• The tightening torque should be 1.17 N·m or less.



- intersection of the "⊲" mark on the lens face and the " | " line.
- Care must be taken regarding the sensor mounting direction with respect to the object's direction of movement.



- detect an object in this direction because it may cause unstable operation. biect (aluminum or coppe
- When detecting a specular object (aluminum or copper foil) or an object having a glossy surface or coating, please take care that there are cases when the object may not be detected due to a small change in angle, wrinkles on the object surface, etc.
- When a specular body is present below the sensor, use the sensor by tilting it slightly upwards to avoid wrong operation.

Refer to p.1458~ for general precautions.

- If a specular body is present in the background, wrong operation may be caused due to a small change in the angle of the background body. In that case, install the sensor at an inclination and confirm the operation with the actual sensing object.
- Do not install the sensor at a distance of less than 50 mm 1.969 in from the object because the sensing is unstable in this range.

Wiring


• The output of **RX-LS200-P** does not incorporate a shortcircuit protection circuit. Do not connect it directly to a power supply or a capacitive load.

Use conditions to comply with CE Marking


• Following work must be done in case of using this product as a CE marking (European standard EMC Directive) conforming product.

Ensure that the shield is connected to 0 V or the actual ground.

 In case of connecting a sensor to power supply 0 V by using a shield (piping, etc.)



• In case of grounding by using a shield (piping, etc.)



Others

• Do not use during the initial transient time (50 ms) after the power supply is switched on.

FIBER

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

HUMAN MACHINE INTERFACES

COMPONENTS

MACHINE

VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide

Amplifie Built-ir

Power Supply Built-in Amplifierseparated

CX-400

CY-100

EX-10

FX-20

EX-30

EX-40

CX-440

EQ-30

EQ-500

MQ-W

RX-LS200 RX RT-610

ENERGY CONSUMPTION VISUALIZATION COMPONENTS

PLC

Adjusting procedure


3

4

point.

PRECAUTIONS FOR PROPER USE

Distance adjustment



Refer to p.1458~ for general precautions.	FIBER SENSORS



MICRO PHOTO-ELECTRI SENSOR

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS

PRESSURE FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS MEASURE-MENT SENSORS

STATIC ELECTRICITY PREVENTION

DEVICES

HUMAN MACHINE INTERFACES

ENERGY CONSUMPTION VISUALIZATIO COMPONENTS

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide

Power Supply Built-in

Optimum position

a 1 8

ø5

0.197

382

<When a sensing object moves horizontally to the sensor> Step Description Distance adjuster Turn the distance adjuster fully counterclockwise to the minimum sensing range position (50 mm 1 n approx.). (Do not turn excessively.) Place an object at the required distance from the sensor, turn the distance adjuster gradually 2 clockwise, and find out point "A" where the

sensor changes to the light received condition. Remove the object, turn the distance adjuster

further clockwise, and find out point "B" where

the sensor changes to the light received condition again with only the background.

When the sensor does not go to the light received condition even if the adjuster is fully

turned clockwise, point "B" is this extreme

The optimum position to stably detect objects is

the center point between "A" and "B".

<When a sensing object is approaching / moving away from the sensor> · Follow only steps ① and ② respectively. Since the sensing point


LASER MARKERS may change depending on the sensing object, be sure to check the operation with the actual sensing object. PLC

The CAD data in the dimensions can be downloaded from our website.

RX-LS200 RX-LS200-P Sensor PT-RX500 PT-RX1000 Protective tube (Optional) Operation mode switch Stability indicator (Green) Distance adjuster (2-turn) 9 15 0.35 Pointe Cover-fixing screw Ð ration indicator (Red) Op Indicator cover (2.5) 0.276 spiral tube ø10 ø0.394 /M10 × 1 M10 × 1 0.039 thread [Brass (C3604) (Nickel plated)] 35 Beam-receiving par (Brass) [Stainless steel (SUS304)] 3 ï 2-M4 × 0.7 0.028 Internal thread M8 × 0.75 0.030, 4 0.157 deep thru-hole threads 14 3.6 Sensing axis Length L 35 Model No. Length L 14 PT-RX500 500⁺¹⁰ 19.685+0.394 Beam-emitting part PT-RX1000 1,000 +10 39.370 6 6 cable, 3 m 9.843 ft long 1.5 5.5 0.217 0.236

DIMENSIONS (Unit: mm in)

MS-RX-1



Ramco National

1-800-280-6933